



AD *ADVANCED*
DIAGNOSTICS™

VAG Guide



VAG GUIDE

When a VAG vehicle is selected from the vehicle menu, the menu structure is set to link most vehicles to the Auto Detect system. This is indicated by Mi 909. The Auto Detect function is linked to ADS2219 Software

The screenshot displays the diagnostic software interface for a Volkswagen Golf. The top navigation bar shows the vehicle model 'VOLKSWAGEN GOLF | EUROPE | 2008 - 2009 | BLADE'. The left sidebar contains menu items: Vehicle Info, Photos, Tips and Hints, Remote, Service Light Reset, and Feedback. The main area is divided into two columns. The left column lists vehicle specifications, and the right column lists diagnostic functions. The 'Program Remotes(905)' and 'Program Immobiliser(909)' options are highlighted with red boxes. A green 'Connect' button is visible at the bottom right of the menu.

Category	Item	Value
Vehicle Information	Chassis	5
	Fuel	ANY
	Gearbox	ANY
SmartPro Information	Program Transponder	Yes
	Program Remotes	Yes
	PIN Code Reading	Yes
	Pre-coded Key	Yes
	Pre-Coding Read	Yes
	Transponder Type	48-A1
	PIN Code Required	No
	Add Key	No
	Working Key Required	No
	Coverage	Partial
SmartPro Information	Immobiliser System	VDO TP2.0
	Remote System	CAN TP2.0
	PIN Code System	ENGINE OR CLUSTER



VAG GUIDE

If for some reason the Auto Detect function fails, what do we do?

- For this example we will use these details:
 - VW Golf
 - 2008
 - 1K Chassis
 - Engine Code BXE
- This information can be found from the White paper label in the spare wheel compartment or from the Chassis plate of the vehicle



VAG GUIDE


Firstly we need to establish which system we need to select to retrieve the PIN code. To do this select the By System menu, and select Engine Code to System Special Function

System Name	System Type	Key Type
REMOTE	TP20 TYPE 7	BLADE
REMOTE	TP20 TYPE 8	BLADE
REMOTE	TP20 TYPE 9	BLADE
SPECIAL FUNCTION	AUTO GEARBOX	
SPECIAL FUNCTION	ENGINE CODE TO SYSTEM	ALL
SPECIAL FUNCTION	UDS ABS CODING	
SPECIAL FUNCTION	VAG RECODE ECU 1	
SPECIAL FUNCTION	VAG RECODE ECU 2	
SPECIAL FUNCTION	VAG SRS	




VAG GUIDE

Engine code to System convertor can be used on the bench prior to connecting to the vehicle




VAG GUIDE

Select between 3 or 4 digit Engine Code




VAG GUIDE

Enter Engine Code



VAG GUIDE

Systems related to the Engine code are displayed



VAG GUIDE

Go back to the By System and select the PIN read system as advised by conversion tool, As you can see there are 4 options for this engine code but we can at least now narrow this down from the 58 PIN read systems available

System Name	System Type	Key Type
PIN READ	EDC16CP1	BLADE
PIN READ	EDC16CP2	BLADE
PIN READ	EDC16U1 TYPE 1	BLADE
PIN READ	EDC16U1 TYPE 2	BLADE
PIN READ	EDC16U31 TYPE 1	BLADE
PIN READ	EDC16U31 TYPE 2	BLADE
PIN READ	EDC16U34 TYPE 1	BLADE
PIN READ	EDC16U34 TYPE 2	BLADE
PIN READ	EDC17	BLADE



VAG GUIDE

Key Programming – By System. Information on the key programming system is usually displayed in the Vehicle Information area of Smart Pro, for example VDO TP2.0 on this vehicle

The screenshot shows the Smart Pro interface for a Volkswagen Golf. The top navigation bar includes a home icon, a 'T' icon with '5', a '24' icon with '0', and system status icons for voltage, engine, Wi-Fi, and battery, along with the time 15:51. Below this, the vehicle model 'VOLKSWAGEN GOLF | EUROPE | 2008 - 2009 | BLADE' is displayed.

The main interface is divided into two columns. The left column contains a sidebar with icons for 'Vehicle Info', 'Photos', 'Tips and Hints', 'Remote', 'Service Light Reset', and 'Feedback'. The right column displays a list of vehicle information and programming options.


Category	Item	Value
Vehicle Information	Chassis	5
	Fuel	ANY
	Gearbox	ANY
	Program Transponder	Yes
SmartPro Information	Program Remotes	Yes
	PIN Code Reading	Yes
	Pre-coded Key	Yes
	Pre-Coding Read	Yes
	Transponder Type	48-A1
	PIN Code Required	No
	Add Key	No
SmartPro Information	Working Key Required	No
	Coverage	Partial
	Immobiliser System	VDO TP2.0
SmartPro Information	Remote System	CAN TP2.0
	PIN Code System	ENGINE OR CLUSTER

On the right side, there are two main programming options: 'Program Remotes(905)' and 'Program Immobiliser(909)'. Below these are 'Identification' and 'Program keys'. A large green button at the bottom right is labeled 'Program Immobiliser Connect'.



VAG GUIDE

Select the Immobiliser system advised by the Vehicle information, as illustrated there are 6 options for TP2.0, this can be narrowed down depending on key type. ADC219 is for lost key situation, TP2.0 Dash reads from the instrument cluster & TP2.0 Immo reads from the engine management



System Name	System Type	Key Type
IMMOBILISER	KW2000 TYPE 2	BLADE
IMMOBILISER	TP20 ADC219	BLADE
IMMOBILISER	TP20 DASH	BLADE
IMMOBILISER	TP20 IMMO	BLADE
IMMOBILISER	TP20 TYPE 1	SLOT
IMMOBILISER	TP20 TYPE 2	BLADE
IMMOBILISER	TP20 TYPE 3	SLOT
IMMOBILISER	UDS ADC219	BLADE
IMMOBILISER	UDS MARELLI	BLADE



By System list – as displayed on AD100Pro/MVPPro

This list cross-references Pro Menu to the Smart Pro By System list

					SP System selection
READ PINCODE					
READ PINCODE	IMMOBOX				PIN READ KW1281 IMMO BLADE
READ PINCODE	DASH PANEL	VDOMOTOMETERMM			PIN READ KW1281 DASH BLADE
READ PINCODE	DASH PANEL	RB4RB8			PIN READ KW2000 RB4 DASH BLADE
READ PINCODE	DASH PANEL	RB8AUDI A4			PIN READ KW2000 RB8 BLADE
READ PINCODE	DASH PANEL	VDOTP20			PIN READ VDO TP20 DASH BLADE
READ PINCODE	DASH PANEL	MMCLUSTER	MM4		PIN READ MM4 BLADE
READ PINCODE	DASH PANEL	MMCLUSTER	USA MM4 VW		PIN READ MM4 VW BLADE
READ PINCODE	DASH PANEL	MMCLUSTER	USA MM4 AUDI		PIN READ USA MM4 AUDI BLADE
READ PINCODE	DASH PANEL	MMCLUSTER	EUR MM4 VW		PIN READ EUR MM4 VW BLADE
READ PINCODE	DASH PANEL	MMCLUSTER	EUR MM4 AUDI 1		PIN READ EUR MM4 AUDI BLADE
READ PINCODE	DASH PANEL	MMCLUSTER	EUR MM4 AUDI 2		PIN READ MM4 BLADE
READ PINCODE	DASH PANEL	MMCLUSTER	USA MM4 AUDI A3		PIN READ USA MM4 AUDI A3 BLADE
READ PINCODE	DASH PANEL	MMCLUSTER	BEETLE MM5		PIN READ BEETLE MM5 BLADE
READ PINCODE	DASH PANEL	MMCLUSTER	BEETLE MM5 05	TYPE 1	PIN READ BEETLE MM5 05 TYPE 1 BLADE
READ PINCODE	DASH PANEL	MMCLUSTER	BEETLE MM5 05	TYPE 2	PIN READ BEETLE MM5 05 TYPE 2 BLADE
READ PINCODE	ENGINE	EDC15			PIN READ EDC15 BLADE
READ PINCODE	ENGINE	EDC16MED9XISO			PIN READ EDC16 BLADE
READ PINCODE	ENGINE	EDC16EDC17MED9XCAN	BLADED KEY		PIN READ EDC16 CAN BLADED
READ PINCODE	ENGINE	EDC16EDC17MED9XCAN	SLOT KEY		PIN READ EDC16 CAN SLOT
READ PINCODE	ENGINE	EDC17			PIN READ EDC17 BLADE
READ PINCODE	ENGINE	ME 7X7XX1			PIN READ KW1281 EMS BLADE
READ PINCODE	ENGINE	ME 7X7XX2			PIN READ KW2000 EMS 1 BLADE
READ PINCODE	ENGINE	ME 7XCRCACFZA			PIN READ KW2000 EMS 2 BLADE
BY SYSTEM					
BY SYSTEM	ISO KW1281	READ PINCODE	ENGINE		PIN READ KW1281 EMS BLADE
BY SYSTEM	ISO KW1281	READ PINCODE	IMMOBOX		PIN READ KW1281 IMMO BLADE
BY SYSTEM	ISO KW1281	READ PINCODE	DASH PANEL	VDOMARELLI	PIN READ KW1281 DASH BLADE
BY SYSTEM	ISO KW1281	READ PINCODE	DASH PANEL	RB4RB8	PIN READ KW2000 RB4 DASH BLADE
BY SYSTEM	ISO KW1281	PROGRAM KEYS	IMMOBOX		IMMOBILISER KW1281 IMMO BLADE
BY SYSTEM	ISO KW1281	PROGRAM KEYS	DASH PANEL		IMMOBILISER KW1281 DASH BLADE
BY SYSTEM	ISO KW1281	PROGRAM REMOTES	CENTLOCK		REMOTE KW1281 TYPE 1 BLADE
BY SYSTEM	ISO KW1281	PROGRAM REMOTES	CENTCONV		REMOTE KW1281 TYPE 2 BLADE
BY SYSTEM	ISO KW2000	READ PINCODE	RB8AUDI A4		PIN READ KW2000 RB8 BLADE
BY SYSTEM	ISO KW2000	READ PINCODE	EDC15		PIN READ EDC15 BLADE
BY SYSTEM	ISO KW2000	READ PINCODE	EDC16U1		PIN READ EDC16U1 TYPE 2 BLADE
BY SYSTEM	ISO KW2000	READ PINCODE	EDC16U31		PIN READ EDC16U31 TYPE 2 BLADE
BY SYSTEM	ISO KW2000	READ PINCODE	EDC16U34		PIN READ EDC16U34 TYPE 2 BLADE
BY SYSTEM	ISO KW2000	READ PINCODE	ME 71X		PIN READ KW2000 EMS 1 BLADE
BY SYSTEM	ISO KW2000	READ PINCODE	ME 7XCRCACFZA		PIN READ KW2000 EMS 2 BLADE
BY SYSTEM	ISO KW2000	PROGRAM KEYS	IMMOBOX		IMMOBILISER KW2000 IMMO BLADE
BY SYSTEM	ISO KW2000	PROGRAM KEYS	DASH PANEL		IMMOBILISER KW2000 DASH BLADE
BY SYSTEM	ISO KW2000	PROGRAM KEYS	KESY		IMMOBILISER KW2000 KESY BLADE
BY SYSTEM	ISO KW2000	PROGRAM REMOTES			REMOTE KW2000 BLADE
BY SYSTEM	TP20	READ PINPRE	DPI		PIN READ VDO TP20 DASH BLADE
BY SYSTEM	TP20	READ PINPRE	EDC16C4		PIN READ EDC16C4 BLADE
BY SYSTEM	TP20	READ PINPRE	EDC16CP1		PIN READ EDC16CP1 BLADE
BY SYSTEM	TP20	READ PINPRE	EDC16CP2		PIN READ EDC16CP2 BLADE
BY SYSTEM	TP20	READ PINPRE	EDC16U1		PIN READ EDC16U1 TYPE 1 BLADE
BY SYSTEM	TP20	READ PINPRE	EDC16U31		PIN READ EDC16U31 TYPE 1 BLADE
BY SYSTEM	TP20	READ PINPRE	EDC16U34		PIN READ EDC16U34 TYPE 1 BLADE
BY SYSTEM	TP20	READ PINPRE	MED 91		PIN READ MED 91 TYPE 1 BLADE
BY SYSTEM	TP20	READ PINPRE	MED 9510		PIN READ MED 9510 BLADE
BY SYSTEM	TP20	READ PINPRE	MICRONAS ADC219,		PIN READ MICRONAS ADC219 BLADE
BY SYSTEM	TP20	READ PINPRE	PPD 1115		PIN READ PPD 1115 BLADE
BY SYSTEM	TP20	PROGRAM KEYS	2003 to 2007		IMMOBILISER TP20 DASH BLADE
BY SYSTEM	TP20	PROGRAM KEYS	2007 to 2009	WITH WORKING KEY	IMMOBILISER TP20 IMMO BLADE
BY SYSTEM	TP20	PROGRAM KEYS	2007 to 2009	KEYS LOST ADC219	IMMOBILISER TP20 ADC219 BLADE
BY SYSTEM	TP20	PROGRAM REMOTES	CENTCONV		REMOTE TP20 TYPE 1 BLADE
BY SYSTEM	TP20	PROGRAM REMOTES	CENTELEC		REMOTE TP20 TYPE 2 BLADE
BY SYSTEM	UDS	PROGRAM KEYS	VDO DASH	WITH WORKING KEY	IMMOBILISER UDS VDO BLADE
BY SYSTEM	UDS	PROGRAM KEYS	VDO DASH	ABS CODING	SPECIAL FUNCTION UDS ABS CODING
BY SYSTEM	UDS	PROGRAM KEYS	VDO DASH	KEYS LOST ADC219	IMMOBILISER UDS ADC219 BLADE
BY SYSTEM	UDS	PROGRAM KEYS	MARELLI DASH		IMMOBILISER UDS MARELLI BLADE

							SP System selection
BY VEHICLE	A2	IMMOBILISER					IMMOBILISER KW1281 TYPE 2 BLADE
BY VEHICLE	A2	REMOTE	TYPE 1				REMOTE KW1281 TYPE 3 BLADE
BY VEHICLE	A2	REMOTE	TYPE 2				REMOTE KW1281 TYPE 4 BLADE
BY VEHICLE	A2	REMOTE	TYPE 3				REMOTE TP20 TYPE 8 BLADE
BY VEHICLE	A2	REMOTE	TYPE 4				REMOTE TP20 TYPE 9 BLADE
BY VEHICLE	A2	AUTO GEARBOX					SPECIAL FUNCTION AUTO GEARBOX
BY VEHICLE	A2	SRS AIRBAG					SPECIAL FUNCTION VAG SRS
BY VEHICLE	A2	READ PINCODE	AMF				PIN READ EDC15 BLADE
BY VEHICLE	A2	READ PINCODE	ANY				PIN READ EDC15 BLADE
BY VEHICLE	A2	READ PINCODE	ATL				PIN READ EDC15 BLADE
BY VEHICLE	A2	READ PINCODE	AUA				PIN READ AUTO CLUSTER BLADE
BY VEHICLE	A2	READ PINCODE	BAD				PIN READ KW1281 EMS BLADE
BY VEHICLE	A2	READ PINCODE	BAY				PIN READ EDC15 BLADE
BY VEHICLE	A2	READ PINCODE	BBY				PIN READ AUTO CLUSTER BLADE
BY VEHICLE	A2	READ PINCODE	BHC				PIN READ EDC15 BLADE
BY VEHICLE	A3	8L	IMMOBILISER				IMMOBILISER KW1281 TYPE 2 BLADE
BY VEHICLE	A3	8L	REMOTE	TYPE 1			REMOTE KW1281 TYPE 3 BLADE
BY VEHICLE	A3	8L	REMOTE	TYPE 2			REMOTE KW1281 TYPE 4 BLADE
BY VEHICLE	A3	8L	REMOTE	TYPE 3			REMOTE TP20 TYPE 8 BLADE
BY VEHICLE	A3	8L	REMOTE	TYPE 4			REMOTE TP20 TYPE 9 BLADE
BY VEHICLE	A3	8L	AUTO GEARBOX				SPECIAL FUNCTION AUTO GEARBOX
BY VEHICLE	A3	8L	SRS AIRBAG				SPECIAL FUNCTION VAG SRS
BY VEHICLE	A3	8L	READ PINCODE	AUTOCLUSTER			PIN READ AUTO CLUSTER BLADE
BY VEHICLE	A3	8L	READ PINCODE	MMCLUSTER	MM4		PIN READ MM4 BLADE
BY VEHICLE	A3	8L	READ PINCODE	MMCLUSTER	USA MM4 VW		PIN READ MM4 VW BLADE
BY VEHICLE	A3	8L	READ PINCODE	MMCLUSTER	USA MM4 AUDI		PIN READ USA MM4 AUDI BLADE
BY VEHICLE	A3	8L	READ PINCODE	MMCLUSTER	EURO MM4 VW		PIN READ EUR MM4 VW BLADE
BY VEHICLE	A3	8L	READ PINCODE	MMCLUSTER	EURO MM4 AUDI 1		PIN READ EUR MM4 AUDI BLADE
BY VEHICLE	A3	8L	READ PINCODE	MMCLUSTER	EURO MM4 AUDI 2		PIN READ MM4 BLADE
BY VEHICLE	A3	8L	READ PINCODE	MMCLUSTER	USA MM4 AUDI A3		PIN READ USA MM4 AUDI A3 BLADE
BY VEHICLE	A3	8L	READ PINCODE	AEH	AUTO		PIN READ AUTO CLUSTER BLADE
BY VEHICLE	A3	8L	READ PINCODE	AEH	MAGNETI MARELLI	MM4	PIN READ MM4 BLADE
BY VEHICLE	A3	8L	READ PINCODE	AEH	MAGNETI MARELLI	USA MM4 VW	PIN READ MM4 VW BLADE
BY VEHICLE	A3	8L	READ PINCODE	AEH	MAGNETI MARELLI	USA MM4 AUDI	PIN READ USA MM4 AUDI BLADE
BY VEHICLE	A3	8L	READ PINCODE	AEH	MAGNETI MARELLI	EURO MM4 VW	PIN READ EUR MM4 VW BLADE
BY VEHICLE	A3	8L	READ PINCODE	AEH	MAGNETI MARELLI	EURO MM4 AUDI 1	PIN READ EUR MM4 AUDI BLADE
BY VEHICLE	A3	8L	READ PINCODE	AEH	MAGNETI MARELLI	EURO MM4 AUDI 2	PIN READ MM4 BLADE
BY VEHICLE	A3	8L	READ PINCODE	AEH	MAGNETI MARELLI	USA MM4 AUDI A3	PIN READ USA MM4 AUDI A3 BLADE
BY VEHICLE	A3	8L	READ PINCODE	AGN	AUTO		PIN READ AUTO CLUSTER BLADE
BY VEHICLE	A3	8L	READ PINCODE	AGN	MAGNETI MARELLI	MM4	PIN READ MM4 BLADE
BY VEHICLE	A3	8L	READ PINCODE	AGN	MAGNETI MARELLI	USA MM4 VW	PIN READ MM4 VW BLADE
BY VEHICLE	A3	8L	READ PINCODE	AGN	MAGNETI MARELLI	USA MM4 AUDI	PIN READ USA MM4 AUDI BLADE
BY VEHICLE	A3	8L	READ PINCODE	AGN	MAGNETI MARELLI	EURO MM4 VW	PIN READ EUR MM4 VW BLADE
BY VEHICLE	A3	8L	READ PINCODE	AGN	MAGNETI MARELLI	EURO MM4 AUDI 1	PIN READ EUR MM4 AUDI BLADE
BY VEHICLE	A3	8L	READ PINCODE	AGN	MAGNETI MARELLI	EURO MM4 AUDI 2	PIN READ MM4 BLADE
BY VEHICLE	A3	8L	READ PINCODE	AGN	MAGNETI MARELLI	USA MM4 AUDI A3	PIN READ USA MM4 AUDI A3 BLADE
BY VEHICLE	A3	8L	READ PINCODE	AGR			PIN READ EDC15 BLADE
BY VEHICLE	A3	8L	READ PINCODE	AGU	AUTO		PIN READ AUTO CLUSTER BLADE
BY VEHICLE	A3	8L	READ PINCODE	AGU	MAGNETI MARELLI	MM4	PIN READ MM4 BLADE
BY VEHICLE	A3	8L	READ PINCODE	AGU	MAGNETI MARELLI	USA MM4 VW	PIN READ MM4 VW BLADE
BY VEHICLE	A3	8L	READ PINCODE	AGU	MAGNETI MARELLI	USA MM4 AUDI	PIN READ USA MM4 AUDI BLADE
BY VEHICLE	A3	8L	READ PINCODE	AGU	MAGNETI MARELLI	EURO MM4 VW	PIN READ EUR MM4 VW BLADE
BY VEHICLE	A3	8L	READ PINCODE	AGU	MAGNETI MARELLI	EURO MM4 AUDI 1	PIN READ EUR MM4 AUDI BLADE
BY VEHICLE	A3	8L	READ PINCODE	AGU	MAGNETI MARELLI	EURO MM4 AUDI 2	PIN READ MM4 BLADE
BY VEHICLE	A3	8L	READ PINCODE	AGU	MAGNETI MARELLI	USA MM4 AUDI A3	PIN READ USA MM4 AUDI A3 BLADE
BY VEHICLE	A3	8L	READ PINCODE	AHF			PIN READ EDC15 BLADE
BY VEHICLE	A3	8L	READ PINCODE	AHL			PIN READ KW1281 EMS BLADE
BY VEHICLE	A3	8L	READ PINCODE	AHU			PIN READ EDC15 BLADE
BY VEHICLE	A3	8L	READ PINCODE	AJM			PIN READ EDC15 BLADE
BY VEHICLE	A3	8L	READ PINCODE	AJQ			PIN READ KW1281 EMS BLADE
BY VEHICLE	A3	8L	READ PINCODE	AKL	AUTO		PIN READ AUTO CLUSTER BLADE
BY VEHICLE	A3	8L	READ PINCODE	AKL	MAGNETI MARELLI	MM4	PIN READ MM4 BLADE
BY VEHICLE	A3	8L	READ PINCODE	AKL	MAGNETI MARELLI	USA MM4 VW	PIN READ MM4 VW BLADE
BY VEHICLE	A3	8L	READ PINCODE	AKL	MAGNETI MARELLI	USA MM4 AUDI	PIN READ USA MM4 AUDI BLADE

Audi 1/12

By Vehicle list – as displayed on AD100Pro/MVPPPro

This list cross-references Pro Menu to the Smart Pro By System list

Audi 2/12

By Vehicle list – as displayed on AD100Pro/MVPPPro

This list cross-references Pro Menu to the Smart Pro By System list

BY VEHICLE	A3	8L	READ PINCODE	AKL	MAGNETI MARELLI	EURO MM4 VW	PIN READ EUR MM4 VW BLADE
BY VEHICLE	A3	8L	READ PINCODE	AKL	MAGNETI MARELLI	EURO MM4 AUDI 1	PIN READ EUR MM4 AUDI BLADE
BY VEHICLE	A3	8L	READ PINCODE	AKL	MAGNETI MARELLI	EURO MM4 AUDI 2	PIN READ MM4 BLADE
BY VEHICLE	A3	8L	READ PINCODE	AKL	MAGNETI MARELLI	USA MM4 AUDI A3	PIN READ USA MM4 AUDI A3 BLADE
BY VEHICLE	A3	8L	READ PINCODE	ALH			PIN READ EDC15 BLADE
BY VEHICLE	A3	8L	READ PINCODE	ANU			PIN READ EDC15 BLADE
BY VEHICLE	A3	8L	READ PINCODE	APG			PIN READ KW1281 EMS BLADE
BY VEHICLE	A3	8L	READ PINCODE	AQA			PIN READ KW1281 EMS BLADE
BY VEHICLE	A3	8L	READ PINCODE	ARX			PIN READ KW1281 EMS BLADE
BY VEHICLE	A3	8L	READ PINCODE	ARY			PIN READ KW1281 EMS BLADE
BY VEHICLE	A3	8L	READ PINCODE	ARZ			PIN READ KW1281 EMS BLADE
BY VEHICLE	A3	8L	READ PINCODE	ASV			PIN READ EDC15 BLADE
BY VEHICLE	A3	8L	READ PINCODE	ASZ			PIN READ EDC15 BLADE
BY VEHICLE	A3	8L	READ PINCODE	ATD			PIN READ EDC15 BLADE
BY VEHICLE	A3	8L	READ PINCODE	AUM			PIN READ KW1281 EMS BLADE
BY VEHICLE	A3	8L	READ PINCODE	AUQ			PIN READ KW1281 EMS BLADE
BY VEHICLE	A3	8L	READ PINCODE	AUY			PIN READ EDC15 BLADE
BY VEHICLE	A3	8L	READ PINCODE	AVU	AUTO		PIN READ AUTO CLUSTER BLADE
BY VEHICLE	A3	8L	READ PINCODE	AVU	MAGNETI MARELLI	MM4	PIN READ MM4 BLADE
BY VEHICLE	A3	8L	READ PINCODE	AVU	MAGNETI MARELLI	USA MM4 VW	PIN READ MM4 VW BLADE
BY VEHICLE	A3	8L	READ PINCODE	AVU	MAGNETI MARELLI	USA MM4 AUDI	PIN READ USA MM4 AUDI BLADE
BY VEHICLE	A3	8L	READ PINCODE	AVU	MAGNETI MARELLI	EURO MM4 VW	PIN READ EUR MM4 VW BLADE
BY VEHICLE	A3	8L	READ PINCODE	AVU	MAGNETI MARELLI	EURO MM4 AUDI 1	PIN READ EUR MM4 AUDI BLADE
BY VEHICLE	A3	8L	READ PINCODE	AVU	MAGNETI MARELLI	EURO MM4 AUDI 2	PIN READ MM4 BLADE
BY VEHICLE	A3	8L	READ PINCODE	AVU	MAGNETI MARELLI	USA MM4 AUDI A3	PIN READ USA MM4 AUDI A3 BLADE
BY VEHICLE	A3	8L	READ PINCODE	AXR			PIN READ EDC15 BLADE
BY VEHICLE	A3	8L	READ PINCODE	BAM			PIN READ KW1281 EMS BLADE
BY VEHICLE	A3	8L	READ PINCODE	BFQ	AUTO		PIN READ AUTO CLUSTER BLADE
BY VEHICLE	A3	8L	READ PINCODE	BFQ	MAGNETI MARELLI	MM4	PIN READ MM4 BLADE
BY VEHICLE	A3	8L	READ PINCODE	BFQ	MAGNETI MARELLI	USA MM4 VW	PIN READ MM4 VW BLADE
BY VEHICLE	A3	8L	READ PINCODE	BFQ	MAGNETI MARELLI	USA MM4 AUDI	PIN READ USA MM4 AUDI BLADE
BY VEHICLE	A3	8L	READ PINCODE	BFQ	MAGNETI MARELLI	EURO MM4 VW	PIN READ EUR MM4 VW BLADE
BY VEHICLE	A3	8L	READ PINCODE	BFQ	MAGNETI MARELLI	EURO MM4 AUDI 1	PIN READ EUR MM4 AUDI BLADE
BY VEHICLE	A3	8L	READ PINCODE	BFQ	MAGNETI MARELLI	EURO MM4 AUDI 2	PIN READ MM4 BLADE
BY VEHICLE	A3	8L	READ PINCODE	BFQ	MAGNETI MARELLI	USA MM4 AUDI A3	PIN READ USA MM4 AUDI A3 BLADE
BY VEHICLE	A3	8P	IMMOBILISER				IMMOBILISER TP20 TYPE 2 BLADE
BY VEHICLE	A3	8P	REMOTE	TYPE 1			REMOTE TP20 TYPE 6 BLADE
BY VEHICLE	A3	8P	REMOTE	TYPE 2			REMOTE TP20 TYPE 7 BLADE
BY VEHICLE	A3	8P	READ PINCODE	AVQ			PIN READ EDC16U1 TYPE 1 BLADE
BY VEHICLE	A3	8P	READ PINCODE	AXW			PIN READ MED 9510 BLADE
BY VEHICLE	A3	8P	READ PINCODE	AXX			PIN READ MED 91 TYPE 1 BLADE
BY VEHICLE	A3	8P	READ PINCODE	AZV	EDC16U1		PIN READ EDC16U1 TYPE 1 BLADE
BY VEHICLE	A3	8P	READ PINCODE	AZV	EDC16U31		PIN READ EDC16U31 TYPE 1 BLADE
BY VEHICLE	A3	8P	READ PINCODE	BAG			PIN READ MED 9510 BLADE
BY VEHICLE	A3	8P	READ PINCODE	BDB			PIN READ KW2000 EMS 1 BLADE
BY VEHICLE	A3	8P	READ PINCODE	BHD			PIN READ MED 9510 BLADE
BY VEHICLE	A3	8P	READ PINCODE	BHZ			PIN READ MED 91 TYPE 1 BLADE
BY VEHICLE	A3	8P	READ PINCODE	BKC			PIN READ EDC16U1 TYPE 1 BLADE
BY VEHICLE	A3	8P	READ PINCODE	BKD			PIN READ EDC16U34 TYPE 1 BLADE
BY VEHICLE	A3	8P	READ PINCODE	BLF			PIN READ MED 9510 BLADE
BY VEHICLE	A3	8P	READ PINCODE	BLP			PIN READ MED 9510 BLADE
BY VEHICLE	A3	8P	READ PINCODE	BLR			PIN READ MED 9510 BLADE
BY VEHICLE	A3	8P	READ PINCODE	BLS			PIN READ EDC16U34 TYPE 1 BLADE
BY VEHICLE	A3	8P	READ PINCODE	BLX			PIN READ MED 9510 BLADE
BY VEHICLE	A3	8P	READ PINCODE	BLY			PIN READ MED 9510 BLADE
BY VEHICLE	A3	8P	READ PINCODE	BMB			PIN READ MED 9510 BLADE
BY VEHICLE	A3	8P	READ PINCODE	BMJ			PIN READ KW2000 EMS 1 BLADE
BY VEHICLE	A3	8P	READ PINCODE	BMM			PIN READ EDC16U34 TYPE 1 BLADE
BY VEHICLE	A3	8P	READ PINCODE	BMN			PIN READ PPD 1115 BLADE
BY VEHICLE	A3	8P	READ PINCODE	BPU			PIN READ MED 17.5 BLADE
BY VEHICLE	A3	8P	READ PINCODE	BPY			PIN READ MED 91 TYPE 1 BLADE
BY VEHICLE	A3	8P	READ PINCODE	BUB			PIN READ KW2000 EMS 1 BLADE
BY VEHICLE	A3	8P	READ PINCODE	BUY			PIN READ PPD 1115 BLADE
BY VEHICLE	A3	8P	READ PINCODE	BVY			PIN READ MED 9510 BLADE
BY VEHICLE	A3	8P	READ PINCODE	BVZ			PIN READ MED 9510 BLADE

Audi 3/12

By Vehicle list – as displayed on AD100Pro/MVPPPro

This list cross-references Pro Menu to the Smart Pro By System list

BY VEHICLE	A3	8P	READ PINCODE	BWA			PIN READ MED 91 TYPE 1 BLADE
BY VEHICLE	A3	8P	READ PINCODE	BXE			PIN READ EDC16U34 TYPE 1 BLADE
BY VEHICLE	A3	8P	READ PINCODE	BYT			PIN READ MED 17.5 BLADE
BY VEHICLE	A3	8P	READ PINCODE	BZB			PIN READ MED 17.5 BLADE
BY VEHICLE	A3	8P	READ PINCODE	CAWB			PIN READ MED 17.5 BLADE
BY VEHICLE	A3	8P	READ PINCODE	CAXC			PIN READ MED 17.5 BLADE
BY VEHICLE	A3	8P	READ PINCODE	CBAA			PIN READ EDC17 BLADE
BY VEHICLE	A3	8P	READ PINCODE	CBAB			PIN READ EDC17 BLADE
BY VEHICLE	A3	8P	READ PINCODE	CBBB			PIN READ EDC17 BLADE
BY VEHICLE	A3	8P	READ PINCODE	CBEA			PIN READ EDC17 BLADE
BY VEHICLE	A3	8P	READ PINCODE	CBFA			PIN READ MED 17.5 BLADE
BY VEHICLE	A3	8P	READ PINCODE	CBRA			PIN READ KW2000 EMS 1 BLADE
BY VEHICLE	A3	8P	READ PINCODE	CCTA			PIN READ MED 17.5 BLADE
BY VEHICLE	A3	8P	READ PINCODE	CCZA			PIN READ MED 17.5 BLADE
BY VEHICLE	A3	8P	READ PINCODE	CDA A			PIN READ MED 17.5 BLADE
BY VEHICLE	A3	8P	READ PINCODE	CDLA			PIN READ MED 91 TYPE 1 BLADE
BY VEHICLE	A4	8D	IMMOBILISER	TYPE 1			IMMOBILISER KW1281 TYPE 1 BLADE
BY VEHICLE	A4	8D	IMMOBILISER	TYPE 2			IMMOBILISER KW1281 TYPE 2 BLADE
BY VEHICLE	A4	8D	IMMOBILISER	TYPE 3			IMMOBILISER KW2000 TYPE 1 BLADE
BY VEHICLE	A4	8D	REMOTE	TYPE 1			REMOTE KW1281 TYPE 3 BLADE
BY VEHICLE	A4	8D	REMOTE	TYPE 2			REMOTE KW1281 TYPE 4 BLADE
BY VEHICLE	A4	8D	REMOTE	TYPE 3			REMOTE TP20 TYPE 8 BLADE
BY VEHICLE	A4	8D	REMOTE	TYPE 4			REMOTE TP20 TYPE 9 BLADE
BY VEHICLE	A4	8D	AUTO GEARBOX				SPECIAL FUNCTION AUTO GEARBOX
BY VEHICLE	A4	8D	SRS AIRBAG				SPECIAL FUNCTION VAG SRS
BY VEHICLE	A4	8D	READ PINCODE	AUTOCLUSTER			PIN READ AUTO CLUSTER BLADE
BY VEHICLE	A4	8D	READ PINCODE	MMCLUSTER	MM4		PIN READ MM4 BLADE
BY VEHICLE	A4	8D	READ PINCODE	MMCLUSTER	USA MM4 VW		PIN READ MM4 VW BLADE
BY VEHICLE	A4	8D	READ PINCODE	MMCLUSTER	USA MM4 AUDI		PIN READ USA MM4 AUDI BLADE
BY VEHICLE	A4	8D	READ PINCODE	MMCLUSTER	EURO MM4 VW		PIN READ EUR MM4 VW BLADE
BY VEHICLE	A4	8D	READ PINCODE	MMCLUSTER	EURO MM4 AUDI 1		PIN READ EUR MM4 AUDI BLADE
BY VEHICLE	A4	8D	READ PINCODE	MMCLUSTER	EURO MM4 AUDI 2		PIN READ MM4 BLADE
BY VEHICLE	A4	8D	READ PINCODE	MMCLUSTER	USA MM4 AUDI A3		PIN READ USA MM4 AUDI A3 BLADE
BY VEHICLE	A4	8D	READ PINCODE	IMMOBILISER BOX			PIN READ IMMO BOX BLADE
BY VEHICLE	A4	8D	READ PINCODE	AAH	AUTO		PIN READ AUTO CLUSTER BLADE
BY VEHICLE	A4	8D	READ PINCODE	AAH	MAGNETI MARELLI	MM4	PIN READ MM4 BLADE
BY VEHICLE	A4	8D	READ PINCODE	AAH	MAGNETI MARELLI	USA MM4 VW	PIN READ MM4 VW BLADE
BY VEHICLE	A4	8D	READ PINCODE	AAH	MAGNETI MARELLI	USA MM4 AUDI	PIN READ USA MM4 AUDI BLADE
BY VEHICLE	A4	8D	READ PINCODE	AAH	MAGNETI MARELLI	EURO MM4 VW	PIN READ EUR MM4 VW BLADE
BY VEHICLE	A4	8D	READ PINCODE	AAH	MAGNETI MARELLI	EURO MM4 AUDI 1	PIN READ EUR MM4 AUDI BLADE
BY VEHICLE	A4	8D	READ PINCODE	AAH	MAGNETI MARELLI	EURO MM4 AUDI 2	PIN READ MM4 BLADE
BY VEHICLE	A4	8D	READ PINCODE	AAH	MAGNETI MARELLI	USA MM4 AUDI A3	PIN READ USA MM4 AUDI A3 BLADE
BY VEHICLE	A4	8D	READ PINCODE	ABC	AUTO		PIN READ AUTO CLUSTER BLADE
BY VEHICLE	A4	8D	READ PINCODE	ABC	MAGNETI MARELLI	MM4	PIN READ MM4 BLADE
BY VEHICLE	A4	8D	READ PINCODE	ABC	MAGNETI MARELLI	USA MM4 VW	PIN READ MM4 VW BLADE
BY VEHICLE	A4	8D	READ PINCODE	ABC	MAGNETI MARELLI	USA MM4 AUDI	PIN READ USA MM4 AUDI BLADE
BY VEHICLE	A4	8D	READ PINCODE	ABC	MAGNETI MARELLI	EURO MM4 VW	PIN READ EUR MM4 VW BLADE
BY VEHICLE	A4	8D	READ PINCODE	ABC	MAGNETI MARELLI	EURO MM4 AUDI 1	PIN READ EUR MM4 AUDI BLADE
BY VEHICLE	A4	8D	READ PINCODE	ABC	MAGNETI MARELLI	EURO MM4 AUDI 2	PIN READ MM4 BLADE
BY VEHICLE	A4	8D	READ PINCODE	ABC	MAGNETI MARELLI	USA MM4 AUDI A3	PIN READ USA MM4 AUDI A3 BLADE
BY VEHICLE	A4	8D	READ PINCODE	ACK	AUTO		PIN READ AUTO CLUSTER BLADE
BY VEHICLE	A4	8D	READ PINCODE	ACK	MAGNETI MARELLI	MM4	PIN READ MM4 BLADE
BY VEHICLE	A4	8D	READ PINCODE	ACK	MAGNETI MARELLI	USA MM4 VW	PIN READ MM4 VW BLADE
BY VEHICLE	A4	8D	READ PINCODE	ACK	MAGNETI MARELLI	USA MM4 AUDI	PIN READ USA MM4 AUDI BLADE
BY VEHICLE	A4	8D	READ PINCODE	ACK	MAGNETI MARELLI	EURO MM4 VW	PIN READ EUR MM4 VW BLADE
BY VEHICLE	A4	8D	READ PINCODE	ACK	MAGNETI MARELLI	EURO MM4 AUDI 1	PIN READ EUR MM4 AUDI BLADE
BY VEHICLE	A4	8D	READ PINCODE	ACK	MAGNETI MARELLI	EURO MM4 AUDI 2	PIN READ MM4 BLADE
BY VEHICLE	A4	8D	READ PINCODE	ACK	MAGNETI MARELLI	USA MM4 AUDI A3	PIN READ USA MM4 AUDI A3 BLADE
BY VEHICLE	A4	8D	READ PINCODE	ACZ	AUTO		PIN READ AUTO CLUSTER BLADE
BY VEHICLE	A4	8D	READ PINCODE	ACZ	MAGNETI MARELLI	MM4	PIN READ MM4 BLADE
BY VEHICLE	A4	8D	READ PINCODE	ACZ	MAGNETI MARELLI	USA MM4 VW	PIN READ MM4 VW BLADE
BY VEHICLE	A4	8D	READ PINCODE	ACZ	MAGNETI MARELLI	USA MM4 AUDI	PIN READ USA MM4 AUDI BLADE
BY VEHICLE	A4	8D	READ PINCODE	ACZ	MAGNETI MARELLI	EURO MM4 VW	PIN READ EUR MM4 VW BLADE
BY VEHICLE	A4	8D	READ PINCODE	ACZ	MAGNETI MARELLI	EURO MM4 AUDI 1	PIN READ EUR MM4 AUDI BLADE
BY VEHICLE	A4	8D	READ PINCODE	ACZ	MAGNETI MARELLI	EURO MM4 AUDI 2	PIN READ MM4 BLADE

Audi 6/12

By Vehicle list – as displayed on AD100Pro/MVPPPro

This list cross-references Pro Menu to the Smart Pro By System list

BY VEHICLE	A4	8D	READ PINCODE	AMM	MAGNETI MARELLI	EURO MM4 AUDI 2	PIN READ MM4 BLADE
BY VEHICLE	A4	8D	READ PINCODE	AMM	MAGNETI MARELLI	USA MM4 AUDI A3	PIN READ USA MM4 AUDI A3 BLADE
BY VEHICLE	A4	8D	READ PINCODE	AMX			PIN READ KW1281 EMS BLADE
BY VEHICLE	A4	8D	READ PINCODE	ANA	AUTO		PIN READ AUTO CLUSTER BLADE
BY VEHICLE	A4	8D	READ PINCODE	ANA	MAGNETI MARELLI	MM4	PIN READ MM4 BLADE
BY VEHICLE	A4	8D	READ PINCODE	ANA	MAGNETI MARELLI	USA MM4 VW	PIN READ MM4 VW BLADE
BY VEHICLE	A4	8D	READ PINCODE	ANA	MAGNETI MARELLI	USA MM4 AUDI	PIN READ USA MM4 AUDI BLADE
BY VEHICLE	A4	8D	READ PINCODE	ANA	MAGNETI MARELLI	EURO MM4 VW	PIN READ EUR MM4 VW BLADE
BY VEHICLE	A4	8D	READ PINCODE	ANA	MAGNETI MARELLI	EURO MM4 AUDI 1	PIN READ EUR MM4 AUDI BLADE
BY VEHICLE	A4	8D	READ PINCODE	ANA	MAGNETI MARELLI	EURO MM4 AUDI 2	PIN READ MM4 BLADE
BY VEHICLE	A4	8D	READ PINCODE	ANA	MAGNETI MARELLI	USA MM4 AUDI A3	PIN READ USA MM4 AUDI A3 BLADE
BY VEHICLE	A4	8D	READ PINCODE	ANB			PIN READ KW1281 EMS BLADE
BY VEHICLE	A4	8D	READ PINCODE	APB			PIN READ KW1281 EMS BLADE
BY VEHICLE	A4	8D	READ PINCODE	APR			PIN READ KW1281 EMS BLADE
BY VEHICLE	A4	8D	READ PINCODE	APS			PIN READ KW1281 EMS BLADE
BY VEHICLE	A4	8D	READ PINCODE	APT			PIN READ KW1281 EMS BLADE
BY VEHICLE	A4	8D	READ PINCODE	APU			PIN READ KW1281 EMS BLADE
BY VEHICLE	A4	8D	READ PINCODE	APZ			PIN READ KW1281 EMS BLADE
BY VEHICLE	A4	8D	READ PINCODE	AQD			PIN READ KW1281 EMS BLADE
BY VEHICLE	A4	8D	READ PINCODE	ARG			PIN READ KW1281 EMS BLADE
BY VEHICLE	A4	8D	READ PINCODE	ARJ			PIN READ KW1281 EMS BLADE
BY VEHICLE	A4	8D	READ PINCODE	ARK			PIN READ KW1281 EMS BLADE
BY VEHICLE	A4	8D	READ PINCODE	ARM	AUTO		PIN READ AUTO CLUSTER BLADE
BY VEHICLE	A4	8D	READ PINCODE	ARM	MAGNETI MARELLI	MM4	PIN READ MM4 BLADE
BY VEHICLE	A4	8D	READ PINCODE	ARM	MAGNETI MARELLI	USA MM4 VW	PIN READ MM4 VW BLADE
BY VEHICLE	A4	8D	READ PINCODE	ARM	MAGNETI MARELLI	USA MM4 AUDI	PIN READ USA MM4 AUDI BLADE
BY VEHICLE	A4	8D	READ PINCODE	ARM	MAGNETI MARELLI	EURO MM4 VW	PIN READ EUR MM4 VW BLADE
BY VEHICLE	A4	8D	READ PINCODE	ARM	MAGNETI MARELLI	EURO MM4 AUDI 1	PIN READ EUR MM4 AUDI BLADE
BY VEHICLE	A4	8D	READ PINCODE	ARM	MAGNETI MARELLI	EURO MM4 AUDI 2	PIN READ MM4 BLADE
BY VEHICLE	A4	8D	READ PINCODE	ARM	MAGNETI MARELLI	USA MM4 AUDI A3	PIN READ USA MM4 AUDI A3 BLADE
BY VEHICLE	A4	8D	READ PINCODE	ASJ	AUTO		PIN READ AUTO CLUSTER BLADE
BY VEHICLE	A4	8D	READ PINCODE	ASJ	MAGNETI MARELLI	MM4	PIN READ MM4 BLADE
BY VEHICLE	A4	8D	READ PINCODE	ASJ	MAGNETI MARELLI	USA MM4 VW	PIN READ MM4 VW BLADE
BY VEHICLE	A4	8D	READ PINCODE	ASJ	MAGNETI MARELLI	USA MM4 AUDI	PIN READ USA MM4 AUDI BLADE
BY VEHICLE	A4	8D	READ PINCODE	ASJ	MAGNETI MARELLI	EURO MM4 VW	PIN READ EUR MM4 VW BLADE
BY VEHICLE	A4	8D	READ PINCODE	ASJ	MAGNETI MARELLI	EURO MM4 AUDI 1	PIN READ EUR MM4 AUDI BLADE
BY VEHICLE	A4	8D	READ PINCODE	ASJ	MAGNETI MARELLI	EURO MM4 AUDI 2	PIN READ MM4 BLADE
BY VEHICLE	A4	8D	READ PINCODE	ASJ	MAGNETI MARELLI	USA MM4 AUDI A3	PIN READ USA MM4 AUDI A3 BLADE
BY VEHICLE	A4	8D	READ PINCODE	ATJ			PIN READ EDC15 BLADE
BY VEHICLE	A4	8D	READ PINCODE	ATQ			PIN READ KW1281 EMS BLADE
BY VEHICLE	A4	8D	READ PINCODE	ATW			PIN READ KW1281 EMS BLADE
BY VEHICLE	A4	8D	READ PINCODE	ATX			PIN READ KW1281 EMS BLADE
BY VEHICLE	A4	8D	READ PINCODE	AVG			PIN READ EDC15 BLADE
BY VEHICLE	A4	8D	READ PINCODE	AVV			PIN READ KW1281 EMS BLADE
BY VEHICLE	A4	8D	READ PINCODE	AWM			PIN READ KW1281 EMS BLADE
BY VEHICLE	A4	8D	READ PINCODE	AWT			PIN READ KW1281 EMS BLADE
BY VEHICLE	A4	8D	READ PINCODE	AWX			PIN READ EDC15 BLADE
BY VEHICLE	A4	8D	READ PINCODE	AZB	AUTO		PIN READ AUTO CLUSTER BLADE
BY VEHICLE	A4	8D	READ PINCODE	AZB	MAGNETI MARELLI	MM4	PIN READ MM4 BLADE
BY VEHICLE	A4	8D	READ PINCODE	AZB	MAGNETI MARELLI	USA MM4 VW	PIN READ MM4 VW BLADE
BY VEHICLE	A4	8D	READ PINCODE	AZB	MAGNETI MARELLI	USA MM4 AUDI	PIN READ USA MM4 AUDI BLADE
BY VEHICLE	A4	8D	READ PINCODE	AZB	MAGNETI MARELLI	EURO MM4 VW	PIN READ EUR MM4 VW BLADE
BY VEHICLE	A4	8D	READ PINCODE	AZB	MAGNETI MARELLI	EURO MM4 AUDI 1	PIN READ EUR MM4 AUDI BLADE
BY VEHICLE	A4	8D	READ PINCODE	AZB	MAGNETI MARELLI	EURO MM4 AUDI 2	PIN READ MM4 BLADE
BY VEHICLE	A4	8D	READ PINCODE	AZB	MAGNETI MARELLI	USA MM4 AUDI A3	PIN READ USA MM4 AUDI A3 BLADE
BY VEHICLE	A4	8D	READ PINCODE	AZR	AUTO		PIN READ AUTO CLUSTER BLADE
BY VEHICLE	A4	8D	READ PINCODE	AZR	MAGNETI MARELLI	MM4	PIN READ MM4 BLADE
BY VEHICLE	A4	8D	READ PINCODE	AZR	MAGNETI MARELLI	USA MM4 VW	PIN READ MM4 VW BLADE
BY VEHICLE	A4	8D	READ PINCODE	AZR	MAGNETI MARELLI	USA MM4 AUDI	PIN READ USA MM4 AUDI BLADE
BY VEHICLE	A4	8D	READ PINCODE	AZR	MAGNETI MARELLI	EURO MM4 VW	PIN READ EUR MM4 VW BLADE
BY VEHICLE	A4	8D	READ PINCODE	AZR	MAGNETI MARELLI	EURO MM4 AUDI 1	PIN READ EUR MM4 AUDI BLADE
BY VEHICLE	A4	8D	READ PINCODE	AZR	MAGNETI MARELLI	EURO MM4 AUDI 2	PIN READ MM4 BLADE
BY VEHICLE	A4	8D	READ PINCODE	AZR	MAGNETI MARELLI	USA MM4 AUDI A3	PIN READ USA MM4 AUDI A3 BLADE
BY VEHICLE	A4	8E 8H	IMMOBILISER				IMMOBILISER KW2000 TYPE2 BLADE
BY VEHICLE	A4	8E 8H	REMOTE	TYPE 1			REMOTE KW1281 TYPE 3 BLADE
BY VEHICLE	A4	8E 8H	REMOTE	TYPE 2			REMOTE KW1281 TYPE 4 BLADE

Audi 7/12

By Vehicle list – as displayed on AD100Pro/MVPPPro

This list cross-references Pro Menu to the Smart Pro By System list

BY VEHICLE	A4	8E 8H	REMOTE	TYPE 3		REMOTE TP20 TYPE 8 BLADE
BY VEHICLE	A4	8E 8H	REMOTE	TYPE 4		REMOTE TP20 TYPE 9 BLADE
BY VEHICLE	A4	8E 8H	READ PINCODE	AKE		PIN READ EDC15 BLADE
BY VEHICLE	A4	8E 8H	READ PINCODE	ALT		PIN READ KW1281 EMS BLADE
BY VEHICLE	A4	8E 8H	READ PINCODE	AMB		PIN READ KW2000 EMS 1 BLADE
BY VEHICLE	A4	8E 8H	READ PINCODE	AML		PIN READ KW2000 EMS 1 BLADE
BY VEHICLE	A4	8E 8H	READ PINCODE	AMM		PIN READ KW2000 EMS 1 BLADE
BY VEHICLE	A4	8E 8H	READ PINCODE	ASB		PIN READ KW2000 EMS 1 BLADE
BY VEHICLE	A4	8E 8H	READ PINCODE	ASN		PIN READ KW2000 EMS 1 BLADE
BY VEHICLE	A4	8E 8H	READ PINCODE	AVB		PIN READ EDC15 BLADE
BY VEHICLE	A4	8E 8H	READ PINCODE	AVF		PIN READ EDC15 BLADE
BY VEHICLE	A4	8E 8H	READ PINCODE	AVJ		PIN READ KW2000 EMS 1 BLADE
BY VEHICLE	A4	8E 8H	READ PINCODE	AVK		PIN READ KW2000 EMS 1 BLADE
BY VEHICLE	A4	8E 8H	READ PINCODE	AWA		PIN READ MED 91 TYPE 1 BLADE
BY VEHICLE	A4	8E 8H	READ PINCODE	AWX		PIN READ EDC15 BLADE
BY VEHICLE	A4	8E 8H	READ PINCODE	AYM		PIN READ EDC15 BLADE
BY VEHICLE	A4	8E 8H	READ PINCODE	BAA		PIN READ KW2000 EMS 1 BLADE
BY VEHICLE	A4	8E 8H	READ PINCODE	BAU		PIN READ EDC15 BLADE
BY VEHICLE	A4	8E 8H	READ PINCODE	BAZ		PIN READ KW2000 EMS 1 BLADE
BY VEHICLE	A4	8E 8H	READ PINCODE	BBJ		PIN READ KW2000 EMS 1 BLADE
BY VEHICLE	A4	8E 8H	READ PINCODE	BBK		PIN READ KW2000 EMS 1 BLADE
BY VEHICLE	A4	8E 8H	READ PINCODE	BDG		PIN READ EDC15 BLADE
BY VEHICLE	A4	8E 8H	READ PINCODE	BCZ		PIN READ EDC15 BLADE
BY VEHICLE	A4	8E 8H	READ PINCODE	BDH		PIN READ EDC15 BLADE
BY VEHICLE	A4	8E 8H	READ PINCODE	BDV		PIN READ KW2000 EMS 1 BLADE
BY VEHICLE	A4	8E 8H	READ PINCODE	BEL		PIN READ KW2000 EMS 1 BLADE
BY VEHICLE	A4	8E 8H	READ PINCODE	BEX		PIN READ KW2000 EMS 1 BLADE
BY VEHICLE	A4	8E 8H	READ PINCODE	BFC		PIN READ EDC15 BLADE
BY VEHICLE	A4	8E 8H	READ PINCODE	BGN		PIN READ KW2000 EMS 1 BLADE
BY VEHICLE	A4	8E 8H	READ PINCODE	BHF		PIN READ KW2000 EMS 1 BLADE
BY VEHICLE	A4	8E 8H	READ PINCODE	BKB		PIN READ KW2000 EMS 1 BLADE
BY VEHICLE	A4	8E 8H	READ PINCODE	BKE		PIN READ EDC16U31 TYPE 2 BLADE
BY VEHICLE	A4	8E 8H	READ PINCODE	BKN		PIN READ EDC16U34 TYPE 2 BLADE
BY VEHICLE	A4	8E 8H	READ PINCODE	BLB		PIN READ MED 9510 BLADE
BY VEHICLE	A4	8E 8H	READ PINCODE	BNA		PIN READ EDC16U31 TYPE 2 BLADE
BY VEHICLE	A4	8E 8H	READ PINCODE	BNS		PIN READ MED 91 TYPE 2 BLADE
BY VEHICLE	A4	8E 8H	READ PINCODE	BPG		PIN READ MED 91 TYPE 2 BLADE
BY VEHICLE	A4	8E 8H	READ PINCODE	BPJ		PIN READ MED 91 TYPE 2 BLADE
BY VEHICLE	A4	8E 8H	READ PINCODE	BPP		PIN READ EDC16U34 TYPE 2 BLADE
BY VEHICLE	A4	8E 8H	READ PINCODE	BPW		PIN READ EDC16U31 TYPE 2 BLADE
BY VEHICLE	A4	8E 8H	READ PINCODE	BRB		PIN READ EDC16U31 TYPE 2 BLADE
BY VEHICLE	A4	8E 8H	READ PINCODE	BRC		PIN READ EDC16U31 TYPE 2 BLADE
BY VEHICLE	A4	8E 8H	READ PINCODE	BRD		PIN READ EDC16U31 TYPE 2 BLADE
BY VEHICLE	A4	8E 8H	READ PINCODE	BRE		PIN READ EDC16U31 TYPE 2 BLADE
BY VEHICLE	A4	8E 8H	READ PINCODE	BRF		PIN READ EDC16U31 TYPE 2 BLADE
BY VEHICLE	A4	8E 8H	READ PINCODE	BRG		PIN READ EDC16U31 TYPE 2 BLADE
BY VEHICLE	A4	8E 8H	READ PINCODE	BUL		PIN READ MED 91 TYPE 2 BLADE
BY VEHICLE	A4	8E 8H	READ PINCODE	BVA		PIN READ PPD 1115 BLADE
BY VEHICLE	A4	8E 8H	READ PINCODE	BVF		PIN READ EDC16U31 TYPE 2 BLADE
BY VEHICLE	A4	8E 8H	READ PINCODE	BWA		PIN READ MED 91 TYPE 2 BLADE
BY VEHICLE	A4	8E 8H	READ PINCODE	BWT		PIN READ MED 91 TYPE 2 BLADE
BY VEHICLE	A6	4A 4B	IMMOBILISER	TYPE 1		IMMOBILISER KW1281 TYPE 1 BLADE
BY VEHICLE	A6	4A 4B	IMMOBILISER	TYPE 2		IMMOBILISER KW1281 TYPE 2 BLADE
BY VEHICLE	A6	4A 4B	REMOTE	TYPE 1		REMOTE KW1281 TYPE 3 BLADE
BY VEHICLE	A6	4A 4B	REMOTE	TYPE 2		REMOTE KW1281 TYPE 4 BLADE
BY VEHICLE	A6	4A 4B	REMOTE	TYPE 3		REMOTE TP20 TYPE 8 BLADE
BY VEHICLE	A6	4A 4B	REMOTE	TYPE 4		REMOTE TP20 TYPE 9 BLADE
BY VEHICLE	A6	4A 4B	AUTO GEARBOX			SPECIAL FUNCTION AUTO GEARBOX
BY VEHICLE	A6	4A 4B	SRS AIRBAG			SPECIAL FUNCTION VAG SRS
BY VEHICLE	A6	4A 4B	READ PINCODE	AUTOCLUSTER		PIN READ AUTO CLUSTER BLADE
BY VEHICLE	A6	4A 4B	READ PINCODE	MMCLUSTER	MM4	PIN READ MM4 BLADE
BY VEHICLE	A6	4A 4B	READ PINCODE	MMCLUSTER	USA MM4 VW	PIN READ MM4 VW BLADE
BY VEHICLE	A6	4A 4B	READ PINCODE	MMCLUSTER	USA MM4 AUDI	PIN READ USA MM4 AUDI BLADE
BY VEHICLE	A6	4A 4B	READ PINCODE	MMCLUSTER	EURO MM4 VW	PIN READ EUR MM4 VW BLADE
BY VEHICLE	A6	4A 4B	READ PINCODE	MMCLUSTER	EURO MM4 AUDI 1	PIN READ EUR MM4 AUDI BLADE
BY VEHICLE	A6	4A 4B	READ PINCODE	MMCLUSTER	EURO MM4 AUDI 2	PIN READ MM4 BLADE

Audi 10/12

By Vehicle list – as displayed on AD100Pro/MVPPPro

This list cross-references Pro Menu to the Smart Pro By System list

BY VEHICLE	A6	4A 4B	READ PINCODE	AMM	AUTO		PIN READ AUTO CLUSTER BLADE
BY VEHICLE	A6	4A 4B	READ PINCODE	AMM	MAGNETI MARELLI	MM4	PIN READ MM4 BLADE
BY VEHICLE	A6	4A 4B	READ PINCODE	AMM	MAGNETI MARELLI	USA MM4 VW	PIN READ MM4 VW BLADE
BY VEHICLE	A6	4A 4B	READ PINCODE	AMM	MAGNETI MARELLI	USA MM4 AUDI	PIN READ USA MM4 AUDI BLADE
BY VEHICLE	A6	4A 4B	READ PINCODE	AMM	MAGNETI MARELLI	EURO MM4 VW	PIN READ EUR MM4 VW BLADE
BY VEHICLE	A6	4A 4B	READ PINCODE	AMM	MAGNETI MARELLI	EURO MM4 AUDI 1	PIN READ EUR MM4 AUDI BLADE
BY VEHICLE	A6	4A 4B	READ PINCODE	AMM	MAGNETI MARELLI	EURO MM4 AUDI 2	PIN READ MM4 BLADE
BY VEHICLE	A6	4A 4B	READ PINCODE	AMM	MAGNETI MARELLI	USA MM4 AUDI A3	PIN READ USA MM4 AUDI A3 BLADE
BY VEHICLE	A6	4A 4B	READ PINCODE	AMX			PIN READ KW1281 EMS BLADE
BY VEHICLE	A6	4A 4B	READ PINCODE	ANB			PIN READ KW1281 EMS BLADE
BY VEHICLE	A6	4A 4B	READ PINCODE	ANK			PIN READ KW1281 EMS BLADE
BY VEHICLE	A6	4A 4B	READ PINCODE	APB			PIN READ KW1281 EMS BLADE
BY VEHICLE	A6	4A 4B	READ PINCODE	APR			PIN READ KW1281 EMS BLADE
BY VEHICLE	A6	4A 4B	READ PINCODE	APS			PIN READ KW1281 EMS BLADE
BY VEHICLE	A6	4A 4B	READ PINCODE	APZ			PIN READ KW1281 EMS BLADE
BY VEHICLE	A6	4A 4B	READ PINCODE	APU			PIN READ KW1281 EMS BLADE
BY VEHICLE	A6	4A 4B	READ PINCODE	AQD			PIN READ KW1281 EMS BLADE
BY VEHICLE	A6	4A 4B	READ PINCODE	AQE			PIN READ KW1281 EMS BLADE
BY VEHICLE	A6	4A 4B	READ PINCODE	AQJ			PIN READ KW1281 EMS BLADE
BY VEHICLE	A6	4A 4B	READ PINCODE	ARH			PIN READ KW1281 EMS BLADE
BY VEHICLE	A6	4A 4B	READ PINCODE	ARJ			PIN READ KW1281 EMS BLADE
BY VEHICLE	A6	4A 4B	READ PINCODE	ARK			PIN READ KW1281 EMS BLADE
BY VEHICLE	A6	4A 4B	READ PINCODE	ARS			PIN READ KW1281 EMS BLADE
BY VEHICLE	A6	4A 4B	READ PINCODE	ASG			PIN READ KW1281 EMS BLADE
BY VEHICLE	A6	4A 4B	READ PINCODE	ARE			PIN READ KW1281 EMS BLADE
BY VEHICLE	A6	4A 4B	READ PINCODE	ASJ	AUTO		PIN READ AUTO CLUSTER BLADE
BY VEHICLE	A6	4A 4B	READ PINCODE	ASJ	MAGNETI MARELLI	MM4	PIN READ MM4 BLADE
BY VEHICLE	A6	4A 4B	READ PINCODE	ASJ	MAGNETI MARELLI	USA MM4 VW	PIN READ MM4 VW BLADE
BY VEHICLE	A6	4A 4B	READ PINCODE	ASJ	MAGNETI MARELLI	USA MM4 AUDI	PIN READ USA MM4 AUDI BLADE
BY VEHICLE	A6	4A 4B	READ PINCODE	ASJ	MAGNETI MARELLI	EURO MM4 VW	PIN READ EUR MM4 VW BLADE
BY VEHICLE	A6	4A 4B	READ PINCODE	ASJ	MAGNETI MARELLI	EURO MM4 AUDI 1	PIN READ EUR MM4 AUDI BLADE
BY VEHICLE	A6	4A 4B	READ PINCODE	ASJ	MAGNETI MARELLI	EURO MM4 AUDI 2	PIN READ MM4 BLADE
BY VEHICLE	A6	4A 4B	READ PINCODE	ASJ	MAGNETI MARELLI	USA MM4 AUDI A3	PIN READ USA MM4 AUDI A3 BLADE
BY VEHICLE	A6	4A 4B	READ PINCODE	ASN			PIN READ KW1281 EMS BLADE
BY VEHICLE	A6	4A 4B	READ PINCODE	ATJ			PIN READ EDC15 BLADE
BY VEHICLE	A6	4A 4B	READ PINCODE	ATQ			PIN READ KW1281 EMS BLADE
BY VEHICLE	A6	4A 4B	READ PINCODE	ATX			PIN READ KW1281 EMS BLADE
BY VEHICLE	A6	4A 4B	READ PINCODE	AVF			PIN READ EDC15 BLADE
BY VEHICLE	A6	4A 4B	READ PINCODE	AVG			PIN READ EDC15 BLADE
BY VEHICLE	A6	4A 4B	READ PINCODE	AVK			PIN READ KW1281 EMS BLADE
BY VEHICLE	A6	4A 4B	READ PINCODE	AWN			PIN READ KW1281 EMS BLADE
BY VEHICLE	A6	4A 4B	READ PINCODE	AWT			PIN READ KW1281 EMS BLADE
BY VEHICLE	A6	4A 4B	READ PINCODE	AWX			PIN READ EDC15 BLADE
BY VEHICLE	A6	4A 4B	READ PINCODE	AYM			PIN READ EDC15 BLADE
BY VEHICLE	A6	4A 4B	READ PINCODE	AZB	AUTO		PIN READ AUTO CLUSTER BLADE
BY VEHICLE	A6	4A 4B	READ PINCODE	AZB	MAGNETI MARELLI	MM4	PIN READ MM4 BLADE
BY VEHICLE	A6	4A 4B	READ PINCODE	AZB	MAGNETI MARELLI	USA MM4 VW	PIN READ MM4 VW BLADE
BY VEHICLE	A6	4A 4B	READ PINCODE	AZB	MAGNETI MARELLI	USA MM4 AUDI	PIN READ USA MM4 AUDI BLADE
BY VEHICLE	A6	4A 4B	READ PINCODE	AZB	MAGNETI MARELLI	EURO MM4 VW	PIN READ EUR MM4 VW BLADE
BY VEHICLE	A6	4A 4B	READ PINCODE	AZB	MAGNETI MARELLI	EURO MM4 AUDI 1	PIN READ EUR MM4 AUDI BLADE
BY VEHICLE	A6	4A 4B	READ PINCODE	AZB	MAGNETI MARELLI	EURO MM4 AUDI 2	PIN READ MM4 BLADE
BY VEHICLE	A6	4A 4B	READ PINCODE	AZB	MAGNETI MARELLI	USA MM4 AUDI A3	PIN READ USA MM4 AUDI A3 BLADE
BY VEHICLE	A6	4A 4B	READ PINCODE	AZR	AUTO		PIN READ AUTO CLUSTER BLADE
BY VEHICLE	A6	4A 4B	READ PINCODE	AZR	MAGNETI MARELLI	MM4	PIN READ MM4 BLADE
BY VEHICLE	A6	4A 4B	READ PINCODE	AZR	MAGNETI MARELLI	USA MM4 VW	PIN READ MM4 VW BLADE
BY VEHICLE	A6	4A 4B	READ PINCODE	AZR	MAGNETI MARELLI	USA MM4 AUDI	PIN READ USA MM4 AUDI BLADE
BY VEHICLE	A6	4A 4B	READ PINCODE	AZR	MAGNETI MARELLI	EURO MM4 VW	PIN READ EUR MM4 VW BLADE
BY VEHICLE	A6	4A 4B	READ PINCODE	AZR	MAGNETI MARELLI	EURO MM4 AUDI 1	PIN READ EUR MM4 AUDI BLADE
BY VEHICLE	A6	4A 4B	READ PINCODE	AZR	MAGNETI MARELLI	EURO MM4 AUDI 2	PIN READ MM4 BLADE
BY VEHICLE	A6	4A 4B	READ PINCODE	AZR	MAGNETI MARELLI	USA MM4 AUDI A3	PIN READ USA MM4 AUDI A3 BLADE
BY VEHICLE	A6	4A 4B	READ PINCODE	BAS			PIN READ KW2000 EMS 1 BLADE
BY VEHICLE	A6	4A 4B	READ PINCODE	BAT			PIN READ KW2000 EMS 1 BLADE
BY VEHICLE	A6	4A 4B	READ PINCODE	BAU			PIN READ EDC15 BLADE
BY VEHICLE	A6	4A 4B	READ PINCODE	BBD			PIN READ KW1281 EMS BLADE
BY VEHICLE	A6	4A 4B	READ PINCODE	BBJ			PIN READ KW1281 EMS BLADE
BY VEHICLE	A6	4A 4B	READ PINCODE	BCY			PIN READ KW1281 EMS BLADE

Audi 11/12

By Vehicle list – as displayed on AD100Pro/MVPPPro

This list cross-references Pro Menu to the Smart Pro By System list

BY VEHICLE	A6	4A 4B	READ PINCODE	BCZ			PIN READ EDC15 BLADE
BY VEHICLE	A6	4A 4B	READ PINCODE	BDG			PIN READ EDC15 BLADE
BY VEHICLE	A6	4A 4B	READ PINCODE	BDV			PIN READ KW2000 EMS 1 BLADE
BY VEHICLE	A6	4A 4B	READ PINCODE	BDH			PIN READ EDC15 BLADE
BY VEHICLE	A6	4A 4B	READ PINCODE	BEL			PIN READ KW2000 EMS 1 BLADE
BY VEHICLE	A6	4A 4B	READ PINCODE	BES			PIN READ KW1281 EMS BLADE
BY VEHICLE	A6	4A 4B	READ PINCODE	BFC			PIN READ EDC15 BLADE
BY VEHICLE	A6	4A 4B	READ PINCODE	BRV			PIN READ KW2000 EMS 1 BLADE
BY VEHICLE	A8	4D	IMMOBILISER				IMMOBILISER KW1281 TYPE 2 BLADE
BY VEHICLE	A8	4D	REMOTE	TYPE 1			REMOTE KW1281 TYPE 3 BLADE
BY VEHICLE	A8	4D	REMOTE	TYPE 2			REMOTE KW1281 TYPE 4 BLADE
BY VEHICLE	A8	4D	REMOTE	TYPE 3			REMOTE TP20 TYPE 8 BLADE
BY VEHICLE	A8	4D	REMOTE	TYPE 4			REMOTE TP20 TYPE 9 BLADE
BY VEHICLE	A8	4D	AUTO GEARBOX				SPECIAL FUNCTION AUTO GEARBOX
BY VEHICLE	A8	4D	SRS AIRBAG				SPECIAL FUNCTION VAG SRS
BY VEHICLE	A8	4D	READ PINCODE	AAH			PIN READ AUTO CLUSTER BLADE
BY VEHICLE	A8	4D	READ PINCODE	ABZ			PIN READ AUTO CLUSTER BLADE
BY VEHICLE	A8	4D	READ PINCODE	ACK			PIN READ AUTO CLUSTER BLADE
BY VEHICLE	A8	4D	READ PINCODE	ACU			PIN READ AUTO CLUSTER BLADE
BY VEHICLE	A8	4D	READ PINCODE	AEJ			PIN READ AUTO CLUSTER BLADE
BY VEHICLE	A8	4D	READ PINCODE	AEW			PIN READ AUTO CLUSTER BLADE
BY VEHICLE	A8	4D	READ PINCODE	AGE			PIN READ AUTO CLUSTER BLADE
BY VEHICLE	A8	4D	READ PINCODE	AGH			PIN READ AUTO CLUSTER BLADE
BY VEHICLE	A8	4D	READ PINCODE	AHC			PIN READ AUTO CLUSTER BLADE
BY VEHICLE	A8	4D	READ PINCODE	AKB			PIN READ KW1281 EMS BLADE
BY VEHICLE	A8	4D	READ PINCODE	AKF			PIN READ EDC15 BLADE
BY VEHICLE	A8	4D	READ PINCODE	AKG			PIN READ AUTO CLUSTER BLADE
BY VEHICLE	A8	4D	READ PINCODE	AKH			PIN READ AUTO CLUSTER BLADE
BY VEHICLE	A8	4D	READ PINCODE	AKJ			PIN READ AUTO CLUSTER BLADE
BY VEHICLE	A8	4D	READ PINCODE	AKN			PIN READ EDC15 BLADE
BY VEHICLE	A8	4D	READ PINCODE	ALG			PIN READ AUTO CLUSTER BLADE
BY VEHICLE	A8	4D	READ PINCODE	AMX			PIN READ KW1281 EMS BLADE
BY VEHICLE	A8	4D	READ PINCODE	APR			PIN READ KW1281 EMS BLADE
BY VEHICLE	A8	4D	READ PINCODE	AQD			PIN READ KW1281 EMS BLADE
BY VEHICLE	A8	4D	READ PINCODE	AQF			PIN READ KW1281 EMS BLADE
BY VEHICLE	A8	4D	READ PINCODE	AQG			PIN READ AUTO CLUSTER BLADE
BY VEHICLE	A8	4D	READ PINCODE	AQH			PIN READ KW1281 EMS BLADE
BY VEHICLE	A8	4D	READ PINCODE	ARU			PIN READ KW1281 EMS BLADE
BY VEHICLE	A8	4D	READ PINCODE	AUW			PIN READ AUTO CLUSTER BLADE
BY VEHICLE	A8	4D	READ PINCODE	AUX			PIN READ AUTO CLUSTER BLADE
BY VEHICLE	A8	4D	READ PINCODE	AVN			PIN READ AUTO CLUSTER BLADE
BY VEHICLE	A8	4D	READ PINCODE	AVP			PIN READ AUTO CLUSTER BLADE
BY VEHICLE	A8	4D	READ PINCODE	AYS			PIN READ AUTO CLUSTER BLADE
BY VEHICLE	A8	4D	READ PINCODE	AZC			PIN READ AUTO CLUSTER BLADE
BY VEHICLE	A8	4D	READ PINCODE	BCS			PIN READ KW1281 EMS BLADE
BY VEHICLE	A8	4E	IMMOBILISER				IMMOBILISER KW2000 KESSY BLADE
BY VEHICLE	A8	4E	READ PINCODE	ASB			PIN READ EDC16U34 TYPE 2 BLADE
BY VEHICLE	A8	4E	READ PINCODE	ASN			PIN READ KW2000 EMS 1 BLADE
BY VEHICLE	A8	4E	READ PINCODE	ASE			PIN READ EDC16U34 TYPE 2 BLADE
BY VEHICLE	A8	4E	READ PINCODE	AUK			PIN READ MED 91 TYPE 2 BLADE
BY VEHICLE	A8	4E	READ PINCODE	BAR			PIN READ MED 91 TYPE 2 BLADE
BY VEHICLE	A8	4E	READ PINCODE	BBJ			PIN READ KW2000 EMS 1 BLADE
BY VEHICLE	A8	4E	READ PINCODE	BDX			PIN READ MED 91 TYPE 2 BLADE
BY VEHICLE	A8	4E	READ PINCODE	BFL			PIN READ MED 91 TYPE 2 BLADE
BY VEHICLE	A8	4E	READ PINCODE	BFM			PIN READ KW2000 EMS 1 BLADE
BY VEHICLE	A8	4E	READ PINCODE	BGK			PIN READ KW2000 EMS 1 BLADE
BY VEHICLE	A8	4E	READ PINCODE	BGS			PIN READ MED 91 TYPE 2 BLADE
BY VEHICLE	A8	4E	READ PINCODE	BHT			PIN READ KW2000 EMS 1 BLADE
BY VEHICLE	A8	4E	READ PINCODE	BMC			PIN READ EDC16U34 TYPE 2 BLADE
BY VEHICLE	A8	4E	READ PINCODE	BNG			PIN READ EDC16U34 TYPE 2 BLADE
BY VEHICLE	A8	4E	READ PINCODE	BPK			PIN READ MED 91 TYPE 2 BLADE
BY VEHICLE	A8	4E	READ PINCODE	BSB			PIN READ KW2000 EMS 1 BLADE
BY VEHICLE	A8	4E	READ PINCODE	BSM			PIN READ MED 91 TYPE 2 BLADE
BY VEHICLE	A8	4E	READ PINCODE	BTE			PIN READ KW2000 EMS 1 BLADE
BY VEHICLE	A8	4E	READ PINCODE	BVJ			PIN READ MED 91 TYPE 2 BLADE
BY VEHICLE	A8	4E	READ PINCODE	BVN			PIN READ EDC16U34 TYPE 2 BLADE

Seat 1/5

By Vehicle list – as displayed on AD100Pro/MVPPPro

This list cross-references Pro Menu to the Smart Pro By System list

							SP System selection
BY VEHICLE	ALHAMBRA	7V 7M	IMMOBILISER	SYSTEM 1			IMMOBILISER KW1281 TYPE 1 BLADE
BY VEHICLE	ALHAMBRA	7V 7M	IMMOBILISER	SYSTEM 2			IMMOBILISER KW1281 TYPE 2 BLADE
BY VEHICLE	ALHAMBRA	7V 7M	SRS AIRBAG				SPECIAL FUNCTION VAG SRS
BY VEHICLE	ALHAMBRA	7V 7M	AUTO GEARBOX				SPECIAL FUNCTION AUTO GEARBOX
BY VEHICLE	ALHAMBRA	7V 7M	READ PINCODE	AFN			PIN READ EDC15 BLADE
BY VEHICLE	ALHAMBRA	7V 7M	READ PINCODE	AHU			PIN READ EDC15 BLADE
BY VEHICLE	ALHAMBRA	7V 7M	READ PINCODE	ANU			PIN READ EDC15 BLADE
BY VEHICLE	ALHAMBRA	7V 7M	READ PINCODE	ASZ			PIN READ EDC15 BLADE
BY VEHICLE	ALHAMBRA	7V 7M	READ PINCODE	ATM			PIN READ KW1281 EMS BLADE
BY VEHICLE	ALHAMBRA	7V 7M	READ PINCODE	AUE			PIN READ KW1281 EMS BLADE
BY VEHICLE	ALHAMBRA	7V 7M	READ PINCODE	AUY			PIN READ EDC15 BLADE
BY VEHICLE	ALHAMBRA	7V 7M	READ PINCODE	AWC			PIN READ KW1281 EMS BLADE
BY VEHICLE	ALHAMBRA	7V 7M	READ PINCODE	AYL			PIN READ KW1281 EMS BLADE
BY VEHICLE	ALHAMBRA	7V 7M	READ PINCODE	BRT			PIN READ EDC16U31 TYPE 2 BLADE
BY VEHICLE	ALHAMBRA	7V 7M	READ PINCODE	BTB			PIN READ EDC15 BLADE
BY VEHICLE	ALHAMBRA	7V 7M	READ PINCODE	BVH			PIN READ EDC16U31 TYPE 2 BLADE
BY VEHICLE	ALHAMBRA	7V 7M	READ PINCODE	BVK			PIN READ EDC15 BLADE
BY VEHICLE	ALTEA	5P	IMMOBILISER				IMMOBILISER TP20 TYPE 2 BLADE
BY VEHICLE	ALTEA	5P	REMOTE	TYPE 1			REMOTE TP20 TYPE 6 BLADE
BY VEHICLE	ALTEA	5P	REMOTE	TYPE 2			REMOTE TP20 TYPE 7 BLADE
BY VEHICLE	ALTEA	5P	READ PINCODE	AZV	EDC16U1		PIN READ EDC16U1 TYPE 1 BLADE
BY VEHICLE	ALTEA	5P	READ PINCODE	AZV	EDC16U31		PIN READ EDC16U31 TYPE 1 BLADE
BY VEHICLE	ALTEA	5P	READ PINCODE	BJB			PIN READ EDC16U1 TYPE 1 BLADE
BY VEHICLE	ALTEA	5P	READ PINCODE	BKC			PIN READ EDC16U1 TYPE 1 BLADE
BY VEHICLE	ALTEA	5P	READ PINCODE	BKD			PIN READ EDC16U1 TYPE 1 BLADE
BY VEHICLE	ALTEA	5P	READ PINCODE	BLR			PIN READ MED 9510 BLADE
BY VEHICLE	ALTEA	5P	READ PINCODE	BLS			PIN READ EDC16U34 TYPE 1 BLADE
BY VEHICLE	ALTEA	5P	READ PINCODE	BLY			PIN READ MED 9510 BLADE
BY VEHICLE	ALTEA	5P	READ PINCODE	BMM			PIN READ EDC16U34 TYPE 1 BLADE
BY VEHICLE	ALTEA	5P	READ PINCODE	BMN			PIN READ PPD 1115 BLADE
BY VEHICLE	ALTEA	5P	READ PINCODE	BVY			PIN READ MED 9510 BLADE
BY VEHICLE	ALTEA	5P	READ PINCODE	BVZ			PIN READ MED 9510 BLADE
BY VEHICLE	ALTEA	5P	READ PINCODE	BWA			PIN READ MED 91 TYPE 1 BLADE
BY VEHICLE	ALTEA	5P	READ PINCODE	BXE			PIN READ EDC16U34 TYPE 1 BLADE
BY VEHICLE	ALTEA	5P	READ PINCODE	BXF			PIN READ EDC16U34 TYPE 1 BLADE
BY VEHICLE	ALTEA	5P	READ PINCODE	BYT			PIN READ MED 17.5 BLADE
BY VEHICLE	ALTEA	5P	READ PINCODE	BZB			PIN READ MED 17.5 BLADE
BY VEHICLE	ALTEA	5P	READ PINCODE	CAXB			PIN READ MED 17.5 BLADE
BY VEHICLE	ALTEA	5P	READ PINCODE	CCZA			PIN READ MED 17.5 BLADE
BY VEHICLE	ALTEA	5P	READ PINCODE	CCZB			PIN READ MED 17.5 BLADE
BY VEHICLE	ALTEA	5P	READ PINCODE	CDAA			PIN READ MED 17.5 BLADE
BY VEHICLE	ALTEA	5P	READ PINCODE	CEGA			PIN READ EDC17 BLADE
BY VEHICLE	AROSA	6B 6H	IMMOBILISER				IMMOBILISER KW1281 TYPE 1 BLADE
BY VEHICLE	AROSA	6B 6H	SRS AIRBAG				SPECIAL FUNCTION VAG SRS
BY VEHICLE	AROSA	6B 6H	AUTO GEARBOX				SPECIAL FUNCTION AUTO GEARBOX
BY VEHICLE	AROSA	6B 6H	READ PINCODE	AKU			PIN READ EDC15 BLADE
BY VEHICLE	AROSA	6B 6H	READ PINCODE	ALD			PIN READ KW1281 EMS BLADE
BY VEHICLE	AROSA	6B 6H	READ PINCODE	AMF			PIN READ EDC15 BLADE
BY VEHICLE	AROSA	6B 6H	READ PINCODE	ANV			PIN READ KW1281 EMS BLADE
BY VEHICLE	AROSA	6B 6H	READ PINCODE	ANW			PIN READ KW1281 EMS BLADE
BY VEHICLE	AROSA	6B 6H	READ PINCODE	AUC			PIN READ KW1281 EMS BLADE
BY VEHICLE	AROSA	6B 6H	READ PINCODE	AUD			PIN READ KW1281 EMS BLADE
BY VEHICLE	AROSA	6B 6H	READ PINCODE	AYR			PIN READ EDC15 BLADE
BY VEHICLE	CORDOBA	6K2 9Z	IMMOBILISER	TYPE 1			IMMOBILISER KW1281 TYPE 1 BLADE
BY VEHICLE	CORDOBA	6K2 9Z	IMMOBILISER	TYPE 2			IMMOBILISER KW1281 TYPE 2 BLADE
BY VEHICLE	CORDOBA	6K2 9Z	REMOTE	TYPE 1			REMOTE KW1281 TYPE 3 BLADE
BY VEHICLE	CORDOBA	6K2 9Z	REMOTE	TYPE 2			REMOTE KW1281 TYPE 4 BLADE
BY VEHICLE	CORDOBA	6K2 9Z	REMOTE	TYPE 3			REMOTE TP20 TYPE 8 BLADE
BY VEHICLE	CORDOBA	6K2 9Z	REMOTE	TYPE 4			REMOTE TP20 TYPE 9 BLADE
BY VEHICLE	CORDOBA	6K2 9Z	AUTO GEARBOX				SPECIAL FUNCTION AUTO GEARBOX
BY VEHICLE	CORDOBA	6K2 9Z	SRS AIRBAG				SPECIAL FUNCTION VAG SRS
BY VEHICLE	CORDOBA	6K2 9Z	READ PINCODE	AUTOCLUSTER			PIN READ AUTO CLUSTER BLADE
BY VEHICLE	CORDOBA	6K2 9Z	READ PINCODE	AEY			PIN READ EDC15 BLADE
BY VEHICLE	CORDOBA	6K2 9Z	READ PINCODE	AFN			PIN READ EDC15 BLADE

Seat 2/5

By Vehicle list – as displayed on AD100Pro/MVPPPro

This list cross-references Pro Menu to the Smart Pro By System list

BY VEHICLE	CORDOBA	6K2 9Z	READ PINCODE	AGP			PIN READ EDC15 BLADE
BY VEHICLE	CORDOBA	6K2 9Z	READ PINCODE	AGR			PIN READ EDC15 BLADE
BY VEHICLE	CORDOBA	6K2 9Z	READ PINCODE	AHU			PIN READ EDC15 BLADE
BY VEHICLE	CORDOBA	6K2 9Z	READ PINCODE	AKK			PIN READ KW1281 EMS BLADE
BY VEHICLE	CORDOBA	6K2 9Z	READ PINCODE	ALD			PIN READ KW1281 EMS BLADE
BY VEHICLE	CORDOBA	6K2 9Z	READ PINCODE	ALH			PIN READ EDC15 BLADE
BY VEHICLE	CORDOBA	6K2 9Z	READ PINCODE	ANW			PIN READ KW1281 EMS BLADE
BY VEHICLE	CORDOBA	6K2 9Z	READ PINCODE	AQM			PIN READ EDC15 BLADE
BY VEHICLE	CORDOBA	6K2 9Z	READ PINCODE	AQX			PIN READ KW1281 EMS BLADE
BY VEHICLE	CORDOBA	6K2 9Z	READ PINCODE	ASV			PIN READ EDC15 BLADE
BY VEHICLE	CORDOBA	6K2 9Z	READ PINCODE	AUC			PIN READ KW1281 EMS BLADE
BY VEHICLE	CORDOBA	6K2 9Z	READ PINCODE	AUD			PIN READ KW1281 EMS BLADE
BY VEHICLE	CORDOBA	6K2 9Z	READ PINCODE	AVZ			PIN READ KW1281 EMS BLADE
BY VEHICLE	CORDOBA	6K2 9Z	READ PINCODE	AYP			PIN READ KW1281 EMS BLADE
BY VEHICLE	CORDOBA	6L2	IMMOBILISER	TYPE 1			IMMOBILISER KW1281 TYPE 1 BLADE
BY VEHICLE	CORDOBA	6L2	IMMOBILISER	TYPE 2			IMMOBILISER KW1281 TYPE 2 BLADE
BY VEHICLE	CORDOBA	6L2	REMOTE	TYPE 1			REMOTE KW1281 TYPE 3 BLADE
BY VEHICLE	CORDOBA	6L2	REMOTE	TYPE 2			REMOTE KW1281 TYPE 4 BLADE
BY VEHICLE	CORDOBA	6L2	REMOTE	TYPE 3			REMOTE TP20 TYPE 8 BLADE
BY VEHICLE	CORDOBA	6L2	REMOTE	TYPE 4			REMOTE TP20 TYPE 9 BLADE
BY VEHICLE	CORDOBA	6L2	READ PINCODE	AMF			PIN READ EDC15 BLADE
BY VEHICLE	CORDOBA	6L2	READ PINCODE	AMY			PIN READ AUTO CLUSTER BLADE
BY VEHICLE	CORDOBA	6L2	READ PINCODE	ASZ			PIN READ EDC15 BLADE
BY VEHICLE	CORDOBA	6L2	READ PINCODE	ATD			PIN READ EDC15 BLADE
BY VEHICLE	CORDOBA	6L2	READ PINCODE	AXR			PIN READ AUTO CLUSTER BLADE
BY VEHICLE	CORDOBA	6L2	READ PINCODE	AZL			PIN READ KW1281 EMS BLADE
BY VEHICLE	CORDOBA	6L2	READ PINCODE	AZQ			PIN READ AUTO CLUSTER BLADE
BY VEHICLE	CORDOBA	6L2	READ PINCODE	BAH			PIN READ KW1281 EMS BLADE
BY VEHICLE	CORDOBA	6L2	READ PINCODE	BBX			PIN READ KW1281 EMS BLADE
BY VEHICLE	CORDOBA	6L2	READ PINCODE	BBY			PIN READ AUTO CLUSTER BLADE
BY VEHICLE	CORDOBA	6L2	READ PINCODE	BBZ			PIN READ AUTO CLUSTER BLADE
BY VEHICLE	CORDOBA	6L2	READ PINCODE	BKY			PIN READ AUTO CLUSTER BLADE
BY VEHICLE	CORDOBA	6L2	READ PINCODE	BLT			PIN READ EDC15 BLADE
BY VEHICLE	CORDOBA	6L2	READ PINCODE	BME			PIN READ AUTO CLUSTER BLADE
BY VEHICLE	CORDOBA	6L2	READ PINCODE	BMT			PIN READ EDC17 BLADE
BY VEHICLE	CORDOBA	6L2	READ PINCODE	BMV			PIN READ AUTO CLUSTER BLADE
BY VEHICLE	CORDOBA	6L2	READ PINCODE	BNM			PIN READ EDC15 BLADE
BY VEHICLE	CORDOBA	6L2	READ PINCODE	BNV			PIN READ EDC15 BLADE
BY VEHICLE	CORDOBA	6L2	READ PINCODE	BTS			PIN READ KW2000 EMS 1 BLADE
BY VEHICLE	CORDOBA	6L2	READ PINCODE	BUD			PIN READ AUTO CLUSTER BLADE
BY VEHICLE	CORDOBA	6L2	READ PINCODE	BXV			PIN READ AUTO CLUSTER BLADE
BY VEHICLE	CORDOBA	6L2	READ PINCODE	BXW			PIN READ AUTO CLUSTER BLADE
BY VEHICLE	CUPRA	6L	IMMOBILISER				IMMOBILISER TP20 TYPE 2 BLADE
BY VEHICLE	CUPRA	6L	REMOTE	TYPE 1			REMOTE TP20 TYPE 6 BLADE
BY VEHICLE	CUPRA	6L	REMOTE	TYPE 2			REMOTE TP20 TYPE 7 BLADE
BY VEHICLE	CUPRA	6L	READ PINCODE	BWA			PIN READ MED 91 TYPE 1 BLADE
BY VEHICLE	CUPRA	6L	READ PINCODE	BWJ			PIN READ MED 91 TYPE 1 BLADE
BY VEHICLE	IBIZA	6J	IMMOBILISER	2003-2009			IMMOBILISER TP20 TYPE 2 BLADE
BY VEHICLE	IBIZA	6J	IMMOBILISER	2009-2011			IMMOBILISER UDS VDO BLADE
BY VEHICLE	IBIZA	6J	REMOTE	TYPE 1			REMOTE TP20 TYPE 6 BLADE
BY VEHICLE	IBIZA	6J	REMOTE	TYPE 2			REMOTE TP20 TYPE 7 BLADE
BY VEHICLE	IBIZA	6J	READ PINCODE	BLS			PIN READ EDC16U34 TYPE 1 BLADE
BY VEHICLE	IBIZA	6J	READ PINCODE	BMS			PIN READ EDC17 BLADE
BY VEHICLE	IBIZA	6J	READ PINCODE	BMT			PIN READ EDC17 BLADE
BY VEHICLE	IBIZA	6J	READ PINCODE	BXJ			PIN READ EDC16U34 TYPE 1 BLADE
BY VEHICLE	IBIZA	6K1	IMMOBILISER	TYPE 1			IMMOBILISER KW1281 TYPE 1 BLADE
BY VEHICLE	IBIZA	6K1	IMMOBILISER	TYPE 2			IMMOBILISER KW1281 TYPE 2 BLADE
BY VEHICLE	IBIZA	6K1	REMOTE	TYPE 1			REMOTE KW1281 TYPE 3 BLADE
BY VEHICLE	IBIZA	6K1	REMOTE	TYPE 2			REMOTE KW1281 TYPE 4 BLADE
BY VEHICLE	IBIZA	6K1	REMOTE	TYPE 3			REMOTE TP20 TYPE 8 BLADE
BY VEHICLE	IBIZA	6K1	REMOTE	TYPE 4			REMOTE TP20 TYPE 9 BLADE
BY VEHICLE	IBIZA	6K1	AUTO GEARBOX				SPECIAL FUNCTION AUTO GEARBOX
BY VEHICLE	IBIZA	6K1	SRS AIRBAG				SPECIAL FUNCTION VAG SRS
BY VEHICLE	IBIZA	6K1	READ PINCODE	AUTOCLUSTER			PIN READ AUTO CLUSTER BLADE
BY VEHICLE	IBIZA	6K1	READ PINCODE	AEY			PIN READ EDC15 BLADE
BY VEHICLE	IBIZA	6K1	READ PINCODE	AFN			PIN READ EDC15 BLADE

Seat 3/5

By Vehicle list – as displayed on AD100Pro/MVPPro

This list cross-references Pro Menu to the Smart Pro By System list

BY VEHICLE	IBIZA	6K1	READ PINCODE	AGP			PIN READ EDC15 BLADE
BY VEHICLE	IBIZA	6K1	READ PINCODE	AGR			PIN READ EDC15 BLADE
BY VEHICLE	IBIZA	6K1	READ PINCODE	AHU			PIN READ EDC15 BLADE
BY VEHICLE	IBIZA	6K1	READ PINCODE	AKK			PIN READ KW1281 EMS BLADE
BY VEHICLE	IBIZA	6K1	READ PINCODE	ALD			PIN READ KW1281 EMS BLADE
BY VEHICLE	IBIZA	6K1	READ PINCODE	ALH			PIN READ EDC15 BLADE
BY VEHICLE	IBIZA	6K1	READ PINCODE	ANW			PIN READ KW1281 EMS BLADE
BY VEHICLE	IBIZA	6K1	READ PINCODE	AQM			PIN READ EDC15 BLADE
BY VEHICLE	IBIZA	6K1	READ PINCODE	AQX			PIN READ KW1281 EMS BLADE
BY VEHICLE	IBIZA	6K1	READ PINCODE	ASV			PIN READ EDC15 BLADE
BY VEHICLE	IBIZA	6K1	READ PINCODE	AUC			PIN READ KW1281 EMS BLADE
BY VEHICLE	IBIZA	6K1	READ PINCODE	AUD			PIN READ KW1281 EMS BLADE
BY VEHICLE	IBIZA	6K1	READ PINCODE	AVZ			PIN READ KW1281 EMS BLADE
BY VEHICLE	IBIZA	6K1	READ PINCODE	AYP			PIN READ KW1281 EMS BLADE
BY VEHICLE	IBIZA	6K1	READ PINCODE	CAVF			PIN READ MED 17.5 BLADE
BY VEHICLE	IBIZA	6L1	IMMOBILISER	TYPE 1			IMMOBILISER KW1281 TYPE 1 BLADE
BY VEHICLE	IBIZA	6L1	IMMOBILISER	TYPE 2			IMMOBILISER KW1281 TYPE 2 BLADE
BY VEHICLE	IBIZA	6L1	REMOTE	TYPE 1			REMOTE KW1281 TYPE 3 BLADE
BY VEHICLE	IBIZA	6L1	REMOTE	TYPE 2			REMOTE KW1281 TYPE 4 BLADE
BY VEHICLE	IBIZA	6L1	REMOTE	TYPE 3			REMOTE TP20 TYPE 8 BLADE
BY VEHICLE	IBIZA	6L1	REMOTE	TYPE 4			REMOTE TP20 TYPE 9 BLADE
BY VEHICLE	IBIZA	6L1	AUTO GEARBOX				SPECIAL FUNCTION AUTO GEARBOX
BY VEHICLE	IBIZA	6L1	SRS AIRBAG				SPECIAL FUNCTION VAG SRS
BY VEHICLE	IBIZA	6L1	READ PINCODE	AUTOCLUSTER			PIN READ AUTO CLUSTER BLADE
BY VEHICLE	IBIZA	6L1	READ PINCODE	AMF			PIN READ EDC15 BLADE
BY VEHICLE	IBIZA	6L1	READ PINCODE	ARL			PIN READ EDC15 BLADE
BY VEHICLE	IBIZA	6L1	READ PINCODE	ASZ			PIN READ EDC15 BLADE
BY VEHICLE	IBIZA	6L1	READ PINCODE	ATD			PIN READ EDC15 BLADE
BY VEHICLE	IBIZA	6L1	READ PINCODE	AUB			PIN READ AUTO CLUSTER BLADE
BY VEHICLE	IBIZA	6L1	READ PINCODE	AXR			PIN READ EDC15 BLADE
BY VEHICLE	IBIZA	6L1	READ PINCODE	AZL			PIN READ KW1281 EMS BLADE
BY VEHICLE	IBIZA	6L1	READ PINCODE	AZQ			PIN READ AUTO CLUSTER BLADE
BY VEHICLE	IBIZA	6L1	READ PINCODE	BAH			PIN READ KW1281 EMS BLADE
BY VEHICLE	IBIZA	6L1	READ PINCODE	BBM			PIN READ AUTO CLUSTER BLADE
BY VEHICLE	IBIZA	6L1	READ PINCODE	BBU			PIN READ KW1281 EMS BLADE
BY VEHICLE	IBIZA	6L1	READ PINCODE	BBX			PIN READ KW1281 EMS BLADE
BY VEHICLE	IBIZA	6L1	READ PINCODE	BBY			PIN READ KW1281 EMS BLADE
BY VEHICLE	IBIZA	6L1	READ PINCODE	BBZ			PIN READ KW1281 EMS BLADE
BY VEHICLE	IBIZA	6L1	READ PINCODE	BJX			PIN READ KW1281 EMS BLADE
BY VEHICLE	IBIZA	6L1	READ PINCODE	BKV			PIN READ KW1281 EMS BLADE
BY VEHICLE	IBIZA	6L1	READ PINCODE	BKY			PIN READ KW1281 EMS BLADE
BY VEHICLE	IBIZA	6L1	READ PINCODE	BLZ			PIN READ KW1281 EMS BLADE
BY VEHICLE	IBIZA	6L1	READ PINCODE	BNM			PIN READ EDC15 BLADE
BY VEHICLE	IBIZA	6L1	READ PINCODE	BME			PIN READ AUTO CLUSTER BLADE
BY VEHICLE	IBIZA	6L1	READ PINCODE	BMS			PIN READ EDC17 BLADE
BY VEHICLE	IBIZA	6L1	READ PINCODE	BMT			PIN READ EDC17 BLADE
BY VEHICLE	IBIZA	6L1	READ PINCODE	BNV			PIN READ EDC15 BLADE
BY VEHICLE	IBIZA	6L1	READ PINCODE	BLT			PIN READ EDC15 BLADE
BY VEHICLE	IBIZA	6L1	READ PINCODE	BPX			PIN READ EDC15 BLADE
BY VEHICLE	IBIZA	6L1	READ PINCODE	BTS			PIN READ KW2000 EMS 1 BLADE
BY VEHICLE	IBIZA	6L1	READ PINCODE	BUD			PIN READ AUTO CLUSTER BLADE
BY VEHICLE	IBIZA	6L1	READ PINCODE	BUK			PIN READ EDC15 BLADE
BY VEHICLE	IBIZA	6L1	READ PINCODE	BXV			PIN READ AUTO CLUSTER BLADE
BY VEHICLE	IBIZA	6L1	READ PINCODE	BXW			PIN READ AUTO CLUSTER BLADE
BY VEHICLE	IBIZA	6L1	READ PINCODE	CAVE			PIN READ EDC17 BLADE
BY VEHICLE	IBIZA	6K9	IMMOBILISER				IMMOBILISER KW1281 TYPE 1 BLADE
BY VEHICLE	IBIZA	6K9	SRS AIRBAG				SPECIAL FUNCTION VAG SRS
BY VEHICLE	IBIZA	6K9	AUTO GEARBOX				SPECIAL FUNCTION AUTO GEARBOX
BY VEHICLE	IBIZA	6K9	READ PINCODE	1Y			PIN READ EDC15 BLADE
BY VEHICLE	IBIZA	6K9	READ PINCODE	AEY			PIN READ EDC15 BLADE
BY VEHICLE	IBIZA	6K9	READ PINCODE	AHB			PIN READ EDC15 BLADE
BY VEHICLE	IBIZA	6K9	READ PINCODE	AKK			PIN READ KW1281 EMS BLADE
BY VEHICLE	IBIZA	6K9	READ PINCODE	AQM			PIN READ EDC15 BLADE
BY VEHICLE	IBIZA	6K9	READ PINCODE	AUD			PIN READ KW1281 EMS BLADE
BY VEHICLE	IBIZA	6K9	READ PINCODE	AYQ			PIN READ EDC15 BLADE
BY VEHICLE	LEON	1M1	IMMOBILISER	TYPE 1			IMMOBILISER KW1281 TYPE 1 BLADE

Seat 4/5

By Vehicle list – as displayed on AD100Pro/MVPPPro

This list cross-references Pro Menu to the Smart Pro By System list

BY VEHICLE	LEON	1M1	IMMOBILISER	TYPE 2		IMMOBILISER KW1281 TYPE 2 BLADE
BY VEHICLE	LEON	1M1	REMOTE	TYPE 1		REMOTE KW1281 TYPE 3 BLADE
BY VEHICLE	LEON	1M1	REMOTE	TYPE 2		REMOTE KW1281 TYPE 4 BLADE
BY VEHICLE	LEON	1M1	REMOTE	TYPE 3		REMOTE TP20 TYPE 8 BLADE
BY VEHICLE	LEON	1M1	REMOTE	TYPE 4		REMOTE TP20 TYPE 9 BLADE
BY VEHICLE	LEON	1M1	READ PINCODE	AUTOCLUSTER		PIN READ AUTO CLUSTER BLADE
BY VEHICLE	LEON	1M1	READ PINCODE	MMCLUSTER	MM4	PIN READ MM4 BLADE
BY VEHICLE	LEON	1M1	READ PINCODE	MMCLUSTER	USA MM4 VW	PIN READ MM4 VW BLADE
BY VEHICLE	LEON	1M1	READ PINCODE	MMCLUSTER	USA MM4 AUDI	PIN READ USA MM4 AUDI BLADE
BY VEHICLE	LEON	1M1	READ PINCODE	MMCLUSTER	EURO MM4 VW	PIN READ EUR MM4 VW BLADE
BY VEHICLE	LEON	1M1	READ PINCODE	MMCLUSTER	EURO MM4 AUDI 1	PIN READ EUR MM4 AUDI BLADE
BY VEHICLE	LEON	1M1	READ PINCODE	MMCLUSTER	EURO MM4 AUDI 2	PIN READ MM4 BLADE
BY VEHICLE	LEON	1M1	READ PINCODE	MMCLUSTER	USA MM4 AUDI A3	PIN READ USA MM4 AUDI A3 BLADE
BY VEHICLE	LEON	1M1	READ PINCODE	AEH	AUTO	PIN READ AUTO CLUSTER BLADE
BY VEHICLE	LEON	1M1	READ PINCODE	AEH	MAGNETI MARELLI	
BY VEHICLE	LEON	1M1	READ PINCODE	AEH	MAGNETI MARELLI	MM4 PIN READ MM4 BLADE
BY VEHICLE	LEON	1M1	READ PINCODE	AEH	MAGNETI MARELLI	USA MM4 VW PIN READ MM4 VW BLADE
BY VEHICLE	LEON	1M1	READ PINCODE	AEH	MAGNETI MARELLI	USA MM4 AUDI PIN READ USA MM4 AUDI BLADE
BY VEHICLE	LEON	1M1	READ PINCODE	AEH	MAGNETI MARELLI	EURO MM4 VW PIN READ EUR MM4 VW BLADE
BY VEHICLE	LEON	1M1	READ PINCODE	AEH	MAGNETI MARELLI	EURO MM4 AUDI 1 PIN READ EUR MM4 AUDI BLADE
BY VEHICLE	LEON	1M1	READ PINCODE	AEH	MAGNETI MARELLI	EURO MM4 AUDI 2 PIN READ MM4 BLADE
BY VEHICLE	LEON	1M1	READ PINCODE	AEH	MAGNETI MARELLI	USA MM4 AUDI A3 PIN READ USA MM4 AUDI A3 BLADE
BY VEHICLE	LEON	1M1	READ PINCODE	AGN		PIN READ AUTO CLUSTER BLADE
BY VEHICLE	LEON	1M1	READ PINCODE	AGR		PIN READ EDC15 BLADE
BY VEHICLE	LEON	1M1	READ PINCODE	AHF		PIN READ EDC15 BLADE
BY VEHICLE	LEON	1M1	READ PINCODE	AHL		PIN READ EDC15 BLADE
BY VEHICLE	LEON	1M1	READ PINCODE	AHW		PIN READ AUTO CLUSTER BLADE
BY VEHICLE	LEON	1M1	READ PINCODE	AJQ		PIN READ KW1281 EMS BLADE
BY VEHICLE	LEON	1M1	READ PINCODE	AKL		PIN READ AUTO CLUSTER BLADE
BY VEHICLE	LEON	1M1	READ PINCODE	ALH		PIN READ EDC15 BLADE
BY VEHICLE	LEON	1M1	READ PINCODE	AMK		PIN READ KW1281 EMS BLADE
BY VEHICLE	LEON	1M1	READ PINCODE	APE		PIN READ KW1281 EMS BLADE
BY VEHICLE	LEON	1M1	READ PINCODE	APG		PIN READ KW1281 EMS BLADE
BY VEHICLE	LEON	1M1	READ PINCODE	APP		PIN READ KW1281 EMS BLADE
BY VEHICLE	LEON	1M1	READ PINCODE	AQM		PIN READ EDC15 BLADE
BY VEHICLE	LEON	1M1	READ PINCODE	ARL		PIN READ EDC15 BLADE
BY VEHICLE	LEON	1M1	READ PINCODE	ARY		PIN READ KW1281 EMS BLADE
BY VEHICLE	LEON	1M1	READ PINCODE	ASZ		PIN READ EDC15 BLADE
BY VEHICLE	LEON	1M1	READ PINCODE	ASV		PIN READ EDC15 BLADE
BY VEHICLE	LEON	1M1	READ PINCODE	AUE		PIN READ KW1281 EMS BLADE
BY VEHICLE	LEON	1M1	READ PINCODE	AUQ		PIN READ KW1281 EMS BLADE
BY VEHICLE	LEON	1M1	READ PINCODE	AUS		PIN READ AUTO CLUSTER BLADE
BY VEHICLE	LEON	1M1	READ PINCODE	AXP		PIN READ KW1281 EMS BLADE
BY VEHICLE	LEON	1M1	READ PINCODE	AXR		PIN READ EDC15 BLADE
BY VEHICLE	LEON	1M1	READ PINCODE	AZD		PIN READ AUTO CLUSTER BLADE
BY VEHICLE	LEON	1M1	READ PINCODE	BAM		PIN READ KW1281 EMS BLADE
BY VEHICLE	LEON	1M1	READ PINCODE	BCA		PIN READ KW1281 EMS BLADE
BY VEHICLE	LEON	1M1	READ PINCODE	BCB		PIN READ AUTO CLUSTER BLADE
BY VEHICLE	LEON	1M1	READ PINCODE	BDE		PIN READ KW1281 EMS BLADE
BY VEHICLE	LEON	1M1	READ PINCODE	BFQ		PIN READ AUTO CLUSTER BLADE
BY VEHICLE	LEON	1P1	IMMOBILISER	2003-2009		IMMOBILISER TP20 TYPE 2 BLADE
BY VEHICLE	LEON	1P1	IMMOBILISER	2009-2011		IMMOBILISER UDS VDO BLADE
BY VEHICLE	LEON	1P1	REMOTE	TYPE 1		REMOTE TP20 TYPE 6 BLADE
BY VEHICLE	LEON	1P1	REMOTE	TYPE 2		REMOTE TP20 TYPE 7 BLADE
BY VEHICLE	LEON	1P1	READ PINCODE	AZV	EDC16U1	PIN READ EDC16U1 TYPE 1 BLADE
BY VEHICLE	LEON	1P1	READ PINCODE	AZV	EDC16U31	PIN READ EDC16U31 TYPE 1 BLADE
BY VEHICLE	LEON	1P1	READ PINCODE	BKC		PIN READ EDC16U1 TYPE 1 BLADE
BY VEHICLE	LEON	1P1	READ PINCODE	BKD		PIN READ EDC16U34 TYPE 1 BLADE
BY VEHICLE	LEON	1P1	READ PINCODE	BLR		PIN READ MED 9510 BLADE
BY VEHICLE	LEON	1P1	READ PINCODE	BLS		PIN READ EDC16U34 TYPE 1 BLADE
BY VEHICLE	LEON	1P1	READ PINCODE	BMM		PIN READ EDC16U34 TYPE 1 BLADE
BY VEHICLE	LEON	1P1	READ PINCODE	BMN		PIN READ PPD 1115 BLADE
BY VEHICLE	LEON	1P1	READ PINCODE	BVY		PIN READ MED 9510 BLADE
BY VEHICLE	LEON	1P1	READ PINCODE	BVZ		PIN READ MED 9510 BLADE
BY VEHICLE	LEON	1P1	READ PINCODE	BWA		PIN READ MED 91 TYPE 1 BLADE
BY VEHICLE	LEON	1P1	READ PINCODE	BWJ		PIN READ MED 91 TYPE 1 BLADE

Seat 5/5

By Vehicle list – as displayed on AD100Pro/MVPPro

This list cross-references Pro Menu to the Smart Pro By System list

BY VEHICLE	LEON	1P1	READ PINCODE	BXE			PIN READ EDC16U31 TYPE 1 BLADE
BY VEHICLE	LEON	1P1	READ PINCODE	BXF			PIN READ EDC16U34 TYPE 1 BLADE
BY VEHICLE	LEON	1P1	READ PINCODE	BYT			PIN READ MED 17.5 BLADE
BY VEHICLE	LEON	1P1	READ PINCODE	BZB			PIN READ MED 17.5 BLADE
BY VEHICLE	LEON	1P1	READ PINCODE	CDLA			PIN READ MED 91 TYPE 1 BLADE
BY VEHICLE	LEON	1P1	READ PINCODE	CDLD			PIN READ MED 91 TYPE 1 BLADE
BY VEHICLE	LEON	1P1	READ PINCODE	CAXC			PIN READ MED 17.5 BLADE
BY VEHICLE	LEON	1P1	READ PINCODE	CCZA			PIN READ MED 17.5 BLADE
BY VEHICLE	LEON	1P1	READ PINCODE	CCZB			PIN READ MED 17.5 BLADE
BY VEHICLE	LEON	1P1	READ PINCODE	CDA A			PIN READ MED 17.5 BLADE
BY VEHICLE	LEON	1P1	READ PINCODE	CEGA			PIN READ EDC17 BLADE
BY VEHICLE	MII	IMMOBILISER					IMMOBILISER UDS MARELLI BLADE
BY VEHICLE	TOLEDO	1M2	IMMOBILISER	TYPE 1			IMMOBILISER KW1281 TYPE 1 BLADE
BY VEHICLE	TOLEDO	1M2	IMMOBILISER	TYPE 2			IMMOBILISER KW1281 TYPE 2 BLADE
BY VEHICLE	TOLEDO	1M2	REMOTE	TYPE 1			REMOTE KW1281 TYPE 3 BLADE
BY VEHICLE	TOLEDO	1M2	REMOTE	TYPE 2			REMOTE KW1281 TYPE 4 BLADE
BY VEHICLE	TOLEDO	1M2	REMOTE	TYPE 3			REMOTE TP20 TYPE 8 BLADE
BY VEHICLE	TOLEDO	1M2	REMOTE	TYPE 4			REMOTE TP20 TYPE 9 BLADE
BY VEHICLE	TOLEDO	1M2	READ PINCODE	AUTOCUSTER			PIN READ AUTO CLUSTER BLADE
BY VEHICLE	TOLEDO	1M2	READ PINCODE	AEH	AUTO		PIN READ AUTO CLUSTER BLADE
BY VEHICLE	TOLEDO	1M2	READ PINCODE	AGN			PIN READ AUTO CLUSTER BLADE
BY VEHICLE	TOLEDO	1M2	READ PINCODE	AGR			PIN READ EDC15 BLADE
BY VEHICLE	TOLEDO	1M2	READ PINCODE	AGZ			PIN READ AUTO CLUSTER BLADE
BY VEHICLE	TOLEDO	1M2	READ PINCODE	AHF			PIN READ EDC15 BLADE
BY VEHICLE	TOLEDO	1M2	READ PINCODE	AHM			PIN READ EDC15 BLADE
BY VEHICLE	TOLEDO	1M2	READ PINCODE	AKL			PIN READ AUTO CLUSTER BLADE
BY VEHICLE	TOLEDO	1M2	READ PINCODE	ALH			PIN READ EDC15 BLADE
BY VEHICLE	TOLEDO	1M2	READ PINCODE	APG			PIN READ KW1281 EMS BLADE
BY VEHICLE	TOLEDO	1M2	READ PINCODE	AQN			PIN READ KW1281 EMS BLADE
BY VEHICLE	TOLEDO	1M2	READ PINCODE	ARL			PIN READ EDC15 BLADE
BY VEHICLE	TOLEDO	1M2	READ PINCODE	ASV			PIN READ EDC15 BLADE
BY VEHICLE	TOLEDO	1M2	READ PINCODE	ASZ			PIN READ EDC15 BLADE
BY VEHICLE	TOLEDO	1M2	READ PINCODE	AUQ			PIN READ KW1281 EMS BLADE
BY VEHICLE	TOLEDO	1M2	READ PINCODE	AUS			PIN READ AUTO CLUSTER BLADE
BY VEHICLE	TOLEDO	1M2	READ PINCODE	AXP			PIN READ KW1281 EMS BLADE
BY VEHICLE	TOLEDO	1M2	READ PINCODE	AZD			PIN READ AUTO CLUSTER BLADE
BY VEHICLE	TOLEDO	1M2	READ PINCODE	BCB			PIN READ AUTO CLUSTER BLADE
BY VEHICLE	TOLEDO	5P2	IMMOBILISER				IMMOBILISER TP20 TYPE 2 BLADE
BY VEHICLE	TOLEDO	5P2	REMOTE	TYPE 1			REMOTE TP20 TYPE 6 BLADE
BY VEHICLE	TOLEDO	5P2	REMOTE	TYPE 2			REMOTE TP20 TYPE 7 BLADE
BY VEHICLE	TOLEDO	5P2	READ PINCODE	AZV	EDC16U1		PIN READ EDC16U1 TYPE 1 BLADE
BY VEHICLE	TOLEDO	5P2	READ PINCODE	AZV	EDC16U31		PIN READ EDC16U31 TYPE 1 BLADE
BY VEHICLE	TOLEDO	5P2	READ PINCODE	BJB			PIN READ EDC16U34 TYPE 1 BLADE
BY VEHICLE	TOLEDO	5P2	READ PINCODE	BKC			PIN READ EDC16U1 TYPE 1 BLADE
BY VEHICLE	TOLEDO	5P2	READ PINCODE	BKD			PIN READ EDC16U34 TYPE 1 BLADE
BY VEHICLE	TOLEDO	5P2	READ PINCODE	BLR			PIN READ MED 9510 BLADE
BY VEHICLE	TOLEDO	5P2	READ PINCODE	BLS			PIN READ EDC16U34 TYPE 1 BLADE
BY VEHICLE	TOLEDO	5P2	READ PINCODE	BLY			PIN READ MED 9510 BLADE
BY VEHICLE	TOLEDO	5P2	READ PINCODE	BMM			PIN READ EDC16U34 TYPE 1 BLADE
BY VEHICLE	TOLEDO	5P2	READ PINCODE	BMN			PIN READ PPD 1115 BLADE
BY VEHICLE	TOLEDO	5P2	READ PINCODE	BVY			PIN READ MED 9510 BLADE
BY VEHICLE	TOLEDO	5P2	READ PINCODE	BVZ			PIN READ MED 9510 BLADE
BY VEHICLE	TOLEDO	5P2	READ PINCODE	BWA			PIN READ MED 91 TYPE 1 BLADE
BY VEHICLE	TOLEDO	5P2	READ PINCODE	BXE			PIN READ EDC16U31 TYPE 1 BLADE
BY VEHICLE	TOLEDO	5P2	READ PINCODE	BZB			PIN READ MED 17.5 BLADE
BY VEHICLE	TOLEDO	5P2	READ PINCODE	CAXB			PIN READ MED 17.5 BLADE
BY VEHICLE	TOLEDO	5P2	READ PINCODE	CCZB			PIN READ MED 17.5 BLADE
BY VEHICLE	TOLEDO	5P2	READ PINCODE	CDA A			PIN READ MED 17.5 BLADE
BY VEHICLE	TOLEDO	5P2	READ PINCODE	CEGA			PIN READ EDC17 BLADE

Skoda 1/3

By Vehicle list – as displayed on AD100Pro/MVPPPro

This list cross-references Pro Menu to the Smart Pro By System list

BY VEHICLE	CITYGO	IMMOBILISER				SP System selection
BY VEHICLE	FABIA	6Y	IMMOBILISER	TYPE 1		IMMOBILISER UDS MARELLI BLADE
BY VEHICLE	FABIA	6Y	IMMOBILISER	TYPE 2		IMMOBILISER KW1281 TYPE 1 BLADE
BY VEHICLE	FABIA	6Y	REMOTE	TYPE 1		IMMOBILISER KW1281 TYPE 2 BLADE
BY VEHICLE	FABIA	6Y	REMOTE	TYPE 2		REMOTE KW1281 TYPE 3 BLADE
BY VEHICLE	FABIA	6Y	REMOTE	TYPE 2		REMOTE KW1281 TYPE 4 BLADE
BY VEHICLE	FABIA	6Y	REMOTE	TYPE 3		REMOTE TP20 TYPE 8 BLADE
BY VEHICLE	FABIA	6Y	REMOTE	TYPE 4		REMOTE TP20 TYPE 9 BLADE
BY VEHICLE	FABIA	6Y	AUTO GEARBOX			SPECIAL FUNCTION AUTO GEARBOX
BY VEHICLE	FABIA	6Y	SRS AIRBAG			SPECIAL FUNCTION VAG SRS
BY VEHICLE	FABIA	6Y	READ PINCODE	AUTOCLUSTER		PIN READ AUTO CLUSTER BLADE
BY VEHICLE	FABIA	6Y	READ PINCODE	AME		PIN READ AUTO CLUSTER BLADE
BY VEHICLE	FABIA	6Y	READ PINCODE	AMF		PIN READ EDC15 BLADE
BY VEHICLE	FABIA	6Y	READ PINCODE	AQV		PIN READ AUTO CLUSTER BLADE
BY VEHICLE	FABIA	6Y	READ PINCODE	AQW		PIN READ AUTO CLUSTER BLADE
BY VEHICLE	FABIA	6Y	READ PINCODE	ARV		PIN READ AUTO CLUSTER BLADE
BY VEHICLE	FABIA	6Y	READ PINCODE	ASY		PIN READ EDC15 BLADE
BY VEHICLE	FABIA	6Y	READ PINCODE	ASZ		PIN READ EDC15 BLADE
BY VEHICLE	FABIA	6Y	READ PINCODE	ATD		PIN READ EDC15 BLADE
BY VEHICLE	FABIA	6Y	READ PINCODE	ATZ		PIN READ AUTO CLUSTER BLADE
BY VEHICLE	FABIA	6Y	READ PINCODE	AUA		PIN READ AUTO CLUSTER BLADE
BY VEHICLE	FABIA	6Y	READ PINCODE	AUB		PIN READ AUTO CLUSTER BLADE
BY VEHICLE	FABIA	6Y	READ PINCODE	AWY		PIN READ AUTO CLUSTER BLADE
BY VEHICLE	FABIA	6Y	READ PINCODE	AXR		PIN READ EDC15 BLADE
BY VEHICLE	FABIA	6Y	READ PINCODE	AZE		PIN READ AUTO CLUSTER BLADE
BY VEHICLE	FABIA	6Y	READ PINCODE	AZF		PIN READ AUTO CLUSTER BLADE
BY VEHICLE	FABIA	6Y	READ PINCODE	AZL		PIN READ KW1281 EMS BLADE
BY VEHICLE	FABIA	6Y	READ PINCODE	AZQ		PIN READ AUTO CLUSTER BLADE
BY VEHICLE	FABIA	6Y	READ PINCODE	BBY		PIN READ AUTO CLUSTER BLADE
BY VEHICLE	FABIA	6Y	READ PINCODE	BBZ		PIN READ AUTO CLUSTER BLADE
BY VEHICLE	FABIA	6Y	READ PINCODE	BKY		PIN READ AUTO CLUSTER BLADE
BY VEHICLE	FABIA	6Y	READ PINCODE	BLT		PIN READ EDC15 BLADE
BY VEHICLE	FABIA	6Y	READ PINCODE	BME		PIN READ AUTO CLUSTER BLADE
BY VEHICLE	FABIA	6Y	READ PINCODE	BNM		PIN READ EDC15 BLADE
BY VEHICLE	FABIA	6Y	READ PINCODE	BNV		PIN READ EDC15 BLADE
BY VEHICLE	FABIA	6Y	READ PINCODE	BUD		PIN READ AUTO CLUSTER BLADE
BY VEHICLE	FABIA	5J 542546	IMMOBILISER			IMMOBILISER KW1281 TYPE 1 BLADE
BY VEHICLE	FABIA	5J 542548	REMOTE	TYPE 1		REMOTE KW1281 TYPE 3 BLADE
BY VEHICLE	FABIA	5J 542549	REMOTE	TYPE 2		REMOTE KW1281 TYPE 4 BLADE
BY VEHICLE	FABIA	5J 542550	REMOTE	TYPE 3		REMOTE TP20 TYPE 8 BLADE
BY VEHICLE	FABIA	5J 542551	REMOTE	TYPE 4		REMOTE TP20 TYPE 9 BLADE
BY VEHICLE	FABIA	5J 542553	READ PINCODE	BLS		PIN READ EDC16U34 TYPE 1 BLADE
BY VEHICLE	FABIA	5J 542554	READ PINCODE	BMS		PIN READ EDC17 BLADE
BY VEHICLE	FABIA	5J 542555	READ PINCODE	BNM		PIN READ EDC15 BLADE
BY VEHICLE	FABIA	5J 542556	READ PINCODE	BNV		PIN READ EDC15 BLADE
BY VEHICLE	FABIA	5J 542557	READ PINCODE	BSW		PIN READ EDC15 BLADE
BY VEHICLE	FABIA	5J 542558	READ PINCODE	BTS		PIN READ KW2000 EMS 1 BLADE
BY VEHICLE	FABIA	5J 542559	READ PINCODE	CAVB		PIN READ MED 17.5 BLADE
BY VEHICLE	FABIA	5J 542560	READ PINCODE	CAVE		PIN READ MED 17.5 BLADE
BY VEHICLE	FELICIA	6U	IMMOBILISER			IMMOBILISER KW1281 TYPE 1 BLADE
BY VEHICLE	FELICIA	6U	REMOTE	TYPE 1		REMOTE KW1281 TYPE 3 BLADE
BY VEHICLE	FELICIA	6U	REMOTE	TYPE 2		REMOTE KW1281 TYPE 4 BLADE
BY VEHICLE	FELICIA	6U	REMOTE	TYPE 3		REMOTE TP20 TYPE 8 BLADE
BY VEHICLE	FELICIA	6U	REMOTE	TYPE 4		REMOTE TP20 TYPE 9 BLADE
BY VEHICLE	OCTAVIA	1U	IMMOBILISER			IMMOBILISER KW1281 TYPE 2 BLADE
BY VEHICLE	OCTAVIA	1U	REMOTE	TYPE 1		REMOTE KW1281 TYPE 3 BLADE
BY VEHICLE	OCTAVIA	1U	REMOTE	TYPE 2		REMOTE KW1281 TYPE 4 BLADE
BY VEHICLE	OCTAVIA	1U	REMOTE	TYPE 3		REMOTE TP20 TYPE 8 BLADE
BY VEHICLE	OCTAVIA	1U	REMOTE	TYPE 4		REMOTE TP20 TYPE 9 BLADE
BY VEHICLE	OCTAVIA	1U	AUTO GEARBOX			SPECIAL FUNCTION AUTO GEARBOX
BY VEHICLE	OCTAVIA	1U	SRS AIRBAG			SPECIAL FUNCTION VAG SRS
BY VEHICLE	OCTAVIA	1U	READ PINCODE	AUTOCLUSTER		PIN READ AUTO CLUSTER BLADE
BY VEHICLE	OCTAVIA	1U	READ PINCODE	MMCLUSTER	MM4	PIN READ MM4 BLADE
BY VEHICLE	OCTAVIA	1U	READ PINCODE	MMCLUSTER	USA MM4 VW	PIN READ MM4 VW BLADE
BY VEHICLE	OCTAVIA	1U	READ PINCODE	MMCLUSTER	USA MM4 AUDI	PIN READ USA MM4 AUDI BLADE

Skoda 2/3

By Vehicle list – as displayed on AD100Pro/MVPPPro

This list cross-references Pro Menu to the Smart Pro By System list

BY VEHICLE	OCTAVIA	1U	READ PINCODE	MMCLUSTER	EURO MM4 VW		PIN READ EUR MM4 VW BLADE
BY VEHICLE	OCTAVIA	1U	READ PINCODE	MMCLUSTER	EURO MM4 AUDI 1		PIN READ EUR MM4 AUDI BLADE
BY VEHICLE	OCTAVIA	1U	READ PINCODE	MMCLUSTER	EURO MM4 AUDI 2		PIN READ MM4 BLADE
BY VEHICLE	OCTAVIA	1U	READ PINCODE	MMCLUSTER	USA MM4 AUDI A3		PIN READ USA MM4 AUDI A3 BLADE
BY VEHICLE	OCTAVIA	1U	READ PINCODE	AEE			PIN READ AUTO CLUSTER BLADE
BY VEHICLE	OCTAVIA	1U	READ PINCODE	AEG			PIN READ AUTO CLUSTER BLADE
BY VEHICLE	OCTAVIA	1U	READ PINCODE	AEH	AUTO		PIN READ AUTO CLUSTER BLADE
BY VEHICLE	OCTAVIA	1U	READ PINCODE	AEH		MM4	PIN READ MM4 BLADE
BY VEHICLE	OCTAVIA	1U	READ PINCODE	AEH		USA MM4 VW	PIN READ MM4 VW BLADE
BY VEHICLE	OCTAVIA	1U	READ PINCODE	AEH		USA MM4 AUDI	PIN READ USA MM4 AUDI BLADE
BY VEHICLE	OCTAVIA	1U	READ PINCODE	AEH		EURO MM4 VW	PIN READ EUR MM4 VW BLADE
BY VEHICLE	OCTAVIA	1U	READ PINCODE	AEH		EURO MM4 AUDI 1	PIN READ EUR MM4 AUDI BLADE
BY VEHICLE	OCTAVIA	1U	READ PINCODE	AEH		EURO MM4 AUDI 2	PIN READ MM4 BLADE
BY VEHICLE	OCTAVIA	1U	READ PINCODE	AEH		USA MM4 AUDI A3	PIN READ USA MM4 AUDI A3 BLADE
BY VEHICLE	OCTAVIA	1U	READ PINCODE	AGN			PIN READ AUTO CLUSTER BLADE
BY VEHICLE	OCTAVIA	1U	READ PINCODE	AGP			PIN READ EDC15 BLADE
BY VEHICLE	OCTAVIA	1U	READ PINCODE	AGR			PIN READ EDC15 BLADE
BY VEHICLE	OCTAVIA	1U	READ PINCODE	AGU			PIN READ AUTO CLUSTER BLADE
BY VEHICLE	OCTAVIA	1U	READ PINCODE	AHF			PIN READ EDC15 BLADE
BY VEHICLE	OCTAVIA	1U	READ PINCODE	AKL			PIN READ AUTO CLUSTER BLADE
BY VEHICLE	OCTAVIA	1U	READ PINCODE	ALH			PIN READ EDC15 BLADE
BY VEHICLE	OCTAVIA	1U	READ PINCODE	AMD			PIN READ AUTO CLUSTER BLADE
BY VEHICLE	OCTAVIA	1U	READ PINCODE	APK			PIN READ AUTO CLUSTER BLADE
BY VEHICLE	OCTAVIA	1U	READ PINCODE	AQM			PIN READ EDC15 BLADE
BY VEHICLE	OCTAVIA	1U	READ PINCODE	AQY			PIN READ AUTO CLUSTER BLADE
BY VEHICLE	OCTAVIA	1U	READ PINCODE	ARX			PIN READ KW1281 EMS BLADE
BY VEHICLE	OCTAVIA	1U	READ PINCODE	ARZ			PIN READ KW1281 EMS BLADE
BY VEHICLE	OCTAVIA	1U	READ PINCODE	ASV			PIN READ EDC15 BLADE
BY VEHICLE	OCTAVIA	1U	READ PINCODE	ASZ			PIN READ EDC15 BLADE
BY VEHICLE	OCTAVIA	1U	READ PINCODE	ATD			PIN READ EDC15 BLADE
BY VEHICLE	OCTAVIA	1U	READ PINCODE	AUM			PIN READ KW1281 EMS BLADE
BY VEHICLE	OCTAVIA	1U	READ PINCODE	AUQ			PIN READ KW1281 EMS BLADE
BY VEHICLE	OCTAVIA	1U	READ PINCODE	AVU			PIN READ AUTO CLUSTER BLADE
BY VEHICLE	OCTAVIA	1U	READ PINCODE	AXP			PIN READ AUTO CLUSTER BLADE
BY VEHICLE	OCTAVIA	1U	READ PINCODE	AXR			PIN READ AUTO CLUSTER BLADE
BY VEHICLE	OCTAVIA	1U	READ PINCODE	AZH			PIN READ KW1281 EMS BLADE
BY VEHICLE	OCTAVIA	1U	READ PINCODE	AZI			PIN READ KW1281 EMS BLADE
BY VEHICLE	OCTAVIA	1U	READ PINCODE	AZR			PIN READ EDC15 BLADE
BY VEHICLE	OCTAVIA	1U	READ PINCODE	BCA			PIN READ KW1281 EMS BLADE
BY VEHICLE	OCTAVIA	1U	READ PINCODE	BFQ			PIN READ AUTO CLUSTER BLADE
BY VEHICLE	OCTAVIA	1Z	IMMOBILISER	2003-2009			IMMOBILISER TP20 TYPE 2 BLADE
BY VEHICLE	OCTAVIA	1Z	IMMOBILISER	2009-2011			IMMOBILISER UDS VDO BLADE
BY VEHICLE	OCTAVIA	1Z	REMOTE	TYPE 1			REMOTE TP20 TYPE 6 BLADE
BY VEHICLE	OCTAVIA	1Z	REMOTE	TYPE 2			REMOTE TP20 TYPE 7 BLADE
BY VEHICLE	OCTAVIA	1Z	READ PINCODE	AXX			PIN READ MED 91 TYPE 1 BLADE
BY VEHICLE	OCTAVIA	1Z	READ PINCODE	AZV	EDC16U1		PIN READ EDC16U1 TYPE 1 BLADE
BY VEHICLE	OCTAVIA	1Z	READ PINCODE	AZV	EDC16U34		PIN READ EDC16U34 TYPE 1 BLADE
BY VEHICLE	OCTAVIA	1Z	READ PINCODE	BAG			PIN READ MED 9510 BLADE
BY VEHICLE	OCTAVIA	1Z	READ PINCODE	BCA			PIN READ KW2000 EMS 1 BLADE
BY VEHICLE	OCTAVIA	1Z	READ PINCODE	BBB			PIN READ EDC16U1 TYPE 1 BLADE
BY VEHICLE	OCTAVIA	1Z	READ PINCODE	BKC			PIN READ EDC16U1 TYPE 1 BLADE
BY VEHICLE	OCTAVIA	1Z	READ PINCODE	BKD			PIN READ EDC16U1 TYPE 1 BLADE
BY VEHICLE	OCTAVIA	1Z	READ PINCODE	BLF			PIN READ MED 9510 BLADE
BY VEHICLE	OCTAVIA	1Z	READ PINCODE	BLR			PIN READ MED 9510 BLADE
BY VEHICLE	OCTAVIA	1Z	READ PINCODE	BLS			PIN READ EDC16U34 TYPE 1 BLADE
BY VEHICLE	OCTAVIA	1Z	READ PINCODE	BLY			PIN READ MED 9510 BLADE
BY VEHICLE	OCTAVIA	1Z	READ PINCODE	BMM			PIN READ EDC16U1 TYPE 1 BLADE
BY VEHICLE	OCTAVIA	1Z	READ PINCODE	BMN			PIN READ PPD 1115 BLADE
BY VEHICLE	OCTAVIA	1Z	READ PINCODE	BVY			PIN READ MED 9510 BLADE
BY VEHICLE	OCTAVIA	1Z	READ PINCODE	BVZ			PIN READ MED 9510 BLADE
BY VEHICLE	OCTAVIA	1Z	READ PINCODE	BWA			PIN READ MED 91 TYPE 1 BLADE
BY VEHICLE	OCTAVIA	1Z	READ PINCODE	BXE	EDC16U31		PIN READ EDC16U31 TYPE 1 BLADE
BY VEHICLE	OCTAVIA	1Z	READ PINCODE	BXE	EDC16U34		PIN READ EDC16U34 TYPE 1 BLADE
BY VEHICLE	OCTAVIA	1Z	READ PINCODE	BXB			PIN READ MED 17.5 BLADE
BY VEHICLE	OCTAVIA	1Z	READ PINCODE	CAXA			PIN READ MED 17.5 BLADE
BY VEHICLE	OCTAVIA	1Z	READ PINCODE	CCZA			PIN READ MED 17.5 BLADE

VW 1/15

By Vehicle list – as displayed on AD100Pro/MVPPro

This list cross-references Pro Menu to the Smart Pro By System list

						SP System selection	
BY VEHICLE	BEETLE	1C 1Y 9C	IMMOBILISER	TO 2011	SYSTEM 1	IMMOBILISER KW1281 TYPE 1 BLADE	
BY VEHICLE	BEETLE	1C 1Y 9C	IMMOBILISER	TO 2011	SYSTEM 2	IMMOBILISER KW1281 TYPE 2 BLADE	
BY VEHICLE	BEETLE	1C 1Y 9C	IMMOBILISER	TO 2011	SYSTEM 3	IMMOBILISER KW2000 TYPE 1 BLADE	
BY VEHICLE	BEETLE	1C 1Y 9C	IMMOBILISER	2012TO		IMMOBILISER UDS MARELLI BLADE	
BY VEHICLE	BEETLE	1C 1Y 9C	REMOTE	TYPE 1		REMOTE KW1281 TYPE 3 BLADE	
BY VEHICLE	BEETLE	1C 1Y 9C	REMOTE	TYPE 2		REMOTE KW1281 TYPE 4 BLADE	
BY VEHICLE	BEETLE	1C 1Y 9C	REMOTE	TYPE 3		REMOTE TP20 TYPE 8 BLADE	
BY VEHICLE	BEETLE	1C 1Y 9C	REMOTE	TYPE 4		REMOTE TP20 TYPE 9 BLADE	
BY VEHICLE	BEETLE	1C 1Y 9C	SRS AIRBAG			SPECIAL FUNCTION VAG SRS	
BY VEHICLE	BEETLE	1C 1Y 9C	AUTO GEARBOX			SPECIAL FUNCTION AUTO GEARBOX	
BY VEHICLE	BEETLE	1C 1Y 9C	READ PINCODE	MMCLUSTER	MM4	PIN READ MM4 BLADE	
BY VEHICLE	BEETLE	1C 1Y 9C	READ PINCODE	MMCLUSTER	USA MM4 VW	PIN READ MM4 VW BLADE	
BY VEHICLE	BEETLE	1C 1Y 9C	READ PINCODE	MMCLUSTER	USA MM4 AUDI	PIN READ USA MM4 AUDI BLADE	
BY VEHICLE	BEETLE	1C 1Y 9C	READ PINCODE	MMCLUSTER	EURO MM4 VW	PIN READ EUR MM4 VW BLADE	
BY VEHICLE	BEETLE	1C 1Y 9C	READ PINCODE	MMCLUSTER	EURO MM4 AUDI 1	PIN READ EUR MM4 AUDI BLADE	
BY VEHICLE	BEETLE	1C 1Y 9C	READ PINCODE	MMCLUSTER	EURO MM4 AUDI 2	PIN READ MM4 BLADE	
BY VEHICLE	BEETLE	1C 1Y 9C	READ PINCODE	MMCLUSTER	USA MM4 AUDI A3	PIN READ USA MM4 AUDI A3 BLADE	
BY VEHICLE	BEETLE	1C 1Y 9C	READ PINCODE	MMCLUSTER	BEETLE MM5	PIN READ BEETLE MM5 BLADE	
BY VEHICLE	BEETLE	1C 1Y 9C	READ PINCODE	MMCLUSTER	BEETLE MM5 05	TYPE 1	PIN READ BEETLE MM5 05 TYPE 1 BLADE
BY VEHICLE	BEETLE	1C 1Y 9C	READ PINCODE	MMCLUSTER	BEETLE MM5 05	TYPE 2	PIN READ BEETLE MM5 05 TYPE 2 BLADE
BY VEHICLE	BEETLE	1C 1Y 9C	READ PINCODE	MMCLUSTER	MM5		PIN READ DASH MM5 BLADE
BY VEHICLE	BEETLE	1C 1Y 9C	READ PINCODE	AEG	MM4		PIN READ MM4 BLADE
BY VEHICLE	BEETLE	1C 1Y 9C	READ PINCODE	AEG	USA MM4 VW		PIN READ MM4 VW BLADE
BY VEHICLE	BEETLE	1C 1Y 9C	READ PINCODE	AEG	USA MM4 AUDI		PIN READ USA MM4 AUDI BLADE
BY VEHICLE	BEETLE	1C 1Y 9C	READ PINCODE	AEG	EURO MM4 VW		PIN READ EUR MM4 VW BLADE
BY VEHICLE	BEETLE	1C 1Y 9C	READ PINCODE	AEG	EURO MM4 AUDI 1		PIN READ EUR MM4 AUDI BLADE
BY VEHICLE	BEETLE	1C 1Y 9C	READ PINCODE	AEG	EURO MM4 AUDI 2		PIN READ MM4 BLADE
BY VEHICLE	BEETLE	1C 1Y 9C	READ PINCODE	AEG	USA MM4 AUDI A3		PIN READ USA MM4 AUDI A3 BLADE
BY VEHICLE	BEETLE	1C 1Y 9C	READ PINCODE	AEG	BEETLE MM5		PIN READ BEETLE MM5 BLADE
BY VEHICLE	BEETLE	1C 1Y 9C	READ PINCODE	AEG	BEETLE MM5 05	TYPE 1	PIN READ BEETLE MM5 05 TYPE 1 BLADE
BY VEHICLE	BEETLE	1C 1Y 9C	READ PINCODE	AEG	BEETLE MM5 05	TYPE 2	PIN READ BEETLE MM5 05 TYPE 2 BLADE
BY VEHICLE	BEETLE	1C 1Y 9C	READ PINCODE	AEG	MM5		PIN READ DASH MM5 BLADE
BY VEHICLE	BEETLE	1C 1Y 9C	READ PINCODE	AGR			PIN READ EDC15 BLADE
BY VEHICLE	BEETLE	1C 1Y 9C	READ PINCODE	AGU	MM4		PIN READ MM4 BLADE
BY VEHICLE	BEETLE	1C 1Y 9C	READ PINCODE	AGU	USA MM4 VW		PIN READ MM4 VW BLADE
BY VEHICLE	BEETLE	1C 1Y 9C	READ PINCODE	AGU	USA MM4 AUDI		PIN READ USA MM4 AUDI BLADE
BY VEHICLE	BEETLE	1C 1Y 9C	READ PINCODE	AGU	EURO MM4 VW		PIN READ EUR MM4 VW BLADE
BY VEHICLE	BEETLE	1C 1Y 9C	READ PINCODE	AGU	EURO MM4 AUDI 1		PIN READ EUR MM4 AUDI BLADE
BY VEHICLE	BEETLE	1C 1Y 9C	READ PINCODE	AGU	EURO MM4 AUDI 2		PIN READ MM4 BLADE
BY VEHICLE	BEETLE	1C 1Y 9C	READ PINCODE	AGU	USA MM4 AUDI A3		PIN READ USA MM4 AUDI A3 BLADE
BY VEHICLE	BEETLE	1C 1Y 9C	READ PINCODE	AGU	BEETLE MM5		PIN READ BEETLE MM5 BLADE
BY VEHICLE	BEETLE	1C 1Y 9C	READ PINCODE	AGU	BEETLE MM5 05	TYPE 1	PIN READ BEETLE MM5 05 TYPE 1 BLADE
BY VEHICLE	BEETLE	1C 1Y 9C	READ PINCODE	AGU	BEETLE MM5 05	TYPE 2	PIN READ BEETLE MM5 05 TYPE 2 BLADE
BY VEHICLE	BEETLE	1C 1Y 9C	READ PINCODE	AGU	MM5		PIN READ DASH MM5 BLADE
BY VEHICLE	BEETLE	1C 1Y 9C	READ PINCODE	ALH			PIN READ EDC15 BLADE
BY VEHICLE	BEETLE	1C 1Y 9C	READ PINCODE	APH			PIN READ KW1281 EMS BLADE
BY VEHICLE	BEETLE	1C 1Y 9C	READ PINCODE	APK	MM4		PIN READ MM4 BLADE
BY VEHICLE	BEETLE	1C 1Y 9C	READ PINCODE	APK	USA MM4 VW		PIN READ MM4 VW BLADE
BY VEHICLE	BEETLE	1C 1Y 9C	READ PINCODE	APK	USA MM4 AUDI		PIN READ USA MM4 AUDI BLADE
BY VEHICLE	BEETLE	1C 1Y 9C	READ PINCODE	APK	EURO MM4 VW		PIN READ EUR MM4 VW BLADE
BY VEHICLE	BEETLE	1C 1Y 9C	READ PINCODE	APK	EURO MM4 AUDI 1		PIN READ EUR MM4 AUDI BLADE
BY VEHICLE	BEETLE	1C 1Y 9C	READ PINCODE	APK	EURO MM4 AUDI 2		PIN READ MM4 BLADE
BY VEHICLE	BEETLE	1C 1Y 9C	READ PINCODE	APK	USA MM4 AUDI A3		PIN READ USA MM4 AUDI A3 BLADE
BY VEHICLE	BEETLE	1C 1Y 9C	READ PINCODE	APK	BEETLE MM5		PIN READ BEETLE MM5 BLADE
BY VEHICLE	BEETLE	1C 1Y 9C	READ PINCODE	APK	BEETLE MM5 05	TYPE 1	PIN READ BEETLE MM5 05 TYPE 1 BLADE
BY VEHICLE	BEETLE	1C 1Y 9C	READ PINCODE	APK	BEETLE MM5 05	TYPE 2	PIN READ BEETLE MM5 05 TYPE 2 BLADE
BY VEHICLE	BEETLE	1C 1Y 9C	READ PINCODE	APK	MM5		PIN READ DASH MM5 BLADE
BY VEHICLE	BEETLE	1C 1Y 9C	READ PINCODE	APL	MM4		PIN READ MM4 BLADE
BY VEHICLE	BEETLE	1C 1Y 9C	READ PINCODE	APL	USA MM4 VW		PIN READ MM4 VW BLADE
BY VEHICLE	BEETLE	1C 1Y 9C	READ PINCODE	APL	USA MM4 AUDI		PIN READ USA MM4 AUDI BLADE
BY VEHICLE	BEETLE	1C 1Y 9C	READ PINCODE	APL	EURO MM4 VW		PIN READ EUR MM4 VW BLADE
BY VEHICLE	BEETLE	1C 1Y 9C	READ PINCODE	APL	EURO MM4 AUDI 1		PIN READ EUR MM4 AUDI BLADE
BY VEHICLE	BEETLE	1C 1Y 9C	READ PINCODE	APL	EURO MM4 AUDI 2		PIN READ MM4 BLADE
BY VEHICLE	BEETLE	1C 1Y 9C	READ PINCODE	APL	USA MM4 AUDI A3		PIN READ USA MM4 AUDI A3 BLADE

VW 3/15

By Vehicle list – as displayed on AD100Pro/MVPPPro

This list cross-references Pro Menu to the Smart Pro By System list

BY VEHICLE	BEETLE	1C 1Y 9C	READ PINCODE	BFS	MM5		PIN READ DASH MM5 BLADE
BY VEHICLE	BEETLE	1C 1Y 9C	READ PINCODE	BGD			PIN READ KW1281 EMS BLADE
BY VEHICLE	BEETLE	1C 1Y 9C	READ PINCODE	BHP			PIN READ KW1281 EMS BLADE
BY VEHICLE	BEETLE	1C 1Y 9C	READ PINCODE	BKF			PIN READ KW1281 EMS BLADE
BY VEHICLE	BEETLE	1C 1Y 9C	READ PINCODE	BNU			PIN READ KW1281 EMS BLADE
BY VEHICLE	BEETLE	1C 1Y 9C	READ PINCODE	BPR			PIN READ KW2000 EMS 1 BLADE
BY VEHICLE	BEETLE	1C 1Y 9C	READ PINCODE	BPS			PIN READ KW2000 EMS 1 BLADE
BY VEHICLE	BEETLE	1C 1Y 9C	READ PINCODE	BSW			PIN READ KW2000 EMS 1 BLADE
BY VEHICLE	BEETLE	1C 1Y 9C	READ PINCODE	CBPA	MM4		PIN READ MM4 BLADE
BY VEHICLE	BEETLE	1C 1Y 9C	READ PINCODE	CBPA	USA MM4 VW		PIN READ MM4 VW BLADE
BY VEHICLE	BEETLE	1C 1Y 9C	READ PINCODE	CBPA	USA MM4 AUDI		PIN READ USA MM4 AUDI BLADE
BY VEHICLE	BEETLE	1C 1Y 9C	READ PINCODE	CBPA	EURO MM4 VW		PIN READ EUR MM4 VW BLADE
BY VEHICLE	BEETLE	1C 1Y 9C	READ PINCODE	CBPA	EURO MM4 AUDI 1		PIN READ EUR MM4 AUDI BLADE
BY VEHICLE	BEETLE	1C 1Y 9C	READ PINCODE	CBPA	EURO MM4 AUDI 2		PIN READ MM4 BLADE
BY VEHICLE	BEETLE	1C 1Y 9C	READ PINCODE	CBPA	USA MM4 AUDI A3		PIN READ USA MM4 AUDI A3 BLADE
BY VEHICLE	BEETLE	1C 1Y 9C	READ PINCODE	CBPA	BEETLE MM5		PIN READ BEETLE MM5 BLADE
BY VEHICLE	BEETLE	1C 1Y 9C	READ PINCODE	CBPA	BEETLE MM5 05	TYPE 1	PIN READ BEETLE MM5 05 TYPE 1 BLADE
BY VEHICLE	BEETLE	1C 1Y 9C	READ PINCODE	CBPA	BEETLE MM5 05	TYPE 2	PIN READ BEETLE MM5 05 TYPE 2 BLADE
BY VEHICLE	BEETLE	1C 1Y 9C	READ PINCODE	CBPA	MM5		PIN READ DASH MM5 BLADE
BY VEHICLE	CADDY	9E 9H 9K	IMMOBILISER				IMMOBILISER KW1281 TYPE 2 BLADE
BY VEHICLE	CADDY	9E 9H 9K	REMOTE	TYPE 1			REMOTE KW1281 TYPE 3 BLADE
BY VEHICLE	CADDY	9E 9H 9K	REMOTE	TYPE 2			REMOTE KW1281 TYPE 4 BLADE
BY VEHICLE	CADDY	9E 9H 9K	REMOTE	TYPE 3			REMOTE TP20 TYPE 8 BLADE
BY VEHICLE	CADDY	9E 9H 9K	REMOTE	TYPE 4			REMOTE TP20 TYPE 9 BLADE
BY VEHICLE	CADDY	9E 9H 9K	SRS AIRBAG				SPECIAL FUNCTION VAG SRS
BY VEHICLE	CADDY	9E 9H 9K	AUTO GEARBOX				SPECIAL FUNCTION AUTO GEARBOX
BY VEHICLE	CADDY	9E 9H 9K	READ PINCODE	AUTOCLUSTER			PIN READ AUTO CLUSTER BLADE
BY VEHICLE	CADDY	9E 9H 9K	READ PINCODE	AEY			PIN READ EDC15 BLADE
BY VEHICLE	CADDY	9E 9H 9K	READ PINCODE	AFF			PIN READ EDC15 BLADE
BY VEHICLE	CADDY	9E 9H 9K	READ PINCODE	AHB			PIN READ EDC15 BLADE
BY VEHICLE	CADDY	9E 9H 9K	READ PINCODE	AHU			PIN READ EDC15 BLADE
BY VEHICLE	CADDY	9E 9H 9K	READ PINCODE	AKK			PIN READ KW1281 EMS BLADE
BY VEHICLE	CADDY	9E 9H 9K	READ PINCODE	ALE			PIN READ EDC15 BLADE
BY VEHICLE	CADDY	9E 9H 9K	READ PINCODE	ALH			PIN READ EDC15 BLADE
BY VEHICLE	CADDY	9E 9H 9K	READ PINCODE	APE			PIN READ KW1281 EMS BLADE
BY VEHICLE	CADDY	9E 9H 9K	READ PINCODE	ASZ			PIN READ EDC15 BLADE
BY VEHICLE	CADDY	9E 9H 9K	READ PINCODE	AUD			PIN READ KW1281 EMS BLADE
BY VEHICLE	CADDY	9E 9H 9K	READ PINCODE	AYQ			PIN READ EDC15 BLADE
BY VEHICLE	CADDY	2K	IMMOBILISER	2003-2009			IMMOBILISER TP20 TYPE 2 BLADE
BY VEHICLE	CADDY	2K	IMMOBILISER	2009-2011			IMMOBILISER UDS VDO BLADE
BY VEHICLE	CADDY	2K	REMOTE	TYPE 1			REMOTE TP20 TYPE 6 BLADE
BY VEHICLE	CADDY	2K	REMOTE	TYPE 2			REMOTE TP20 TYPE 7 BLADE
BY VEHICLE	CADDY	2K	READ PINCODE	BCA			PIN READ KW2000 EMS 1 BLADE
BY VEHICLE	CADDY	2K	READ PINCODE	BDJ			PIN READ EDC16U1 TYPE 1 BLADE
BY VEHICLE	CADDY	2K	READ PINCODE	BJB			PIN READ EDC16U1 TYPE 1 BLADE
BY VEHICLE	CADDY	2K	READ PINCODE	BKC			PIN READ EDC16U1 TYPE 1 BLADE
BY VEHICLE	CADDY	2K	READ PINCODE	BLS			PIN READ EDC16U34 TYPE 1 BLADE
BY VEHICLE	CADDY	2K	READ PINCODE	BMM			PIN READ EDC16U34 TYPE 1 BLADE
BY VEHICLE	CADDY	2K	READ PINCODE	BST			PIN READ EDC16U1 TYPE 1 BLADE
BY VEHICLE	CADDY	2K	READ PINCODE	BSU			PIN READ EDC16U34 TYPE 1 BLADE
BY VEHICLE	CADDY	2K	READ PINCODE	BSX			PIN READ KW2000 EMS 1 BLADE
BY VEHICLE	CALIFORNIA	7H	IMMOBILISER				IMMOBILISER KW1281 TYPE 1 BLADE
BY VEHICLE	CALIFORNIA	7H	REMOTE	TYPE 1			REMOTE KW1281 TYPE 3 BLADE
BY VEHICLE	CALIFORNIA	7H	REMOTE	TYPE 2			REMOTE KW1281 TYPE 4 BLADE
BY VEHICLE	CALIFORNIA	7H	REMOTE	TYPE 3			REMOTE TP20 TYPE 8 BLADE
BY VEHICLE	CALIFORNIA	7H	REMOTE	TYPE 4			REMOTE TP20 TYPE 9 BLADE
BY VEHICLE	CALIFORNIA	7H	READ PINCODE	AUTOCLUSTER			PIN READ AUTO CLUSTER BLADE
BY VEHICLE	CALIFORNIA	7H	READ PINCODE	AXB			PIN READ EDC16U1 TYPE 2 BLADE
BY VEHICLE	CALIFORNIA	7H	READ PINCODE	AXC			PIN READ EDC16U1 TYPE 2 BLADE
BY VEHICLE	CALIFORNIA	7H	READ PINCODE	AXD			PIN READ EDC16U1 TYPE 2 BLADE
BY VEHICLE	CALIFORNIA	7H	READ PINCODE	AXE			PIN READ EDC16U1 TYPE 2 BLADE
BY VEHICLE	CALIFORNIA	7H	READ PINCODE	BNZ			PIN READ EDC16U31 TYPE 2 BLADE
BY VEHICLE	CALIFORNIA	7H	READ PINCODE	BPC			PIN READ EDC16U31 TYPE 2 BLADE
BY VEHICLE	CALIFORNIA	7H	READ PINCODE	BRR			PIN READ EDC16U31 TYPE 2 BLADE
BY VEHICLE	CALIFORNIA	7H	READ PINCODE	BR5			PIN READ EDC16U31 TYPE 2 BLADE
BY VEHICLE	CALIFORNIA	7J	IMMOBILISER				IMMOBILISER KW1281 TYPE 1 BLADE

VW 4/15

By Vehicle list – as displayed on AD100Pro/MVPPPro

This list cross-references Pro Menu to the Smart Pro By System list

BY VEHICLE	CALIFORNIA	7J	REMOTE	TYPE 1		REMOTE KW1281 TYPE 3 BLADE
BY VEHICLE	CALIFORNIA	7J	REMOTE	TYPE 2		REMOTE KW1281 TYPE 4 BLADE
BY VEHICLE	CALIFORNIA	7J	REMOTE	TYPE 3		REMOTE TP20 TYPE 8 BLADE
BY VEHICLE	CALIFORNIA	7J	REMOTE	TYPE 4		REMOTE TP20 TYPE 9 BLADE
BY VEHICLE	CALIFORNIA	7J	READ PINCODE	AUTOCLUSTER		PIN READ AUTO CLUSTER BLADE
BY VEHICLE	CALIFORNIA	7J	READ PINCODE	AXA		PIN READ KW1281 EMS BLADE
BY VEHICLE	CALIFORNIA	7J	READ PINCODE	AXB		PIN READ KW1281 EMS BLADE
BY VEHICLE	CALIFORNIA	7J	READ PINCODE	AXC		PIN READ EDC16U31 TYPE 2 BLADE
BY VEHICLE	CALIFORNIA	7J	READ PINCODE	AXD		PIN READ EDC16U31 TYPE 2 BLADE
BY VEHICLE	CALIFORNIA	7J	READ PINCODE	AXE		PIN READ EDC16U31 TYPE 2 BLADE
BY VEHICLE	CALIFORNIA	7J	READ PINCODE	BDL		PIN READ KW1281 EMS BLADE
BY VEHICLE	CALIFORNIA	7J	READ PINCODE	BNZ		PIN READ EDC16U31 TYPE 2 BLADE
BY VEHICLE	CALIFORNIA	7J	READ PINCODE	BPC		PIN READ EDC16U31 TYPE 2 BLADE
BY VEHICLE	CALIFORNIA	7J	READ PINCODE	BRR		PIN READ EDC16U31 TYPE 2 BLADE
BY VEHICLE	CALIFORNIA	7J	READ PINCODE	BRS		PIN READ EDC16U31 TYPE 2 BLADE
BY VEHICLE	CARAVELLE	7H	IMMOBILISER	TYPE 1		IMMOBILISER KW1281 TYPE 1 BLADE
BY VEHICLE	CARAVELLE	7H	IMMOBILISER	TYPE 2		IMMOBILISER KW1281 TYPE 2 BLADE
BY VEHICLE	CARAVELLE	7H	REMOTE	TYPE 1		REMOTE KW1281 TYPE 3 BLADE
BY VEHICLE	CARAVELLE	7H	REMOTE	TYPE 2		REMOTE KW1281 TYPE 4 BLADE
BY VEHICLE	CARAVELLE	7H	REMOTE	TYPE 3		REMOTE TP20 TYPE 8 BLADE
BY VEHICLE	CARAVELLE	7H	REMOTE	TYPE 4		REMOTE TP20 TYPE 9 BLADE
BY VEHICLE	CARAVELLE	7H	READ PINCODE	AUTOCLUSTER		PIN READ AUTO CLUSTER BLADE
BY VEHICLE	CARAVELLE	7H	READ PINCODE	AXA		PIN READ KW1281 EMS BLADE
BY VEHICLE	CARAVELLE	7H	READ PINCODE	AXB		PIN READ EDC16U1 TYPE 2 BLADE
BY VEHICLE	CARAVELLE	7H	READ PINCODE	AXC		PIN READ EDC16U31 TYPE 2 BLADE
BY VEHICLE	CARAVELLE	7H	READ PINCODE	AXD		PIN READ EDC16U31 TYPE 2 BLADE
BY VEHICLE	CARAVELLE	7H	READ PINCODE	AXE		PIN READ EDC16U31 TYPE 2 BLADE
BY VEHICLE	CARAVELLE	7H	READ PINCODE	BDL		PIN READ KW1281 EMS BLADE
BY VEHICLE	CARAVELLE	7H	READ PINCODE	BKK		PIN READ KW1281 EMS BLADE
BY VEHICLE	CARAVELLE	7H	READ PINCODE	BNZ		PIN READ EDC16U31 TYPE 2 BLADE
BY VEHICLE	CARAVELLE	7H	READ PINCODE	BPC		PIN READ EDC16U31 TYPE 2 BLADE
BY VEHICLE	CARAVELLE	7H	READ PINCODE	BRR		PIN READ EDC16U31 TYPE 2 BLADE
BY VEHICLE	CARAVELLE	7H	READ PINCODE	BRS		PIN READ EDC16U31 TYPE 2 BLADE
BY VEHICLE	CARMINH	7H	IMMOBILISER			IMMOBILISER KW1281 TYPE 1 BLADE
BY VEHICLE	CARMINH	7H	REMOTE	TYPE 1		REMOTE KW1281 TYPE 3 BLADE
BY VEHICLE	CARMINH	7H	REMOTE	TYPE 2		REMOTE KW1281 TYPE 4 BLADE
BY VEHICLE	CARMINH	7H	REMOTE	TYPE 3		REMOTE TP20 TYPE 8 BLADE
BY VEHICLE	CARMINH	7H	REMOTE	TYPE 4		REMOTE TP20 TYPE 9 BLADE
BY VEHICLE	CARMINH	7H	READ PINCODE	ANJ		PIN READ EDC15 BLADE
BY VEHICLE	CRAFTER	2E 2F	IMMOBILISER			IMMOBILISER CRAFTER BLADE
BY VEHICLE	CRAFTER	2E 2F	REMOTE			REMOTE CRAFTER BLADE
BY VEHICLE	CRAFTER	2E 2F	READ PINCODE	AUTOCLUSTER		PIN READ AUTO CLUSTER BLADE
BY VEHICLE	CRAFTER	2E 2F	READ PINCODE	ANJ		PIN READ EDC15 BLADE
BY VEHICLE	CRAFTER	2E 2F	READ PINCODE	AUH		PIN READ EDC15 BLADE
BY VEHICLE	CRAFTER	2E 2F	READ PINCODE	AVR		PIN READ EDC15 BLADE
BY VEHICLE	CRAFTER	2E 2F	READ PINCODE	BAH		PIN READ KW2000 EMS 1 BLADE
BY VEHICLE	CRAFTER	2E 2F	READ PINCODE	BBE		PIN READ EDC15 BLADE
BY VEHICLE	CRAFTER	2E 2F	READ PINCODE	BBF		PIN READ EDC15 BLADE
BY VEHICLE	CRAFTER	2E 2F	READ PINCODE	BCA		PIN READ KW2000 EMS 1 BLADE
BY VEHICLE	CRAFTER	2E 2F	READ PINCODE	BJJ		PIN READ EDC16U34 TYPE 2 BLADE
BY VEHICLE	CRAFTER	2E 2F	READ PINCODE	BJK		PIN READ CRAFTER EDC BLADE
BY VEHICLE	CRAFTER	2E 2F	READ PINCODE	BJL		PIN READ CRAFTER EDC BLADE
BY VEHICLE	CRAFTER	2E 2F	READ PINCODE	BJM		PIN READ EDC16U34 TYPE 2 BLADE
BY VEHICLE	CRAFTER	2E 2F	READ PINCODE	BKC		PIN READ IMMO CAN 1 BLADE
BY VEHICLE	CRAFTER	2E 2F	READ PINCODE	BKD		PIN READ IMMO CAN 1 BLADE
BY VEHICLE	CRAFTER	2E 2F	READ PINCODE	BLF		PIN READ MED 9510 BLADE
BY VEHICLE	CRAFTER	2E 2F	READ PINCODE	BMS		PIN READ IMMO CAN 3 BLADE
BY VEHICLE	CRAFTER	2E 2F	READ PINCODE	BMT		PIN READ IMMO CAN 3 BLADE
BY VEHICLE	CRAFTER	2E 2F	READ PINCODE	BPR		PIN READ KW2000 EMS 1 BLADE
BY VEHICLE	CRAFTER	2E 2F	READ PINCODE	BPS		PIN READ KW2000 EMS 1 BLADE
BY VEHICLE	CRAFTER	2E 2F	READ PINCODE	BSF		PIN READ MED 9510 BLADE
BY VEHICLE	CRAFTER	2E 2F	READ PINCODE	BUB		PIN READ KW2000 EMS 1 BLADE
BY VEHICLE	CRAFTER	2E 2F	READ PINCODE	BVX		PIN READ MED 9510 BLADE
BY VEHICLE	CRAFTER	2E 2F	READ PINCODE	BVY		PIN READ MED 9510 BLADE
BY VEHICLE	CRAFTER	2E 2F	READ PINCODE	BWA		PIN READ MED 91 TYPE 1 BLADE
BY VEHICLE	CRAFTER	2E 2F	READ PINCODE	BXE	TYPE 1	READ PIN IMMO CAN 2 BLADE

VW 5/15

By Vehicle list – as displayed on AD100Pro/MVPPPro

This list cross-references Pro Menu to the Smart Pro By System list

BY VEHICLE	FOX	5Z		AUTO GEARBOX			SPECIAL FUNCTION AUTO GEARBOX
BY VEHICLE	FOX	5Z		READ PINCODE	AUTOCLUSTER		PIN READ AUTO CLUSTER BLADE
BY VEHICLE	FOX	5Z		READ PINCODE	AQZ		PIN READ AUTO CLUSTER BLADE
BY VEHICLE	FOX	5Z		READ PINCODE	ASY		PIN READ EDC15 BLADE
BY VEHICLE	FOX	5Z		READ PINCODE	BAH		PIN READ KW1281 EMS BLADE
BY VEHICLE	FOX	5Z		READ PINCODE	BJA		PIN READ KW1281 EMS BLADE
BY VEHICLE	FOX	5Z		READ PINCODE	BJE		PIN READ AUTO CLUSTER BLADE
BY VEHICLE	FOX	5Z		READ PINCODE	BKR		PIN READ AUTO CLUSTER BLADE
BY VEHICLE	FOX	5Z		READ PINCODE	BLH		PIN READ KW1281 EMS BLADE
BY VEHICLE	FOX	5Z		READ PINCODE	BMD		PIN READ AUTO CLUSTER BLADE
BY VEHICLE	FOX	5Z		READ PINCODE	BNM		PIN READ EDC15 BLADE
BY VEHICLE	FOX	5Z		READ PINCODE	BNX		PIN READ AUTO CLUSTER BLADE
BY VEHICLE	FOX	5Z		READ PINCODE	BPA		PIN READ KW1281 EMS BLADE
BY VEHICLE	FOX	5Z		READ PINCODE	CCNA		PIN READ AUTO CLUSTER BLADE
BY VEHICLE	FOX	5Z		READ PINCODE	CCRA		PIN READ AUTO CLUSTER BLADE
BY VEHICLE	FOX	5Z		READ PINCODE	CFZA		PIN READ AUTO CLUSTER BLADE
BY VEHICLE	FOX	5Z		READ PINCODE	CHFA		PIN READ AUTO CLUSTER BLADE
BY VEHICLE	FOX	5Z		READ PINCODE	CHFB		PIN READ AUTO CLUSTER BLADE
BY VEHICLE	GOL/FOX/SURAN	5Z		IMMOBILISER	TO2011	TYPE 1	IMMOBILISER KW1281 TYPE 1 BLADE
BY VEHICLE	GOL/FOX/SURAN	5Z		IMMOBILISER	TO2011	TYPE 2	IMMOBILISER KW2000 TYPE 1 BLADE
BY VEHICLE	GOL/FOX/SURAN	5Z		IMMOBILISER	2012TO		IMMOBILISER UDS MARELLI BLADE
BY VEHICLE	GOL/FOX/SURAN	5Z		IMMOBILISER	2012TO		IMMOBILISER KW1281 TYPE 1 BLADE
BY VEHICLE	GOL/FOX/SURAN	5Z		REMOTE	TYPE 1		REMOTE KW1281 TYPE 3 BLADE
BY VEHICLE	GOL/FOX/SURAN	5Z		REMOTE	TYPE 2		REMOTE KW1281 TYPE 4 BLADE
BY VEHICLE	GOL/FOX/SURAN	5Z		REMOTE	TYPE 3		REMOTE TP20 TYPE 8 BLADE
BY VEHICLE	GOL/FOX/SURAN	5Z		REMOTE	TYPE 4		REMOTE TP20 TYPE 9 BLADE
BY VEHICLE	GOL/FOX/SURAN	5Z		REMOTE	TYPE 5		REMOTE TP20 TYPE 4 BLADE
BY VEHICLE	GOL/FOX/SURAN	5Z		READ PINCODE	IMMOBILISER BOX		PIN READ IMMO BOX BLADE
BY VEHICLE	GOL/FOX/SURAN	5Z		READ PINCODE	CCRA		PIN READ KW2000 EMS 2 BLADE
BY VEHICLE	GOL/FOX/SURAN	5Z		READ PINCODE	CFZA		PIN READ KW2000 EMS 2 BLADE
BY VEHICLE	GOL/FOX/SURAN	5Z		AUTO GEARBOX			SPECIAL FUNCTION AUTO GEARBOX
BY VEHICLE	GOLF BORA JETTA	1H		IMMOBILISER			IMMOBILISER KW1281 TYPE 1 BLADE
BY VEHICLE	GOLF BORA JETTA	1H		SRS AIRBAG			SPECIAL FUNCTION VAG SRS
BY VEHICLE	GOLF BORA JETTA	1H		AUTO GEARBOX			SPECIAL FUNCTION AUTO GEARBOX
BY VEHICLE	GOLF BORA JETTA	1H		READ PINCODE	AEY		PIN READ EDC15 BLADE
BY VEHICLE	GOLF BORA JETTA	1H		READ PINCODE	AFF		PIN READ EDC15 BLADE
BY VEHICLE	GOLF BORA JETTA	1H		READ PINCODE	AHU		PIN READ EDC15 BLADE
BY VEHICLE	GOLF BORA JETTA	1H		READ PINCODE	ALE		PIN READ EDC15 BLADE
BY VEHICLE	GOLF BORA JETTA	1H		READ PINCODE	ALH		PIN READ EDC15 BLADE
BY VEHICLE	GOLF BORA JETTA	1J 1E		IMMOBILISER	SYSTEM 1		IMMOBILISER KW1281 TYPE 1 BLADE
BY VEHICLE	GOLF BORA JETTA	1J 1E		IMMOBILISER	SYSTEM 2		IMMOBILISER KW1281 TYPE 2 BLADE
BY VEHICLE	GOLF BORA JETTA	1J 1E		REMOTE	TYPE 1		REMOTE KW1281 TYPE 3 BLADE
BY VEHICLE	GOLF BORA JETTA	1J 1E		REMOTE	TYPE 2		REMOTE KW1281 TYPE 4 BLADE
BY VEHICLE	GOLF BORA JETTA	1J 1E		REMOTE	TYPE 3		REMOTE TP20 TYPE 8 BLADE
BY VEHICLE	GOLF BORA JETTA	1J 1E		REMOTE	TYPE 4		REMOTE TP20 TYPE 9 BLADE
BY VEHICLE	GOLF BORA JETTA	1J 1E		SRS AIRBAG			SPECIAL FUNCTION VAG SRS
BY VEHICLE	GOLF BORA JETTA	1J 1E		AUTO GEARBOX			SPECIAL FUNCTION AUTO GEARBOX
BY VEHICLE	GOLF BORA JETTA	1J 1E		READ PINCODE	AUTOCLUSTER		PIN READ AUTO CLUSTER BLADE
BY VEHICLE	GOLF BORA JETTA	1J 1E		READ PINCODE	RB8CLUSTER		PIN READ KW2000 RB4 DASH BLADE
BY VEHICLE	GOLF BORA JETTA	1J 1E		READ PINCODE	AEG		PIN READ AUTO CLUSTER BLADE
BY VEHICLE	GOLF BORA JETTA	1J 1E		READ PINCODE	AEH	AUTO	PIN READ AUTO CLUSTER BLADE
BY VEHICLE	GOLF BORA JETTA	1J 1E		READ PINCODE	AEH	MAGNETI MARELLI MM4	PIN READ MM4 BLADE
BY VEHICLE	GOLF BORA JETTA	1J 1E		READ PINCODE	AEH	MAGNETI MARELLI USA MM4 VW	PIN READ MM4 VW BLADE
BY VEHICLE	GOLF BORA JETTA	1J 1E		READ PINCODE	AEH	MAGNETI MARELLI USA MM4 AUDI	PIN READ USA MM4 AUDI BLADE
BY VEHICLE	GOLF BORA JETTA	1J 1E		READ PINCODE	AEH	MAGNETI MARELLI EURO MM4 VW	PIN READ EUR MM4 VW BLADE
BY VEHICLE	GOLF BORA JETTA	1J 1E		READ PINCODE	AEH	MAGNETI MARELLI EURO MM4 AUDI 1	PIN READ EUR MM4 AUDI BLADE
BY VEHICLE	GOLF BORA JETTA	1J 1E		READ PINCODE	AEH	MAGNETI MARELLI EURO MM4 AUDI 2	PIN READ MM4 BLADE
BY VEHICLE	GOLF BORA JETTA	1J 1E		READ PINCODE	AEH	MAGNETI MARELLI USA MM4 AUDI A3	PIN READ USA MM4 AUDI A3 BLADE
BY VEHICLE	GOLF BORA JETTA	1J 1E		READ PINCODE	AFH		PIN READ AUTO CLUSTER BLADE
BY VEHICLE	GOLF BORA JETTA	1J 1E		READ PINCODE	AFK		PIN READ AUTO CLUSTER BLADE
BY VEHICLE	GOLF BORA JETTA	1J 1E		READ PINCODE	AFN		PIN READ EDC15 BLADE
BY VEHICLE	GOLF BORA JETTA	1J 1E		READ PINCODE	AFP		PIN READ AUTO CLUSTER BLADE
BY VEHICLE	GOLF BORA JETTA	1J 1E		READ PINCODE	AGN		PIN READ AUTO CLUSTER BLADE
BY VEHICLE	GOLF BORA JETTA	1J 1E		READ PINCODE	AGP		PIN READ EDC15 BLADE
BY VEHICLE	GOLF BORA JETTA	1J 1E		READ PINCODE	AGR		PIN READ EDC15 BLADE
BY VEHICLE	GOLF BORA JETTA	1J 1E		READ PINCODE	AGU		PIN READ AUTO CLUSTER BLADE

VW 6/15

By Vehicle list – as displayed on AD100Pro/MVPPPro

This list cross-references Pro Menu to the Smart Pro By System list

BY VEHICLE	GOLF BORA JETTA	1J 1E	READ PINCODE	AGZ			PIN READ AUTO CLUSTER BLADE
BY VEHICLE	GOLF BORA JETTA	1J 1E	READ PINCODE	AHF			PIN READ EDC15 BLADE
BY VEHICLE	GOLF BORA JETTA	1J 1E	READ PINCODE	AHU			PIN READ EDC15 BLADE
BY VEHICLE	GOLF BORA JETTA	1J 1E	READ PINCODE	AHW			PIN READ AUTO CLUSTER BLADE
BY VEHICLE	GOLF BORA JETTA	1J 1E	READ PINCODE	AJM			PIN READ EDC15 BLADE
BY VEHICLE	GOLF BORA JETTA	1J 1E	READ PINCODE	AKL	AUTO		PIN READ AUTO CLUSTER BLADE
BY VEHICLE	GOLF BORA JETTA	1J 1E	READ PINCODE	AKH			PIN READ AUTO CLUSTER BLADE
BY VEHICLE	GOLF BORA JETTA	1J 1E	READ PINCODE	AKQ			PIN READ AUTO CLUSTER BLADE
BY VEHICLE	GOLF BORA JETTA	1J 1E	READ PINCODE	ALE			PIN READ EDC15 BLADE
BY VEHICLE	GOLF BORA JETTA	1J 1E	READ PINCODE	ALH			PIN READ EDC15 BLADE
BY VEHICLE	GOLF BORA JETTA	1J 1E	READ PINCODE	AMF			PIN READ EDC15 BLADE
BY VEHICLE	GOLF BORA JETTA	1J 1E	READ PINCODE	ANU			PIN READ EDC15 BLADE
BY VEHICLE	GOLF BORA JETTA	1J 1E	READ PINCODE	APE			PIN READ KW1281 EMS BLADE
BY VEHICLE	GOLF BORA JETTA	1J 1E	READ PINCODE	APF			PIN READ AUTO CLUSTER BLADE
BY VEHICLE	GOLF BORA JETTA	1J 1E	READ PINCODE	APK			PIN READ AUTO CLUSTER BLADE
BY VEHICLE	GOLF BORA JETTA	1J 1E	READ PINCODE	AQA			PIN READ KW1281 EMS BLADE
BY VEHICLE	GOLF BORA JETTA	1J 1E	READ PINCODE	AQM			PIN READ EDC15 BLADE
BY VEHICLE	GOLF BORA JETTA	1J 1E	READ PINCODE	AQN			PIN READ KW1281 EMS BLADE
BY VEHICLE	GOLF BORA JETTA	1J 1E	READ PINCODE	AQP			PIN READ KW1281 EMS BLADE
BY VEHICLE	GOLF BORA JETTA	1J 1E	READ PINCODE	AQY			PIN READ AUTO CLUSTER BLADE
BY VEHICLE	GOLF BORA JETTA	1J 1E	READ PINCODE	ARL			PIN READ EDC15 BLADE
BY VEHICLE	GOLF BORA JETTA	1J 1E	READ PINCODE	ARX			PIN READ KW1281 EMS BLADE
BY VEHICLE	GOLF BORA JETTA	1J 1E	READ PINCODE	ARZ			PIN READ KW1281 EMS BLADE
BY VEHICLE	GOLF BORA JETTA	1J 1E	READ PINCODE	ASZ			PIN READ EDC15 BLADE
BY VEHICLE	GOLF BORA JETTA	1J 1E	READ PINCODE	ATD			PIN READ EDC15 BLADE
BY VEHICLE	GOLF BORA JETTA	1J 1E	READ PINCODE	ATF			PIN READ AUTO CLUSTER BLADE
BY VEHICLE	GOLF BORA JETTA	1J 1E	READ PINCODE	ATN			PIN READ AUTO CLUSTER BLADE
BY VEHICLE	GOLF BORA JETTA	1J 1E	READ PINCODE	ATU			PIN READ AUTO CLUSTER BLADE
BY VEHICLE	GOLF BORA JETTA	1J 1E	READ PINCODE	AUA			PIN READ AUTO CLUSTER BLADE
BY VEHICLE	GOLF BORA JETTA	1J 1E	READ PINCODE	AUE			PIN READ KW1281 EMS BLADE
BY VEHICLE	GOLF BORA JETTA	1J 1E	READ PINCODE	AUM			PIN READ KW1281 EMS BLADE
BY VEHICLE	GOLF BORA JETTA	1J 1E	READ PINCODE	AUQ			PIN READ KW1281 EMS BLADE
BY VEHICLE	GOLF BORA JETTA	1J 1E	READ PINCODE	AUR			PIN READ AUTO CLUSTER BLADE
BY VEHICLE	GOLF BORA JETTA	1J 1E	READ PINCODE	AUS			PIN READ AUTO CLUSTER BLADE
BY VEHICLE	GOLF BORA JETTA	1J 1E	READ PINCODE	AUW			PIN READ KW1281 EMS BLADE
BY VEHICLE	GOLF BORA JETTA	1J 1E	READ PINCODE	AUY			PIN READ EDC15 BLADE
BY VEHICLE	GOLF BORA JETTA	1J 1E	READ PINCODE	AVH			PIN READ KW1281 EMS BLADE
BY VEHICLE	GOLF BORA JETTA	1J 1E	READ PINCODE	AVU			PIN READ AUTO CLUSTER BLADE
BY VEHICLE	GOLF BORA JETTA	1J 1E	READ PINCODE	AWD			PIN READ KW1281 EMS BLADE
BY VEHICLE	GOLF BORA JETTA	1J 1E	READ PINCODE	AWM			PIN READ KW1281 EMS BLADE
BY VEHICLE	GOLF BORA JETTA	1J 1E	READ PINCODE	AWP			PIN READ KW1281 EMS BLADE
BY VEHICLE	GOLF BORA JETTA	1J 1E	READ PINCODE	AWW			PIN READ KW1281 EMS BLADE
BY VEHICLE	GOLF BORA JETTA	1J 1E	READ PINCODE	AXP			PIN READ KW1281 EMS BLADE
BY VEHICLE	GOLF BORA JETTA	1J 1E	READ PINCODE	AXR			PIN READ EDC15 BLADE
BY VEHICLE	GOLF BORA JETTA	1J 1E	READ PINCODE	AZD			PIN READ AUTO CLUSTER BLADE
BY VEHICLE	GOLF BORA JETTA	1J 1E	READ PINCODE	AZG			PIN READ KW1281 EMS BLADE
BY VEHICLE	GOLF BORA JETTA	1J 1E	READ PINCODE	AZH			PIN READ KW1281 EMS BLADE
BY VEHICLE	GOLF BORA JETTA	1J 1E	READ PINCODE	AZI			PIN READ KW1281 EMS BLADE
BY VEHICLE	GOLF BORA JETTA	1J 1E	READ PINCODE	BAD			PIN READ AUTO CLUSTER BLADE
BY VEHICLE	GOLF BORA JETTA	1J 1E	READ PINCODE	BAG			PIN READ AUTO CLUSTER BLADE
BY VEHICLE	GOLF BORA JETTA	1J 1E	READ PINCODE	BCA			PIN READ KW1281 EMS BLADE
BY VEHICLE	GOLF BORA JETTA	1J 1E	READ PINCODE	BCB			PIN READ AUTO CLUSTER BLADE
BY VEHICLE	GOLF BORA JETTA	1J 1E	READ PINCODE	BDE			PIN READ KW1281 EMS BLADE
BY VEHICLE	GOLF BORA JETTA	1J 1E	READ PINCODE	BEH			PIN READ KW1281 EMS BLADE
BY VEHICLE	GOLF BORA JETTA	1J 1E	READ PINCODE	BEV			PIN READ KW1281 EMS BLADE
BY VEHICLE	GOLF BORA JETTA	1J 1E	READ PINCODE	BEW			PIN READ EDC15 BLADE
BY VEHICLE	GOLF BORA JETTA	1J 1E	READ PINCODE	BFH			PIN READ KW1281 EMS BLADE
BY VEHICLE	GOLF BORA JETTA	1J 1E	READ PINCODE	BFQ			PIN READ AUTO CLUSTER BLADE
BY VEHICLE	GOLF BORA JETTA	1J 1E	READ PINCODE	BHP			PIN READ KW1281 EMS BLADE
BY VEHICLE	GOLF BORA JETTA	1J 1E	READ PINCODE	BHR			PIN READ KW1281 EMS BLADE
BY VEHICLE	GOLF BORA JETTA	1J 1E	READ PINCODE	BJS			PIN READ KW1281 EMS BLADE
BY VEHICLE	GOLF BORA JETTA	1J 1E	READ PINCODE	BML			PIN READ KW1281 EMS BLADE
BY VEHICLE	GOLF BORA JETTA	1J 1E	READ PINCODE	BPR			PIN READ KW2000 EMS 1 BLADE
BY VEHICLE	GOLF BORA JETTA	1K	IMMOBILISER	TYPE 1			IMMOBILISER TP20 TYPE 2 BLADE
BY VEHICLE	GOLF BORA JETTA	1K	IMMOBILISER	TYPE 2			IMMOBILISER KW1281 TYPE 2 BLADE
BY VEHICLE	GOLF BORA JETTA	1K	IMMOBILISER	2009-2011			IMMOBILISER UDS VDO BLADE

VW 7/15

By Vehicle list – as displayed on AD100Pro/MVPPPro

This list cross-references Pro Menu to the Smart Pro By System list

BY VEHICLE	GOLF BORA JETTA	1K	REMOTE	TYPE 1		REMOTE TP20 TYPE 6 BLADE
BY VEHICLE	GOLF BORA JETTA	1K	REMOTE	TYPE 2		REMOTE TP20 TYPE 7 BLADE
BY VEHICLE	GOLF BORA JETTA	1K	READ PINCODE	AXW		PIN READ MED 9510 BLADE
BY VEHICLE	GOLF BORA JETTA	1K	READ PINCODE	AXX		PIN READ MED 91 TYPE 1 BLADE
BY VEHICLE	GOLF BORA JETTA	1K	READ PINCODE	AZV	EDCU1	PIN READ EDC16U1 TYPE 1 BLADE
BY VEHICLE	GOLF BORA JETTA	1K	READ PINCODE	AZV	EDCU31	PIN READ EDC16U31 TYPE 1 BLADE
BY VEHICLE	GOLF BORA JETTA	1K	READ PINCODE	BAG		PIN READ MED 9510 BLADE
BY VEHICLE	GOLF BORA JETTA	1K	READ PINCODE	BCA		PIN READ KW2000 EMS 1 BLADE
BY VEHICLE	GOLF BORA JETTA	1K	READ PINCODE	BDB		PIN READ KW2000 EMS 1 BLADE
BY VEHICLE	GOLF BORA JETTA	1K	READ PINCODE	BDK		PIN READ EDC16U1 TYPE 1 BLADE
BY VEHICLE	GOLF BORA JETTA	1K	READ PINCODE	BGP		PIN READ KW2000 EMS 1 BLADE
BY VEHICLE	GOLF BORA JETTA	1K	READ PINCODE	BGQ		PIN READ KW2000 EMS 1 BLADE
BY VEHICLE	GOLF BORA JETTA	1K	READ PINCODE	BKC		PIN READ EDC16U1 TYPE 1 BLADE
BY VEHICLE	GOLF BORA JETTA	1K	READ PINCODE	BKD		PIN READ EDC16U1 TYPE 1 BLADE
BY VEHICLE	GOLF BORA JETTA	1K	READ PINCODE	BKG		PIN READ MED 9510 BLADE
BY VEHICLE	GOLF BORA JETTA	1K	READ PINCODE	BLF		PIN READ MED 9510 BLADE
BY VEHICLE	GOLF BORA JETTA	1K	READ PINCODE	BLG		PIN READ MED 9510 BLADE
BY VEHICLE	GOLF BORA JETTA	1K	READ PINCODE	BLN		PIN READ MED 9510 BLADE
BY VEHICLE	GOLF BORA JETTA	1K	READ PINCODE	BLP		PIN READ MED 9510 BLADE
BY VEHICLE	GOLF BORA JETTA	1K	READ PINCODE	BLR		PIN READ MED 9510 BLADE
BY VEHICLE	GOLF BORA JETTA	1K	READ PINCODE	BLS		PIN READ EDC16U34 TYPE 1 BLADE
BY VEHICLE	GOLF BORA JETTA	1K	READ PINCODE	BLX		PIN READ MED 9510 BLADE
BY VEHICLE	GOLF BORA JETTA	1K	READ PINCODE	BLY		PIN READ MED 9510 BLADE
BY VEHICLE	GOLF BORA JETTA	1K	READ PINCODE	BMJ		PIN READ KW2000 EMS 1 BLADE
BY VEHICLE	GOLF BORA JETTA	1K	READ PINCODE	BMM		PIN READ EDC16U34 TYPE 1 BLADE
BY VEHICLE	GOLF BORA JETTA	1K	READ PINCODE	BMN		PIN READ PPD 1115 BLADE
BY VEHICLE	GOLF BORA JETTA	1K	READ PINCODE	BMY		PIN READ MED 17.5 BLADE
BY VEHICLE	GOLF BORA JETTA	1K	READ PINCODE	BPY		PIN READ MED 91 TYPE 1 BLADE
BY VEHICLE	GOLF BORA JETTA	1K	READ PINCODE	BRM		PIN READ EDC16U34 TYPE 1 BLADE
BY VEHICLE	GOLF BORA JETTA	1K	READ PINCODE	BRU		PIN READ EDC16U1 TYPE 1 BLADE
BY VEHICLE	GOLF BORA JETTA	1K	READ PINCODE	BTk		PIN READ KW2000 EMS 1 BLADE
BY VEHICLE	GOLF BORA JETTA	1K	READ PINCODE	BUB		PIN READ KW2000 EMS 1 BLADE
BY VEHICLE	GOLF BORA JETTA	1K	READ PINCODE	BVE		PIN READ PPD 1115 BLADE
BY VEHICLE	GOLF BORA JETTA	1K	READ PINCODE	BVX		PIN READ MED 9510 BLADE
BY VEHICLE	GOLF BORA JETTA	1K	READ PINCODE	BVY		PIN READ MED 9510 BLADE
BY VEHICLE	GOLF BORA JETTA	1K	READ PINCODE	BVZ		PIN READ MED 9510 BLADE
BY VEHICLE	GOLF BORA JETTA	1K	READ PINCODE	BWA		PIN READ MED 91 TYPE 1 BLADE
BY VEHICLE	GOLF BORA JETTA	1K	READ PINCODE	BXE		PIN READ EDC16U34 TYPE 1 BLADE
BY VEHICLE	GOLF BORA JETTA	1K	READ PINCODE	BXF		PIN READ EDC16U34 TYPE 1 BLADE
BY VEHICLE	GOLF BORA JETTA	1K	READ PINCODE	BXJ		PIN READ EDC16U34 TYPE 1 BLADE
BY VEHICLE	GOLF BORA JETTA	1K	READ PINCODE	BYD		PIN READ MED 91 TYPE 1 BLADE
BY VEHICLE	GOLF BORA JETTA	1K	READ PINCODE	CAVD		PIN READ MED 17.5 BLADE
BY VEHICLE	GOLF BORA JETTA	1K	READ PINCODE	CAWB		PIN READ MED 17.5 BLADE
BY VEHICLE	GOLF BORA JETTA	1K	READ PINCODE	CAXA		PIN READ MED 17.5 BLADE
BY VEHICLE	GOLF BORA JETTA	1K	READ PINCODE	CBDA		PIN READ EDC17 BLADE
BY VEHICLE	GOLF BORA JETTA	1K	READ PINCODE	CBDB		PIN READ EDC17 BLADE
BY VEHICLE	GOLF BORA JETTA	1K	READ PINCODE	CBEA		PIN READ EDC17 BLADE
BY VEHICLE	GOLF BORA JETTA	1K	READ PINCODE	CBFA		PIN READ MED 17.5 BLADE
BY VEHICLE	GOLF BORA JETTA	1K	READ PINCODE	CBRA		PIN READ KW2000 EMS 1 BLADE
BY VEHICLE	GOLF BORA JETTA	1K	READ PINCODE	CBTA		PIN READ KW2000 EMS 1 BLADE
BY VEHICLE	GOLF BORA JETTA	1K	READ PINCODE	CBUA		PIN READ KW2000 EMS 1 BLADE
BY VEHICLE	GOLF BORA JETTA	1K	READ PINCODE	CCCA		PIN READ KW2000 EMS 1 BLADE
BY VEHICLE	GOLF BORA JETTA	1K	READ PINCODE	CCTA		PIN READ MED 17.5 BLADE
BY VEHICLE	GOLF BORA JETTA	1K	READ PINCODE	CCZA		PIN READ MED 17.5 BLADE
BY VEHICLE	GOLF BORA JETTA	1K	READ PINCODE	CCZB		PIN READ MED 17.5 BLADE
BY VEHICLE	GOLF BORA JETTA	1K	READ PINCODE	CEGA		PIN READ EDC17 BLADE
BY VEHICLE	GOLF BORA JETTA	1K	READ PINCODE	CJAA		PIN READ EDC17 BLADE
BY VEHICLE	GOLF BORA JETTA	5M	IMMOBILISER	TYPE 1		IMMOBILISER TP20 TYPE 2 BLADE
BY VEHICLE	GOLF BORA JETTA	5M	IMMOBILISER	TYPE 2		IMMOBILISER KW1281 TYPE 2 BLADE
BY VEHICLE	GOLF BORA JETTA	5M	REMOTE	TYPE 1		REMOTE TP20 TYPE 6 BLADE
BY VEHICLE	GOLF BORA JETTA	5M	REMOTE	TYPE 2		REMOTE TP20 TYPE 7 BLADE
BY VEHICLE	GOLF BORA JETTA	5M	READ PINCODE	AZV	EDCU1	PIN READ EDC16U1 TYPE 1 BLADE
BY VEHICLE	GOLF BORA JETTA	5M	READ PINCODE	AZV	EDCU31	PIN READ EDC16U31 TYPE 1 BLADE
BY VEHICLE	GOLF BORA JETTA	5M	READ PINCODE	BCA		PIN READ KW2000 EMS 1 BLADE
BY VEHICLE	GOLF BORA JETTA	5M	READ PINCODE	BEE		PIN READ KW2000 EMS 1 BLADE
BY VEHICLE	GOLF BORA JETTA	5M	READ PINCODE	BDK		PIN READ EDC16U1 TYPE 1 BLADE

VW 8/15

By Vehicle list – as displayed on AD100Pro/MVPPPro

This list cross-references Pro Menu to the Smart Pro By System list

BY VEHICLE	GOLF BORA JETTA	5M	READ PINCODE	BKC		PIN READ EDC16U1 TYPE 1 BLADE
BY VEHICLE	GOLF BORA JETTA	5M	READ PINCODE	BKD		PIN READ EDC16U1 TYPE 1 BLADE
BY VEHICLE	GOLF BORA JETTA	5M	READ PINCODE	BKG		PIN READ MED 9510 BLADE
BY VEHICLE	GOLF BORA JETTA	5M	READ PINCODE	BLF		PIN READ MED 9510 BLADE
BY VEHICLE	GOLF BORA JETTA	5M	READ PINCODE	BLG		PIN READ MED 9510 BLADE
BY VEHICLE	GOLF BORA JETTA	5M	READ PINCODE	BLN		PIN READ MED 9510 BLADE
BY VEHICLE	GOLF BORA JETTA	5M	READ PINCODE	BLP		PIN READ MED 9510 BLADE
BY VEHICLE	GOLF BORA JETTA	5M	READ PINCODE	BLR		PIN READ MED 9510 BLADE
BY VEHICLE	GOLF BORA JETTA	5M	READ PINCODE	BLS		PIN READ EDC16U34 TYPE 1 BLADE
BY VEHICLE	GOLF BORA JETTA	5M	READ PINCODE	BLY		PIN READ MED 9510 BLADE
BY VEHICLE	GOLF BORA JETTA	5M	READ PINCODE	BMM		PIN READ EDC16U34 TYPE 1 BLADE
BY VEHICLE	GOLF BORA JETTA	5M	READ PINCODE	BMV		PIN READ MED 17.5 BLADE
BY VEHICLE	GOLF BORA JETTA	5M	READ PINCODE	BRU		PIN READ EDC16U1 TYPE 1 BLADE
BY VEHICLE	GOLF BORA JETTA	5M	READ PINCODE	BTK		PIN READ KW2000 EMS 1 BLADE
BY VEHICLE	GOLF BORA JETTA	5M	READ PINCODE	BUB		PIN READ KW2000 EMS 1 BLADE
BY VEHICLE	GOLF BORA JETTA	5M	READ PINCODE	BVB		PIN READ PPD 1115 BLADE
BY VEHICLE	GOLF BORA JETTA	5M	READ PINCODE	BXE		PIN READ EDC16U34 TYPE 1 BLADE
BY VEHICLE	GOLF BORA JETTA	5M	READ PINCODE	BXF		PIN READ EDC16U34 TYPE 1 BLADE
BY VEHICLE	GOLF BORA JETTA	5M	READ PINCODE	CAVD		PIN READ MED 17.5 BLADE
BY VEHICLE	GOLF BORA JETTA	5M	READ PINCODE	CAXA		PIN READ MED 17.5 BLADE
BY VEHICLE	GOLF BORA JETTA	5M	READ PINCODE	CCCA		PIN READ KW2000 EMS 1 BLADE
BY VEHICLE	KOMBI	7HJ	IMMOBILISER			IMMOBILISER KW1281 TYPE 2 BLADE
BY VEHICLE	KOMBI	7HJ	REMOTE	TYPE 1		REMOTE KW1281 TYPE 3 BLADE
BY VEHICLE	KOMBI	7HJ	REMOTE	TYPE 2		REMOTE KW1281 TYPE 4 BLADE
BY VEHICLE	KOMBI	7HJ	REMOTE	TYPE 3		REMOTE TP20 TYPE 8 BLADE
BY VEHICLE	KOMBI	7HJ	REMOTE	TYPE 4		REMOTE TP20 TYPE 9 BLADE
BY VEHICLE	KOMBI	7HJ	READ PINCODE	AUTOCLUSTER		PIN READ AUTO CLUSTER BLADE
BY VEHICLE	KOMBI	7HJ	READ PINCODE	AXA		PIN READ KW1281 EMS BLADE
BY VEHICLE	KOMBI	7HJ	READ PINCODE	AXB		PIN READ EDC16U1 TYPE 2 BLADE
BY VEHICLE	KOMBI	7HJ	READ PINCODE	AXC		PIN READ EDC16U31 TYPE 2 BLADE
BY VEHICLE	KOMBI	7HJ	READ PINCODE	AXD		PIN READ EDC16U31 TYPE 2 BLADE
BY VEHICLE	KOMBI	7HJ	READ PINCODE	AXE		PIN READ EDC16U31 TYPE 2 BLADE
BY VEHICLE	KOMBI	7HJ	READ PINCODE	BDL		PIN READ KW1281 EMS BLADE
BY VEHICLE	KOMBI	7HJ	READ PINCODE	BKK		PIN READ KW1281 EMS BLADE
BY VEHICLE	KOMBI	7HJ	READ PINCODE	BNZ		PIN READ EDC16U31 TYPE 2 BLADE
BY VEHICLE	KOMBI	7HJ	READ PINCODE	BPC		PIN READ EDC16U31 TYPE 2 BLADE
BY VEHICLE	KOMBI	7HJ	READ PINCODE	BRR		PIN READ EDC16U31 TYPE 2 BLADE
BY VEHICLE	KOMBI	7HJ	READ PINCODE	BRS		PIN READ EDC16U31 TYPE 2 BLADE
BY VEHICLE	LAVIDA		IMMOBILISER			IMMOBILISER KW1281 TYPE 1 BLADE
BY VEHICLE	LAVIDA		REMOTE	TYPE 1		REMOTE KW1281 TYPE 3 BLADE
BY VEHICLE	LAVIDA		REMOTE	TYPE 2		REMOTE KW1281 TYPE 4 BLADE
BY VEHICLE	LAVIDA		REMOTE	TYPE 3		REMOTE TP20 TYPE 8 BLADE
BY VEHICLE	LAVIDA		REMOTE	TYPE 4		REMOTE TP20 TYPE 9 BLADE
BY VEHICLE	LT	2D	IMMOBILISER			IMMOBILISER KW1281 TYPE 1 BLADE
BY VEHICLE	LT	2D	REMOTE	TYPE 1		REMOTE KW1281 TYPE 3 BLADE
BY VEHICLE	LT	2D	REMOTE	TYPE 2		REMOTE KW1281 TYPE 4 BLADE
BY VEHICLE	LT	2D	REMOTE	TYPE 3		REMOTE TP20 TYPE 8 BLADE
BY VEHICLE	LT	2D	REMOTE	TYPE 4		REMOTE TP20 TYPE 9 BLADE
BY VEHICLE	LT	2D	SRS AIRBAG			SPECIAL FUNCTION VAG SRS
BY VEHICLE	LT	2D	AUTO GEARBOX			SPECIAL FUNCTION AUTO GEARBOX
BY VEHICLE	LT	2D	READ PINCODE	AGK		PIN READ EDC15 BLADE
BY VEHICLE	LT	2D	READ PINCODE	AGL		PIN READ IMMO EMS BLADE
BY VEHICLE	LT	2D	READ PINCODE	AGX		PIN READ EDC15 BLADE
BY VEHICLE	LT	2D	READ PINCODE	AHD		PIN READ EDC15 BLADE
BY VEHICLE	LT	2D	READ PINCODE	ANJ		PIN READ EDC15 BLADE
BY VEHICLE	LT	2D	READ PINCODE	APA		PIN READ EDC15 BLADE
BY VEHICLE	LT	2D	READ PINCODE	ATA		PIN READ EDC15 BLADE
BY VEHICLE	LT	2D	READ PINCODE	AUH		PIN READ EDC15 BLADE
BY VEHICLE	LT	2D	READ PINCODE	AVR		PIN READ EDC15 BLADE
BY VEHICLE	LT	2D	READ PINCODE	AWZ		PIN READ EDC15 BLADE
BY VEHICLE	LT	2D	READ PINCODE	AXF		PIN READ EDC15 BLADE
BY VEHICLE	LT	2D	READ PINCODE	BBE		PIN READ EDC15 BLADE
BY VEHICLE	LT	2D	READ PINCODE	BBF		PIN READ EDC15 BLADE
BY VEHICLE	LT	2D	READ PINCODE	BCQ		PIN READ EDC15 BLADE
BY VEHICLE	LT	2D	READ PINCODE	IMMOBILISER BOX		PIN READ IMMO EMS BLADE
BY VEHICLE	LT	2E 2F	IMMOBILISER			IMMOBILISER KW1281 TYPE 1 BLADE

VW 9/15

By Vehicle list – as displayed on AD100Pro/MVPPPro

This list cross-references Pro Menu to the Smart Pro By System list

BY VEHICLE	LT	2E 2F	REMOTE	TYPE 1			REMOTE KW1281 TYPE 3 BLADE
BY VEHICLE	LT	2E 2F	REMOTE	TYPE 2			REMOTE KW1281 TYPE 4 BLADE
BY VEHICLE	LT	2E 2F	REMOTE	TYPE 3			REMOTE TP20 TYPE 8 BLADE
BY VEHICLE	LT	2E 2F	REMOTE	TYPE 4			REMOTE TP20 TYPE 9 BLADE
BY VEHICLE	LT	2E 2F	SRS AIRBAG				SPECIAL FUNCTION VAG SRS
BY VEHICLE	LT	2E 2F	AUTO GEARBOX				SPECIAL FUNCTION AUTO GEARBOX
BY VEHICLE	LT	2E 2F	READ PINCODE	AUTOCLUSTER			PIN READ AUTO CLUSTER BLADE
BY VEHICLE	LT	2E 2F	READ PINCODE	IMMOBILISER BOX			PIN READ IMMO EMS BLADE
BY VEHICLE	LT	2E 2F	READ PINCODE	BJJ			PIN READ EDC16U34 TYPE 2 BLADE
BY VEHICLE	LT	2E 2F	READ PINCODE	BJK			PIN READ EDC16U34 TYPE 2 BLADE
BY VEHICLE	LT	2E 2F	READ PINCODE	BJL			PIN READ EDC16U34 TYPE 2 BLADE
BY VEHICLE	LT	2E 2F	READ PINCODE	BJM			PIN READ EDC16U34 TYPE 2 BLADE
BY VEHICLE	LT	2E 2F	READ PINCODE	CEBA			PIN READ EDC17 BLADE
BY VEHICLE	LT	2E 2F	READ PINCODE	CEBB			PIN READ EDC17 BLADE
BY VEHICLE	LUPO	6X	IMMOBILISER				IMMOBILISER KW1281 TYPE 1 BLADE
BY VEHICLE	LUPO	6X	REMOTE	TYPE 1			REMOTE KW1281 TYPE 3 BLADE
BY VEHICLE	LUPO	6X	REMOTE	TYPE 2			REMOTE KW1281 TYPE 4 BLADE
BY VEHICLE	LUPO	6X	REMOTE	TYPE 3			REMOTE TP20 TYPE 8 BLADE
BY VEHICLE	LUPO	6X	REMOTE	TYPE 4			REMOTE TP20 TYPE 9 BLADE
BY VEHICLE	LUPO	6X	SRS AIRBAG				SPECIAL FUNCTION VAG SRS
BY VEHICLE	LUPO	6X	AUTO GEARBOX				SPECIAL FUNCTION AUTO GEARBOX
BY VEHICLE	LUPO	6X	READ PINCODE	AKU			PIN READ EDC15 BLADE
BY VEHICLE	LUPO	6X	READ PINCODE	ALD			PIN READ KW1281 EMS BLADE
BY VEHICLE	LUPO	6X	READ PINCODE	AMF			PIN READ EDC15 BLADE
BY VEHICLE	LUPO	6X	READ PINCODE	ANV			PIN READ KW1281 EMS BLADE
BY VEHICLE	LUPO	6X	READ PINCODE	ANY			PIN READ EDC15 BLADE
BY VEHICLE	LUPO	6X	READ PINCODE	APE			PIN READ KW1281 EMS BLADE
BY VEHICLE	LUPO	6X	READ PINCODE	AUC			PIN READ KW1281 EMS BLADE
BY VEHICLE	LUPO	6X	READ PINCODE	AUD			PIN READ KW1281 EMS BLADE
BY VEHICLE	LUPO	6X	READ PINCODE	AYR			PIN READ EDC15 BLADE
BY VEHICLE	LUPO	6X	READ PINCODE	AYZ			PIN READ EDC15 BLADE
BY VEHICLE	MULTIVAN	7HF	IMMOBILISER				IMMOBILISER KW1281 TYPE 2 BLADE
BY VEHICLE	MULTIVAN	7HF	REMOTE	TYPE 1			REMOTE KW1281 TYPE 3 BLADE
BY VEHICLE	MULTIVAN	7HF	REMOTE	TYPE 2			REMOTE KW1281 TYPE 4 BLADE
BY VEHICLE	MULTIVAN	7HF	REMOTE	TYPE 3			REMOTE TP20 TYPE 8 BLADE
BY VEHICLE	MULTIVAN	7HF	REMOTE	TYPE 4			REMOTE TP20 TYPE 9 BLADE
BY VEHICLE	MULTIVAN	7HF	READ PINCODE	AUTOCLUSTER			PIN READ AUTO CLUSTER BLADE
BY VEHICLE	MULTIVAN	7HF	READ PINCODE	AXA			PIN READ KW1281 EMS BLADE
BY VEHICLE	MULTIVAN	7HF	READ PINCODE	AXB			PIN READ EDC16U1 TYPE 2 BLADE
BY VEHICLE	MULTIVAN	7HF	READ PINCODE	AXC			PIN READ EDC16U31 TYPE 2 BLADE
BY VEHICLE	MULTIVAN	7HF	READ PINCODE	AXD			PIN READ EDC16U31 TYPE 2 BLADE
BY VEHICLE	MULTIVAN	7HF	READ PINCODE	AXE			PIN READ EDC16U31 TYPE 2 BLADE
BY VEHICLE	MULTIVAN	7HF	READ PINCODE	BDL			PIN READ KW1281 EMS BLADE
BY VEHICLE	MULTIVAN	7HF	READ PINCODE	BKK			PIN READ KW1281 EMS BLADE
BY VEHICLE	MULTIVAN	7HF	READ PINCODE	BNZ			PIN READ EDC16U31 TYPE 2 BLADE
BY VEHICLE	MULTIVAN	7HF	READ PINCODE	BPC			PIN READ EDC16U31 TYPE 2 BLADE
BY VEHICLE	MULTIVAN	7HF	READ PINCODE	BRR			PIN READ EDC16U31 TYPE 2 BLADE
BY VEHICLE	MULTIVAN	7HF	READ PINCODE	BRS			PIN READ EDC16U31 TYPE 2 BLADE
BY VEHICLE	PASSAT	3B B5	IMMOBILISER				IMMOBILISER KW1281 TYPE 2 BLADE
BY VEHICLE	PASSAT	3B B5	REMOTE	TYPE 1			REMOTE KW1281 TYPE 3 BLADE
BY VEHICLE	PASSAT	3B B5	REMOTE	TYPE 2			REMOTE KW1281 TYPE 4 BLADE
BY VEHICLE	PASSAT	3B B5	REMOTE	TYPE 3			REMOTE TP20 TYPE 8 BLADE
BY VEHICLE	PASSAT	3B B5	REMOTE	TYPE 4			REMOTE TP20 TYPE 9 BLADE
BY VEHICLE	PASSAT	3B B5	SRS AIRBAG				SPECIAL FUNCTION VAG SRS
BY VEHICLE	PASSAT	3B B5	AUTO GEARBOX				SPECIAL FUNCTION AUTO GEARBOX
BY VEHICLE	PASSAT	3B B5	READ PINCODE	AUTOCLUSTER			PIN READ AUTO CLUSTER BLADE
BY VEHICLE	PASSAT	3B B5	READ PINCODE	MMCLUSTER	MM4		PIN READ MM4 BLADE
BY VEHICLE	PASSAT	3B B5	READ PINCODE	MMCLUSTER	USA MM4 VW		PIN READ MM4 VW BLADE
BY VEHICLE	PASSAT	3B B5	READ PINCODE	MMCLUSTER	USA MM4 AUDI		PIN READ USA MM4 AUDI BLADE
BY VEHICLE	PASSAT	3B B5	READ PINCODE	MMCLUSTER	EURO MM4 VW		PIN READ EUR MM4 VW BLADE
BY VEHICLE	PASSAT	3B B5	READ PINCODE	MMCLUSTER	EURO MM4 AUDI 1		PIN READ EUR MM4 AUDI BLADE
BY VEHICLE	PASSAT	3B B5	READ PINCODE	MMCLUSTER	EURO MM4 AUDI 2		PIN READ MM4 BLADE
BY VEHICLE	PASSAT	3B B5	READ PINCODE	MMCLUSTER	USA MM4 AUDI A3		PIN READ USA MM4 AUDI A3 BLADE
BY VEHICLE	PASSAT	3B B5	READ PINCODE	MMCLUSTER	BEETLE MMS		PIN READ BEETLE MMS BLADE
BY VEHICLE	PASSAT	3B B5	READ PINCODE	MMCLUSTER	BEETLE MMS 05	TYPE 1	PIN READ BEETLE MMS 05 TYPE 1 BLADE
BY VEHICLE	PASSAT	3B B5	READ PINCODE	MMCLUSTER	BEETLE MMS 05	TYPE 2	PIN READ BEETLE MMS 05 TYPE 2 BLADE

VW 10/15

By Vehicle list – as displayed on AD100Pro/MVPPPro

This list cross-references Pro Menu to the Smart Pro By System list

BY VEHICLE	PASSAT	3B B5	READ PINCODE	MMCLUSTER	MM5		PIN READ DASH MMS BLADE
BY VEHICLE	PASSAT	3B B5	READ PINCODE	ACK			PIN READ AUTO CLUSTER BLADE
BY VEHICLE	PASSAT	3B B5	READ PINCODE	ADP			PIN READ AUTO CLUSTER BLADE
BY VEHICLE	PASSAT	3B B5	READ PINCODE	ADR			PIN READ AUTO CLUSTER BLADE
BY VEHICLE	PASSAT	3B B5	READ PINCODE	AEB			PIN READ AUTO CLUSTER BLADE
BY VEHICLE	PASSAT	3B B5	READ PINCODE	AFB			PIN READ EDC15 BLADE
BY VEHICLE	PASSAT	3B B5	READ PINCODE	AFN			PIN READ EDC15 BLADE
BY VEHICLE	PASSAT	3B B5	READ PINCODE	AFY			PIN READ AUTO CLUSTER BLADE
BY VEHICLE	PASSAT	3B B5	READ PINCODE	AGE			PIN READ AUTO CLUSTER BLADE
BY VEHICLE	PASSAT	3B B5	READ PINCODE	AGZ			PIN READ AUTO CLUSTER BLADE
BY VEHICLE	PASSAT	3B B5	READ PINCODE	AHA			PIN READ AUTO CLUSTER BLADE
BY VEHICLE	PASSAT	3B B5	READ PINCODE	AHH			PIN READ EDC15 BLADE
BY VEHICLE	PASSAT	3B B5	READ PINCODE	AHL			PIN READ AUTO CLUSTER BLADE
BY VEHICLE	PASSAT	3B B5	READ PINCODE	AHU			PIN READ EDC15 BLADE
BY VEHICLE	PASSAT	3B B5	READ PINCODE	AJM			PIN READ EDC15 BLADE
BY VEHICLE	PASSAT	3B B5	READ PINCODE	AKN			PIN READ EDC15 BLADE
BY VEHICLE	PASSAT	3B B5	READ PINCODE	ALG			PIN READ AUTO CLUSTER BLADE
BY VEHICLE	PASSAT	3B B5	READ PINCODE	ALT			PIN READ KW1281 EMS BLADE
BY VEHICLE	PASSAT	3B B5	READ PINCODE	ALZ			PIN READ AUTO CLUSTER BLADE
BY VEHICLE	PASSAT	3B B5	READ PINCODE	AMX			PIN READ KW1281 EMS BLADE
BY VEHICLE	PASSAT	3B B5	READ PINCODE	ANA			PIN READ AUTO CLUSTER BLADE
BY VEHICLE	PASSAT	3B B5	READ PINCODE	ANB			PIN READ AUTO CLUSTER BLADE
BY VEHICLE	PASSAT	3B B5	READ PINCODE	APR			PIN READ KW1281 EMS BLADE
BY VEHICLE	PASSAT	3B B5	READ PINCODE	APT			PIN READ AUTO CLUSTER BLADE
BY VEHICLE	PASSAT	3B B5	READ PINCODE	APU			PIN READ AUTO CLUSTER BLADE
BY VEHICLE	PASSAT	3B B5	READ PINCODE	AQD			PIN READ KW1281 EMS BLADE
BY VEHICLE	PASSAT	3B B5	READ PINCODE	ARG			PIN READ AUTO CLUSTER BLADE
BY VEHICLE	PASSAT	3B B5	READ PINCODE	ARM			PIN READ AUTO CLUSTER BLADE
BY VEHICLE	PASSAT	3B B5	READ PINCODE	ASU			PIN READ KW1281 EMS BLADE
BY VEHICLE	PASSAT	3B B5	READ PINCODE	ATJ			PIN READ EDC15 BLADE
BY VEHICLE	PASSAT	3B B5	READ PINCODE	ATQ			PIN READ KW1281 EMS BLADE
BY VEHICLE	PASSAT	3B B5	READ PINCODE	ATW			PIN READ AUTO CLUSTER BLADE
BY VEHICLE	PASSAT	3B B5	READ PINCODE	AUG			PIN READ AUTO CLUSTER BLADE
BY VEHICLE	PASSAT	3B B5	READ PINCODE	ATW			PIN READ KW1281 EMS BLADE
BY VEHICLE	PASSAT	3B B5	READ PINCODE	ATX			PIN READ KW1281 EMS BLADE
BY VEHICLE	PASSAT	3B B5	READ PINCODE	AUG			PIN READ KW1281 EMS BLADE
BY VEHICLE	PASSAT	3B B5	READ PINCODE	AUZ			PIN READ KW1281 EMS BLADE
BY VEHICLE	PASSAT	3B B5	READ PINCODE	AVA			PIN READ KW1281 EMS BLADE
BY VEHICLE	PASSAT	3B B5	READ PINCODE	AVB			PIN READ EDC15 BLADE
BY VEHICLE	PASSAT	3B B5	READ PINCODE	AVF			PIN READ EDC15 BLADE
BY VEHICLE	PASSAT	3B B5	READ PINCODE	AVG			PIN READ EDC15 BLADE
BY VEHICLE	PASSAT	3B B5	READ PINCODE	AWL			PIN READ KW1281 EMS BLADE
BY VEHICLE	PASSAT	3B B5	READ PINCODE	AWM			PIN READ KW1281 EMS BLADE
BY VEHICLE	PASSAT	3B B5	READ PINCODE	AWT			PIN READ KW1281 EMS BLADE
BY VEHICLE	PASSAT	3B B5	READ PINCODE	AWX			PIN READ EDC15 BLADE
BY VEHICLE	PASSAT	3B B5	READ PINCODE	AZM			PIN READ AUTO CLUSTER BLADE
BY VEHICLE	PASSAT	3B B5	READ PINCODE	BAU			PIN READ KW1281 EMS BLADE
BY VEHICLE	PASSAT	3B B5	READ PINCODE	BBG			PIN READ AUTO CLUSTER BLADE
BY VEHICLE	PASSAT	3B B5	READ PINCODE	BDG			PIN READ KW1281 EMS BLADE
BY VEHICLE	PASSAT	3B B5	READ PINCODE	BDH			PIN READ KW1281 EMS BLADE
BY VEHICLE	PASSAT	3B B5	READ PINCODE	BDN			PIN READ KW1281 EMS BLADE
BY VEHICLE	PASSAT	3B B5	READ PINCODE	BGW			PIN READ EDC16U31 TYPE 2 BLADE
BY VEHICLE	PASSAT	3B B5	READ PINCODE	BHW			PIN READ EDC16U31 TYPE 2 BLADE
BY VEHICLE	PASSAT	3C B6	IMMOBILISER	TYPE 1			IMMOBILISER TP20 TYPE 3 SLOT
BY VEHICLE	PASSAT	3C B6	IMMOBILISER	TYPE 2			IMMOBILISER TP20 TYPE 1 SLOT
BY VEHICLE	PASSAT	3C B6	REMOTE	TYPE 1			REMOTE TP20 TYPE 6 BLADE
BY VEHICLE	PASSAT	3C B6	REMOTE	TYPE 2			REMOTE TP20 TYPE 7 BLADE
BY VEHICLE	PASSAT	3C B6	READ PINCODE	AXX			PIN READ MED 91 TYPE 1 BLADE
BY VEHICLE	PASSAT	3C B6	READ PINCODE	AXZ			PIN READ MED 91 TYPE 1 BLADE
BY VEHICLE	PASSAT	3C B6	READ PINCODE	BKC			PIN READ EDC16U31 TYPE 1 BLADE
BY VEHICLE	PASSAT	3C B6	READ PINCODE	BKP ADD KEY			PIN READ IMMO CAN 4 BLADE
BY VEHICLE	PASSAT	3C B6	READ PINCODE	BLF			PIN READ MED 9510 BLADE
BY VEHICLE	PASSAT	3C B6	READ PINCODE	BLP			PIN READ MED 9510 BLADE
BY VEHICLE	PASSAT	3C B6	READ PINCODE	BLR			PIN READ MED 9510 BLADE
BY VEHICLE	PASSAT	3C B6	READ PINCODE	BLS			PIN READ EDC16U34 TYPE 1 BLADE
BY VEHICLE	PASSAT	3C B6	READ PINCODE	BLV			PIN READ MED 91 TYPE 1 BLADE

VW 11/15

By Vehicle list – as displayed on AD100Pro/MVPPPro

This list cross-references Pro Menu to the Smart Pro By System list

BY VEHICLE	PASSAT	3C B6	READ PINCODE	BLX		PIN READ MED 9510 BLADE
BY VEHICLE	PASSAT	3C B6	READ PINCODE	BLY		PIN READ MED 9510 BLADE
BY VEHICLE	PASSAT	3C B6	READ PINCODE	BMA		PIN READ PPD 1115 BLADE
BY VEHICLE	PASSAT	3C B6	READ PINCODE	BMP		PIN READ EDC16U34 TYPE 1 BLADE
BY VEHICLE	PASSAT	3C B6	READ PINCODE	BMR		PIN READ PPD 1115 BLADE
BY VEHICLE	PASSAT	3C B6	READ PINCODE	BPY		PIN READ MED 91 TYPE 1 BLADE
BY VEHICLE	PASSAT	3C B6	READ PINCODE	BUZ		PIN READ PPD 1115 BLADE
BY VEHICLE	PASSAT	3C B6	READ PINCODE	BVD		PIN READ EDC16U34 TYPE 1 BLADE
BY VEHICLE	PASSAT	3C B6	READ PINCODE	BVE		PIN READ PPD 1115 BLADE
BY VEHICLE	PASSAT	3C B6	READ PINCODE	BVX		PIN READ MED 9510 BLADE
BY VEHICLE	PASSAT	3C B6	READ PINCODE	BVY		PIN READ MED 9510 BLADE
BY VEHICLE	PASSAT	3C B6	READ PINCODE	BVZ		PIN READ MED 9510 BLADE
BY VEHICLE	PASSAT	3C B6	READ PINCODE	BWA		PIN READ MED 91 TYPE 1 BLADE
BY VEHICLE	PASSAT	3C B6	READ PINCODE	BWS		PIN READ MED 91 TYPE 1 BLADE
BY VEHICLE	PASSAT	3C B6	READ PINCODE	BWV		PIN READ PPD 1115 BLADE
BY VEHICLE	PASSAT	3C B6	READ PINCODE	BXE		PIN READ EDC16U34 TYPE 1 BLADE
BY VEHICLE	PASSAT	3C B6	READ PINCODE	BZB		PIN READ MED 17.5 BLADE
BY VEHICLE	PASSAT	3C B6	READ PINCODE	CABB		PIN READ MED 17.5 BLADE
BY VEHICLE	PASSAT	3C B6	READ PINCODE	CAVD		PIN READ MED 17.5 BLADE
BY VEHICLE	PASSAT	3C B6	READ PINCODE	CAWB		PIN READ MED 17.5 BLADE
BY VEHICLE	PASSAT	3C B6	READ PINCODE	CAXA		PIN READ MED 17.5 BLADE
BY VEHICLE	PASSAT	3C B6	READ PINCODE	CAXB		PIN READ MED 17.5 BLADE
BY VEHICLE	PASSAT	3C B6	READ PINCODE	CBAA		PIN READ EDC17 BLADE
BY VEHICLE	PASSAT	3C B6	READ PINCODE	CBAB		PIN READ EDC17 BLADE
BY VEHICLE	PASSAT	3C B6	READ PINCODE	CBAC		PIN READ EDC17 BLADE
BY VEHICLE	PASSAT	3C B6	READ PINCODE	CBBB		PIN READ EDC17 BLADE
BY VEHICLE	PASSAT	3C B6	READ PINCODE	CBDC		PIN READ EDC17 BLADE
BY VEHICLE	PASSAT	3C B6	READ PINCODE	CBFA		PIN READ MED 17.5 BLADE
BY VEHICLE	PASSAT	3C B6	READ PINCODE	CCTA		PIN READ MED 17.5 BLADE
BY VEHICLE	PASSAT	3C B6	READ PINCODE	CCTB		PIN READ MED 17.5 BLADE
BY VEHICLE	PASSAT	3C B6	READ PINCODE	CC2A		PIN READ MED 17.5 BLADE
BY VEHICLE	PASSAT	3C B6	READ PINCODE	CC2B		PIN READ MED 17.5 BLADE
BY VEHICLE	PASSAT	3C B6	READ PINCODE	CDAA		PIN READ MED 17.5 BLADE
BY VEHICLE	PASSAT	3C B6	READ PINCODE	CDAB		PIN READ MED 17.5 BLADE
BY VEHICLE	PASSAT	3C B6	READ PINCODE	CDGA		PIN READ MED 17.5 BLADE
BY VEHICLE	PHAETON	3D	IMMOBILISER			IMMOBILISER KW2000 KESSY BLADE
BY VEHICLE	PHAETON	3D	READ PINCODE	AJS		PIN READ EDC16U1 TYPE 2 BLADE
BY VEHICLE	PHAETON	3D	READ PINCODE	AYT		PIN READ KW2000 EMS 1 BLADE
BY VEHICLE	PHAETON	3D	READ PINCODE	BAN		PIN READ KW2000 EMS 1 BLADE
BY VEHICLE	PHAETON	3D	READ PINCODE	BAP		PIN READ KW2000 EMS 1 BLADE
BY VEHICLE	PHAETON	3D	READ PINCODE	BGH		PIN READ KW2000 EMS 1 BLADE
BY VEHICLE	PHAETON	3D	READ PINCODE	BGJ		PIN READ KW2000 EMS 1 BLADE
BY VEHICLE	PHAETON	3D	READ PINCODE	BKL		PIN READ KW2000 EMS 1 BLADE
BY VEHICLE	PHAETON	3D	READ PINCODE	BMK		PIN READ EDC16U34 TYPE 2 BLADE
BY VEHICLE	PHAETON	3D	READ PINCODE	BRK		PIN READ KW2000 EMS 1 BLADE
BY VEHICLE	PHAETON	3D	READ PINCODE	BRN		PIN READ KW2000 EMS 1 BLADE
BY VEHICLE	PHAETON	3D	READ PINCODE	BRP		PIN READ KW2000 EMS 1 BLADE
BY VEHICLE	PHAETON	3D	READ PINCODE	BTT		PIN READ KW2000 EMS 1 BLADE
BY VEHICLE	PHAETON	3D	READ PINCODE	CHNA		PIN READ MED 91 TYPE 1 BLADE
BY VEHICLE	PHAETON	3D	READ PINCODE	CMVA		PIN READ MED 91 TYPE 1 BLADE
BY VEHICLE	POLO	6N 6K	IMMOBILISER			IMMOBILISER KW1281 TYPE 1 BLADE
BY VEHICLE	POLO	6N 6K	REMOTE	TYPE 1		REMOTE KW1281 TYPE 3 BLADE
BY VEHICLE	POLO	6N 6K	REMOTE	TYPE 2		REMOTE KW1281 TYPE 4 BLADE
BY VEHICLE	POLO	6N 6K	REMOTE	TYPE 3		REMOTE TP20 TYPE 8 BLADE
BY VEHICLE	POLO	6N 6K	REMOTE	TYPE 4		REMOTE TP20 TYPE 9 BLADE
BY VEHICLE	POLO	6N 6K	SRS AIRBAG			SPECIAL FUNCTION VAG SRS
BY VEHICLE	POLO	6N 6K	AUTO GEARBOX			SPECIAL FUNCTION AUTO GEARBOX
BY VEHICLE	POLO	6N 6K	READ PINCODE	AEF		PIN READ EDC15 BLADE
BY VEHICLE	POLO	6N 6K	READ PINCODE	AEY		PIN READ EDC15 BLADE
BY VEHICLE	POLO	6N 6K	READ PINCODE	AFN		PIN READ EDC15 BLADE
BY VEHICLE	POLO	6N 6K	READ PINCODE	AGD		PIN READ EDC15 BLADE
BY VEHICLE	POLO	6N 6K	READ PINCODE	AGP		PIN READ EDC15 BLADE
BY VEHICLE	POLO	6N 6K	READ PINCODE	AGR		PIN READ EDC15 BLADE
BY VEHICLE	POLO	6N 6K	READ PINCODE	AHG		PIN READ EDC15 BLADE
BY VEHICLE	POLO	6N 6K	READ PINCODE	AHU		PIN READ EDC15 BLADE

VW 12/15

By Vehicle list – as displayed on AD100Pro/MVPPPro

This list cross-references Pro Menu to the Smart Pro By System list

BY VEHICLE	POLO	6N 6K	READ PINCODE	AKK				PIN READ KW1281 EMS BLADE
BY VEHICLE	POLO	6N 6K	READ PINCODE	AKP				PIN READ KW1281 EMS BLADE
BY VEHICLE	POLO	6N 6K	READ PINCODE	AKU				PIN READ EDC15 BLADE
BY VEHICLE	POLO	6N 6K	READ PINCODE	ALD				PIN READ KW1281 EMS BLADE
BY VEHICLE	POLO	6N 6K	READ PINCODE	ALH				PIN READ EDC15 BLADE
BY VEHICLE	POLO	6N 6K	READ PINCODE	AMF				PIN READ EDC15 BLADE
BY VEHICLE	POLO	6N 6K	READ PINCODE	ANU				PIN READ EDC15 BLADE
BY VEHICLE	POLO	6N 6K	READ PINCODE	ANW				PIN READ KW1281 EMS BLADE
BY VEHICLE	POLO	6N 6K	READ PINCODE	ANY				PIN READ EDC15 BLADE
BY VEHICLE	POLO	6N 6K	READ PINCODE	APE				PIN READ KW1281 EMS BLADE
BY VEHICLE	POLO	6N 6K	READ PINCODE	AQM				PIN READ EDC15 BLADE
BY VEHICLE	POLO	6N 6K	READ PINCODE	ASX				PIN READ EDC15 BLADE
BY VEHICLE	POLO	6N 6K	READ PINCODE	ATL				PIN READ EDC15 BLADE
BY VEHICLE	POLO	6N 6K	READ PINCODE	AUA				PIN READ KW1281 EMS BLADE
BY VEHICLE	POLO	6N 6K	READ PINCODE	AUC				PIN READ KW1281 EMS BLADE
BY VEHICLE	POLO	6N 6K	READ PINCODE	AUD				PIN READ KW1281 EMS BLADE
BY VEHICLE	POLO	6N 6K	READ PINCODE	AXU				PIN READ KW2000 EMS 1 BLADE
BY VEHICLE	POLO	6N 6K	READ PINCODE	BCA				PIN READ KW2000 EMS 1 BLADE
BY VEHICLE	POLO	6N 6K	READ PINCODE	BJX				PIN READ KW1281 EMS BLADE
BY VEHICLE	POLO	9N	IMMOBILISER	TYPE 1				IMMOBILISER KW1281 TYPE 1 BLADE
BY VEHICLE	POLO	9N	IMMOBILISER	TYPE 2				IMMOBILISER KW1281 TYPE 2 BLADE
BY VEHICLE	POLO	9N	REMOTE	TYPE 1				REMOTE KW1281 TYPE 3 BLADE
BY VEHICLE	POLO	9N	REMOTE	TYPE 2				REMOTE KW1281 TYPE 4 BLADE
BY VEHICLE	POLO	9N	REMOTE	TYPE 3				REMOTE TP20 TYPE 8 BLADE
BY VEHICLE	POLO	9N	REMOTE	TYPE 4				REMOTE TP20 TYPE 9 BLADE
BY VEHICLE	POLO	9N	REMOTE	TYPE 5				REMOTE TP20 TYPE 6 BLADE
BY VEHICLE	POLO	9N	READ PINCODE	AUTOCLUSTER				PIN READ AUTO CLUSTER BLADE
BY VEHICLE	POLO	9N	READ PINCODE	AGP				PIN READ EDC15 BLADE
BY VEHICLE	POLO	9N	READ PINCODE	AGU				PIN READ AUTO CLUSTER BLADE
BY VEHICLE	POLO	9N	READ PINCODE	AMF				PIN READ EDC15 BLADE
BY VEHICLE	POLO	9N	READ PINCODE	ASY				PIN READ EDC15 BLADE
BY VEHICLE	POLO	9N	READ PINCODE	ASZ				PIN READ EDC15 BLADE
BY VEHICLE	POLO	9N	READ PINCODE	ATD				PIN READ EDC15 BLADE
BY VEHICLE	POLO	9N	READ PINCODE	AUA				PIN READ AUTO CLUSTER BLADE
BY VEHICLE	POLO	9N	READ PINCODE	AUD				PIN READ EDC15 BLADE
BY VEHICLE	POLO	9N	READ PINCODE	AVY				PIN READ AUTO CLUSTER BLADE
BY VEHICLE	POLO	9N	READ PINCODE	AWP				PIN READ EDC15 BLADE
BY VEHICLE	POLO	9N	READ PINCODE	AWY				PIN READ AUTO CLUSTER BLADE
BY VEHICLE	POLO	9N	READ PINCODE	AXR				PIN READ EDC15 BLADE
BY VEHICLE	POLO	9N	READ PINCODE	AXX				PIN READ MED 91 TYPE 1 BLADE
BY VEHICLE	POLO	9N	READ PINCODE	AYQ				PIN READ EDC15 BLADE
BY VEHICLE	POLO	9N	READ PINCODE	AZQ				PIN READ AUTO CLUSTER BLADE
BY VEHICLE	POLO	9N	READ PINCODE	BAH				PIN READ KW1281 EMS BLADE
BY VEHICLE	POLO	9N	READ PINCODE	BAY				PIN READ EDC15 BLADE
BY VEHICLE	POLO	9N	READ PINCODE	BBM				PIN READ AUTO CLUSTER BLADE
BY VEHICLE	POLO	9N	READ PINCODE	BBY				PIN READ AUTO CLUSTER BLADE
BY VEHICLE	POLO	9N	READ PINCODE	BBZ				PIN READ AUTO CLUSTER BLADE
BY VEHICLE	POLO	9N	READ PINCODE	BGU				PIN READ AUTO CLUSTER BLADE
BY VEHICLE	POLO	9N	READ PINCODE	BJX				PIN READ KW1281 EMS BLADE
BY VEHICLE	POLO	9N	READ PINCODE	BKR				PIN READ AUTO CLUSTER BLADE
BY VEHICLE	POLO	9N	READ PINCODE	BKY				PIN READ AUTO CLUSTER BLADE
BY VEHICLE	POLO	9N	READ PINCODE	BLF				PIN READ MED 9510 BLADE
BY VEHICLE	POLO	9N	READ PINCODE	BLM				PIN READ AUTO CLUSTER BLADE
BY VEHICLE	POLO	9N	READ PINCODE	BLT				PIN READ EDC15 BLADE
BY VEHICLE	POLO	9N	READ PINCODE	BMD				PIN READ AUTO CLUSTER BLADE
BY VEHICLE	POLO	9N	READ PINCODE	BME				PIN READ AUTO CLUSTER BLADE
BY VEHICLE	POLO	9N	READ PINCODE	BMS				PIN READ EDC17 BLADE
BY VEHICLE	POLO	9N	READ PINCODE	BMT				PIN READ EDC17 BLADE
BY VEHICLE	POLO	9N	READ PINCODE	BNM				PIN READ EDC15 BLADE
BY VEHICLE	POLO	9N	READ PINCODE	BRU				PIN READ EDC16U1 TYPE 1 BLADE
BY VEHICLE	POLO	9N	READ PINCODE	BTS				PIN READ KW2000 EMS 1 BLADE
BY VEHICLE	POLO	9N	READ PINCODE	BUD				PIN READ AUTO CLUSTER BLADE
BY VEHICLE	POLO	9N	READ PINCODE	BWB				PIN READ EDC17 BLADE
BY VEHICLE	POLO	9N	READ PINCODE	BZG				PIN READ AUTO CLUSTER BLADE
BY VEHICLE	ROUTAN	IMMOBILISER						IMMOBILISER FOBIK
BY VEHICLE	ROUTAN	SKIM READING						PIN READ SKIM FOBIK

VW 13/15

By Vehicle list – as displayed on AD100Pro/MVPPPro

This list cross-references Pro Menu to the Smart Pro By System list

BY VEHICLE	SAVEIRO	5U	IMMOBILISER	TYPE 1		IMMOBILISER KW1281 TYPE 1 BLADE
BY VEHICLE	SAVEIRO	5U	IMMOBILISER	TYPE 2		IMMOBILISER KW2000 TYPE 1 BLADE
BY VEHICLE	SAVEIRO	5U	REMOTE	TYPE 1		REMOTE KW1281 TYPE 3 BLADE
BY VEHICLE	SAVEIRO	5U	REMOTE	TYPE 2		REMOTE KW1281 TYPE 4 BLADE
BY VEHICLE	SAVEIRO	5U	REMOTE	TYPE 3		REMOTE TP20 TYPE 8 BLADE
BY VEHICLE	SAVEIRO	5U	REMOTE	TYPE 4		REMOTE TP20 TYPE 9 BLADE
BY VEHICLE	SAVEIRO	5U	REMOTE	TYPE 5		REMOTE TP20 TYPE 4 BLADE
BY VEHICLE	SAVEIRO	5U	READ PINCODE	IMMOBILISER BOX		PIN READ IMMO BOX BLADE
BY VEHICLE	SAVEIRO	5U	READ PINCODE	CCRA		PIN READ KW2000 EMS 2 BLADE
BY VEHICLE	SAVEIRO	5U	READ PINCODE	CFZA		PIN READ KW2000 EMS 2 BLADE
BY VEHICLE	SAVEIRO	5U	AUTO GEARBOX			SPECIAL FUNCTION AUTO GEARBOX
BY VEHICLE	SCIROCCO	2009-2011				IMMOBILISER UDS VDO BLADE
BY VEHICLE	SHARAN	7M8 7M9	IMMOBILISER			IMMOBILISER KW1281 TYPE 1 BLADE
BY VEHICLE	SHARAN	7M8 7M9	REMOTE	TYPE 1		REMOTE KW1281 TYPE 3 BLADE
BY VEHICLE	SHARAN	7M8 7M9	REMOTE	TYPE 2		REMOTE KW1281 TYPE 4 BLADE
BY VEHICLE	SHARAN	7M8 7M9	REMOTE	TYPE 3		REMOTE TP20 TYPE 8 BLADE
BY VEHICLE	SHARAN	7M8 7M9	REMOTE	TYPE 4		REMOTE TP20 TYPE 9 BLADE
BY VEHICLE	SHARAN	7M8 7M9	SRS AIRBAG			SPECIAL FUNCTION VAG SRS
BY VEHICLE	SHARAN	7M8 7M9	AUTO GEARBOX			SPECIAL FUNCTION AUTO GEARBOX
BY VEHICLE	SHARAN	7M8 7M9	READ PINCODE	AFN		PIN READ EDC15 BLADE
BY VEHICLE	SHARAN	7M8 7M9	READ PINCODE	AHU		PIN READ EDC15 BLADE
BY VEHICLE	SHARAN	7M8 7M9	READ PINCODE	ANU		PIN READ EDC15 BLADE
BY VEHICLE	SHARAN	7M8 7M9	READ PINCODE	ASZ		PIN READ EDC15 BLADE
BY VEHICLE	SHARAN	7M8 7M9	READ PINCODE	ATM		PIN READ KW1281 EMS BLADE
BY VEHICLE	SHARAN	7M8 7M9	READ PINCODE	AUY		PIN READ EDC15 BLADE
BY VEHICLE	SHARAN	7M8 7M9	READ PINCODE	AVG		PIN READ EDC15 BLADE
BY VEHICLE	SHARAN	7M8 7M9	READ PINCODE	AWC		PIN READ KW1281 EMS BLADE
BY VEHICLE	SHARAN	7M8 7M9	READ PINCODE	AYL		PIN READ KW1281 EMS BLADE
BY VEHICLE	SHARAN	7M8 7M9	READ PINCODE	BRT		PIN READ EDC16U31 TYPE 2 BLADE
BY VEHICLE	SHARAN	7M8 7M9	READ PINCODE	BTB		PIN READ EDC15 BLADE
BY VEHICLE	SHARAN	7M8 7M9	READ PINCODE	BVH		PIN READ EDC16U31 TYPE 2 BLADE
BY VEHICLE	SHARAN	7M8 7M9	READ PINCODE	BVK		PIN READ EDC15 BLADE
BY VEHICLE	SHARAN	7M6	IMMOBILISER			IMMOBILISER KW1281 TYPE 2 BLADE
BY VEHICLE	SHARAN	7M6	REMOTE	TYPE 1		REMOTE KW1281 TYPE 3 BLADE
BY VEHICLE	SHARAN	7M6	REMOTE	TYPE 2		REMOTE KW1281 TYPE 4 BLADE
BY VEHICLE	SHARAN	7M6	REMOTE	TYPE 3		REMOTE TP20 TYPE 8 BLADE
BY VEHICLE	SHARAN	7M6	REMOTE	TYPE 4		REMOTE TP20 TYPE 9 BLADE
BY VEHICLE	SHARAN	7M6	SRS AIRBAG			SPECIAL FUNCTION VAG SRS
BY VEHICLE	SHARAN	7M6	READ PINCODE	AUTOCLUSTER		PIN READ AUTO CLUSTER BLADE
BY VEHICLE	SHARAN	7M6	READ PINCODE	ANU		PIN READ EDC15 BLADE
BY VEHICLE	SHARAN	7M6	READ PINCODE	ASZ		PIN READ EDC15 BLADE
BY VEHICLE	SHARAN	7M6	READ PINCODE	ATM		PIN READ KW1281 EMS BLADE
BY VEHICLE	SHARAN	7M6	READ PINCODE	AUY		PIN READ EDC15 BLADE
BY VEHICLE	SHARAN	7M6	READ PINCODE	AWC		PIN READ KW1281 EMS BLADE
BY VEHICLE	SHARAN	7M6	READ PINCODE	AYL		PIN READ KW1281 EMS BLADE
BY VEHICLE	SHARAN	7M6	READ PINCODE	BRT		PIN READ EDC16U31 TYPE 2 BLADE
BY VEHICLE	SHARAN	7M6	READ PINCODE	BTB		PIN READ EDC15 BLADE
BY VEHICLE	SHARAN	7M6	READ PINCODE	BVH		PIN READ EDC16U31 TYPE 2 BLADE
BY VEHICLE	SHARAN	7M6	READ PINCODE	BVK		PIN READ EDC15 BLADE
BY VEHICLE	TIGUAN	5N	IMMOBILISER	2003-2009		IMMOBILISER TP20 TYPE 2 BLADE
BY VEHICLE	TIGUAN	5N	IMMOBILISER	2009-2011		IMMOBILISER UDS VDO BLADE
BY VEHICLE	TIGUAN	5N	REMOTE	TYPE 1		REMOTE TP20 TYPE 6 BLADE
BY VEHICLE	TIGUAN	5N	REMOTE	TYPE 2		REMOTE TP20 TYPE 7 BLADE
BY VEHICLE	TIGUAN	5N	READ PINCODE	CBAA		PIN READ EDC17 BLADE
BY VEHICLE	TIGUAN	5N	READ PINCODE	CBAB		PIN READ EDC17 BLADE
BY VEHICLE	TIGUAN	5N	READ PINCODE	CBBA		PIN READ EDC17 BLADE
BY VEHICLE	TIGUAN	5N	READ PINCODE	CBBB		PIN READ EDC17 BLADE
BY VEHICLE	TOUAREG	7LA	IMMOBILISER			IMMOBILISER KW2000 KESSY BLADE
BY VEHICLE	TOUAREG	7LA	READ PINCODE	AQX		PIN READ KW2000 EMS 1 BLADE
BY VEHICLE	TOUAREG	7LA	READ PINCODE	ASY		PIN READ EDC15 BLADE
BY VEHICLE	TOUAREG	7LA	READ PINCODE	AXQ		PIN READ KW2000 EMS 1 BLADE
BY VEHICLE	TOUAREG	7LA	READ PINCODE	AYH		PIN READ EDC16U1 TYPE 2 BLADE
BY VEHICLE	TOUAREG	7LA	READ PINCODE	AZL		PIN READ KW2000 EMS 1 BLADE
BY VEHICLE	TOUAREG	7LA	READ PINCODE	AZZ		PIN READ KW2000 EMS 1 BLADE
BY VEHICLE	TOUAREG	7LA	READ PINCODE	BAA		PIN READ KW2000 EMS 1 BLADE
BY VEHICLE	TOUAREG	7LA	READ PINCODE	BAC		PIN READ EDC16U1 TYPE 2 BLADE

VW 14/15

By Vehicle list – as displayed on AD100Pro/MVPPPro

This list cross-references Pro Menu to the Smart Pro By System list

BY VEHICLE	TOUAREG	7LA	READ PINCODE	BAR			PIN READ MED 91 TYPE 2 BLADE
BY VEHICLE	TOUAREG	7LA	READ PINCODE	BBK			PIN READ KW2000 EMS 1 BLADE
BY VEHICLE	TOUAREG	7LA	READ PINCODE	BHK			PIN READ MED 91 TYPE 2 BLADE
BY VEHICLE	TOUAREG	7LA	READ PINCODE	BHL			PIN READ MED 91 TYPE 2 BLADE
BY VEHICLE	TOUAREG	7LA	READ PINCODE	BHP			PIN READ KW2000 EMS 1 BLADE
BY VEHICLE	TOUAREG	7LA	READ PINCODE	BJN			PIN READ KW2000 EMS 1 BLADE
BY VEHICLE	TOUAREG	7LA	READ PINCODE	BKJ			PIN READ KW2000 EMS 1 BLADE
BY VEHICLE	TOUAREG	7LA	READ PINCODE	BKS			PIN READ EDC16U34 TYPE 2 BLADE
BY VEHICLE	TOUAREG	7LA	READ PINCODE	BKW			PIN READ EDC16U1 TYPE 2 BLADE
BY VEHICLE	TOUAREG	7LA	READ PINCODE	BLE			PIN READ EDC16U31 TYPE 2 BLADE
BY VEHICLE	TOUAREG	7LA	READ PINCODE	BLG			PIN READ MED 9510 BLADE
BY VEHICLE	TOUAREG	7LA	READ PINCODE	BLK			PIN READ EDC16U1 TYPE 2 BLADE
BY VEHICLE	TOUAREG	7LA	READ PINCODE	BMV			PIN READ KW2000 EMS 1 BLADE
BY VEHICLE	TOUAREG	7LA	READ PINCODE	BMX			PIN READ KW2000 EMS 1 BLADE
BY VEHICLE	TOUAREG	7LA	READ PINCODE	BPD			PIN READ EDC16U31 TYPE 2 BLADE
BY VEHICLE	TOUAREG	7LA	READ PINCODE	BPE			PIN READ EDC16U31 TYPE 2 BLADE
BY VEHICLE	TOUAREG	7LA	READ PINCODE	BPU			PIN READ MED 17.5 BLADE
BY VEHICLE	TOUAREG	7LA	READ PINCODE	BRJ			PIN READ KW2000 EMS 1 BLADE
BY VEHICLE	TOUAREG	7LA	READ PINCODE	BUN			PIN READ EDC16U34 TYPE 2 BLADE
BY VEHICLE	TOUAREG	7LA	READ PINCODE	BWF			PIN READ EDC16U31 TYPE 2 BLADE
BY VEHICLE	TOUAREG	7LA	READ PINCODE	CASA			PIN READ EDC17 BLADE
BY VEHICLE	TOUAREG	7LA	READ PINCODE	CASB			PIN READ EDC17 BLADE
BY VEHICLE	TOUAREG	7LA	READ PINCODE	CASC			PIN READ EDC17 BLADE
BY VEHICLE	TOUAREG	7LA	READ PINCODE	CATA			PIN READ EDC17 BLADE
BY VEHICLE	TOURAN	1T1 1T2	IMMOBILISER	2003-2009			IMMOBILISER TP20 TYPE 2 BLADE
BY VEHICLE	TOURAN	1T1 1T2	IMMOBILISER	2009-2011			IMMOBILISER UDS VDO BLADE
BY VEHICLE	TOURAN	1T1 1T2	REMOTE	TYPE 1			REMOTE TP20 TYPE 6 BLADE
BY VEHICLE	TOURAN	1T1 1T2	REMOTE	TYPE 2			REMOTE TP20 TYPE 7 BLADE
BY VEHICLE	TOURAN	1T1 1T2	READ PINCODE	AVQ			PIN READ EDC16U1 TYPE 1 BLADE
BY VEHICLE	TOURAN	1T1 1T2	READ PINCODE	AXW			PIN READ MED 9510 BLADE
BY VEHICLE	TOURAN	1T1 1T2	READ PINCODE	AZV		EDC16U1	PIN READ EDC16U1 TYPE 1 BLADE
BY VEHICLE	TOURAN	1T1 1T2	READ PINCODE	AZV		EDC16U31	PIN READ EDC16U31 TYPE 1 BLADE
BY VEHICLE	TOURAN	1T1 1T2	READ PINCODE	BAG			PIN READ MED 9510 BLADE
BY VEHICLE	TOURAN	1T1 1T2	READ PINCODE	BKC			PIN READ EDC16U1 TYPE 1 BLADE
BY VEHICLE	TOURAN	1T1 1T2	READ PINCODE	BKD			PIN READ EDC16U1 TYPE 1 BLADE
BY VEHICLE	TOURAN	1T1 1T2	READ PINCODE	BLF			PIN READ MED 9510 BLADE
BY VEHICLE	TOURAN	1T1 1T2	READ PINCODE	BLG			PIN READ MED 9510 BLADE
BY VEHICLE	TOURAN	1T1 1T2	READ PINCODE	BLP			PIN READ MED 9510 BLADE
BY VEHICLE	TOURAN	1T1 1T2	READ PINCODE	BLR			PIN READ MED 9510 BLADE
BY VEHICLE	TOURAN	1T1 1T2	READ PINCODE	BLS			PIN READ EDC16U34 TYPE 1 BLADE
BY VEHICLE	TOURAN	1T1 1T2	READ PINCODE	BLX			PIN READ MED 9510 BLADE
BY VEHICLE	TOURAN	1T1 1T2	READ PINCODE	BLY			PIN READ MED 9510 BLADE
BY VEHICLE	TOURAN	1T1 1T2	READ PINCODE	BMM			PIN READ EDC16U34 TYPE 1 BLADE
BY VEHICLE	TOURAN	1T1 1T2	READ PINCODE	BMN			PIN READ PPD 1115 BLADE
BY VEHICLE	TOURAN	1T1 1T2	READ PINCODE	BMV			PIN READ MED 17.5 BLADE
BY VEHICLE	TOURAN	1T1 1T2	READ PINCODE	BRU			PIN READ EDC16U1 TYPE 1 BLADE
BY VEHICLE	TOURAN	1T1 1T2	READ PINCODE	BSX			PIN READ KW2000 EMS 1 BLADE
BY VEHICLE	TOURAN	1T1 1T2	READ PINCODE	BVX			PIN READ MED 9510 BLADE
BY VEHICLE	TOURAN	1T1 1T2	READ PINCODE	BVY			PIN READ MED 9510 BLADE
BY VEHICLE	TOURAN	1T1 1T2	READ PINCODE	BVZ			PIN READ MED 9510 BLADE
BY VEHICLE	TOURAN	1T1 1T2	READ PINCODE	BXE		EDC16U31	PIN READ EDC16U31 TYPE 1 BLADE
BY VEHICLE	TOURAN	1T1 1T2	READ PINCODE	BXE		EDC16U34	PIN READ EDC16U34 TYPE 1 BLADE
BY VEHICLE	TOURAN	1T1 1T2	READ PINCODE	BXF			PIN READ EDC16U34 TYPE 1 BLADE
BY VEHICLE	TOURAN	1T1 1T2	READ PINCODE	BXJ			PIN READ EDC16U34 TYPE 1 BLADE
BY VEHICLE	TRANSPORTER	7D 70	IMMOBILISER				IMMOBILISER KW1281 TYPE 1 BLADE
BY VEHICLE	TRANSPORTER	7D 70	REMOTE	TYPE 1			REMOTE KW1281 TYPE 3 BLADE
BY VEHICLE	TRANSPORTER	7D 70	REMOTE	TYPE 2			REMOTE KW1281 TYPE 4 BLADE
BY VEHICLE	TRANSPORTER	7D 70	REMOTE	TYPE 3			REMOTE TP20 TYPE 8 BLADE
BY VEHICLE	TRANSPORTER	7D 70	REMOTE	TYPE 4			REMOTE TP20 TYPE 9 BLADE
BY VEHICLE	TRANSPORTER	7D 70	SRS AIRBAG				SPECIAL FUNCTION VAG SRS
BY VEHICLE	TRANSPORTER	7D 70	AUTO GEARBOX				SPECIAL FUNCTION AUTO GEARBOX
BY VEHICLE	TRANSPORTER	7D 70	READ PINCODE	ACV			PIN READ EDC15 BLADE
BY VEHICLE	TRANSPORTER	7D 70	READ PINCODE	AHY			PIN READ EDC15 BLADE
BY VEHICLE	TRANSPORTER	7D 70	READ PINCODE	AJT			PIN READ EDC15 BLADE
BY VEHICLE	TRANSPORTER	7D 70	READ PINCODE	AUF			PIN READ EDC15 BLADE
BY VEHICLE	TRANSPORTER	7D 70	READ PINCODE	AXG			PIN READ EDC15 BLADE

BY VEHICLE	TRANSPORTER	7D 70	READ PINCODE	AXL			PIN READ EDC15 BLADE
BY VEHICLE	TRANSPORTER	7D 70	READ PINCODE	AYC			PIN READ EDC15 BLADE
BY VEHICLE	TRANSPORTER	7D 70	READ PINCODE	AYY			PIN READ EDC15 BLADE
BY VEHICLE	TRANSPORTER	7H	IMMOBILISER				IMMOBILISER KW1281 TYPE 2 BLADE
BY VEHICLE	TRANSPORTER	7H	REMOTE	TYPE 1			REMOTE KW1281 TYPE 3 BLADE
BY VEHICLE	TRANSPORTER	7H	REMOTE	TYPE 2			REMOTE KW1281 TYPE 4 BLADE
BY VEHICLE	TRANSPORTER	7H	REMOTE	TYPE 3			REMOTE TP20 TYPE 8 BLADE
BY VEHICLE	TRANSPORTER	7H	REMOTE	TYPE 4			REMOTE TP20 TYPE 9 BLADE
BY VEHICLE	TRANSPORTER	7H	READ PINCODE	AUTOCLUSTER			PIN READ AUTO CLUSTER BLADE
BY VEHICLE	TRANSPORTER	7H	READ PINCODE	AXA			PIN READ KW1281 EMS BLADE
BY VEHICLE	TRANSPORTER	7H	READ PINCODE	AXB			PIN READ EDC16U1 TYPE 2 BLADE
BY VEHICLE	TRANSPORTER	7H	READ PINCODE	AXC			PIN READ EDC16U31 TYPE 2 BLADE
BY VEHICLE	TRANSPORTER	7H	READ PINCODE	AXD			PIN READ EDC16U31 TYPE 2 BLADE
BY VEHICLE	TRANSPORTER	7H	READ PINCODE	AXE			PIN READ EDC16U31 TYPE 2 BLADE
BY VEHICLE	TRANSPORTER	7H	READ PINCODE	BDL			PIN READ KW1281 EMS BLADE
BY VEHICLE	TRANSPORTER	7H	READ PINCODE	BKK			PIN READ KW1281 EMS BLADE
BY VEHICLE	TRANSPORTER	7H	READ PINCODE	BNZ			PIN READ EDC16U31 TYPE 2 BLADE
BY VEHICLE	TRANSPORTER	7H	READ PINCODE	BPC			PIN READ EDC16U31 TYPE 2 BLADE
BY VEHICLE	TRANSPORTER	7H	READ PINCODE	BRR			PIN READ EDC16U31 TYPE 2 BLADE
BY VEHICLE	TRANSPORTER	7H	READ PINCODE	BRS			PIN READ EDC16U31 TYPE 2 BLADE
BY VEHICLE	TRANSPORTER	7HC	IMMOBILISER				IMMOBILISER KW1281 TYPE 2 BLADE
BY VEHICLE	TRANSPORTER	7HC	REMOTE	TYPE 1			REMOTE KW1281 TYPE 3 BLADE
BY VEHICLE	TRANSPORTER	7HC	REMOTE	TYPE 2			REMOTE KW1281 TYPE 4 BLADE
BY VEHICLE	TRANSPORTER	7HC	REMOTE	TYPE 3			REMOTE TP20 TYPE 8 BLADE
BY VEHICLE	TRANSPORTER	7HC	REMOTE	TYPE 4			REMOTE TP20 TYPE 9 BLADE
BY VEHICLE	TRANSPORTER	7HC	READ PINCODE	AUTOCLUSTER			PIN READ AUTO CLUSTER BLADE
BY VEHICLE	TRANSPORTER	7HC	READ PINCODE	AXA			PIN READ KW1281 EMS BLADE
BY VEHICLE	TRANSPORTER	7HC	READ PINCODE	AXB			PIN READ EDC16U1 TYPE 2 BLADE
BY VEHICLE	TRANSPORTER	7HC	READ PINCODE	AXC			PIN READ EDC16U31 TYPE 2 BLADE
BY VEHICLE	TRANSPORTER	7HC	READ PINCODE	AXD			PIN READ EDC16U31 TYPE 2 BLADE
BY VEHICLE	TRANSPORTER	7HC	READ PINCODE	AXE			PIN READ EDC16U31 TYPE 2 BLADE
BY VEHICLE	TRANSPORTER	7HC	READ PINCODE	BDL			PIN READ KW1281 EMS BLADE
BY VEHICLE	TRANSPORTER	7HC	READ PINCODE	BKK			PIN READ KW1281 EMS BLADE
BY VEHICLE	TRANSPORTER	7HC	READ PINCODE	BNZ			PIN READ EDC16U31 TYPE 2 BLADE
BY VEHICLE	TRANSPORTER	7HC	READ PINCODE	BPC			PIN READ EDC16U31 TYPE 2 BLADE
BY VEHICLE	TRANSPORTER	7HC	READ PINCODE	BRR			PIN READ EDC16U31 TYPE 2 BLADE
BY VEHICLE	TRANSPORTER	7HC	READ PINCODE	BRS			PIN READ EDC16U31 TYPE 2 BLADE
BY VEHICLE	TRANSPORTER	7J	IMMOBILISER				IMMOBILISER KW1281 TYPE 1 BLADE
BY VEHICLE	TRANSPORTER	7J	REMOTE	TYPE 1			REMOTE KW1281 TYPE 3 BLADE
BY VEHICLE	TRANSPORTER	7J	REMOTE	TYPE 2			REMOTE KW1281 TYPE 4 BLADE
BY VEHICLE	TRANSPORTER	7J	REMOTE	TYPE 3			REMOTE TP20 TYPE 8 BLADE
BY VEHICLE	TRANSPORTER	7J	REMOTE	TYPE 4			REMOTE TP20 TYPE 9 BLADE
BY VEHICLE	TRANSPORTER	7J	READ PINCODE	AUTOCLUSTER			PIN READ AUTO CLUSTER BLADE
BY VEHICLE	TRANSPORTER	7J	READ PINCODE	AXA			PIN READ KW1281 EMS BLADE
BY VEHICLE	TRANSPORTER	7J	READ PINCODE	AXB			PIN READ KW1281 EMS BLADE
BY VEHICLE	TRANSPORTER	7J	READ PINCODE	AXC			PIN READ EDC16U31 TYPE 2 BLADE
BY VEHICLE	TRANSPORTER	7J	READ PINCODE	AXD			PIN READ EDC16U31 TYPE 2 BLADE
BY VEHICLE	TRANSPORTER	7J	READ PINCODE	AXE			PIN READ EDC16U31 TYPE 2 BLADE
BY VEHICLE	TRANSPORTER	7J	READ PINCODE	BDL			PIN READ KW1281 EMS BLADE
BY VEHICLE	TRANSPORTER	7J	READ PINCODE	BNZ			PIN READ EDC16U31 TYPE 2 BLADE
BY VEHICLE	TRANSPORTER	7J	READ PINCODE	BPC			PIN READ EDC16U31 TYPE 2 BLADE
BY VEHICLE	TRANSPORTER	7J	READ PINCODE	BRR			PIN READ EDC16U31 TYPE 2 BLADE
BY VEHICLE	TRANSPORTER	7J	READ PINCODE	BRS			PIN READ EDC16U31 TYPE 2 BLADE
BY VEHICLE	UP	IMMOBILISER					IMMOBILISER UDS MARELLI BLADE

VW 15/15

By Vehicle list – as displayed on AD100Pro/MVPPPro

This list cross-references Pro Menu to the Smart Pro By System list