

INSTRUCTION REFERS TO MODELS:

ERGOWORK chair LK Standard BLCPT Black, ERGOWORK chair LK Standard BCPT Black Plus, ERGOWORK chair PRO Standard BCPT Black, ERGOWORK chair PRO Standard BCPT Black Plus, ERGOWORK chair PRO Standard BCPT Blue, ERGOWORK chair PRO Standard BCPT Blue Plus, ERGOWORK chair PRO Standard BCPT Green, ERGOWORK chair PRO Standard BCPT Green Plus, ERGOWORK chair PRO Standard BCPT Grey, ERGOWORK chair PRO Standard BCPT Grey Plus, ERGOWORK chair PRO Standard BCPT Red, ERGOWORK chair PRO Standard BCPT Red Plus.

LIST OF INCLUDED PARTS:

Before the assembly, please make sure that all parts specified below are included in a package:

1. Backrest with metal plate, small knob - 1 set
2. Seat with a metal plate - 1 set (for chair type „Plus”, armrests may be already fixed to the seat)
3. Mechanism with a knob - 1 set
4. Column with a cover - 1 piece
5. A five branched base - 1 piece
6. Castors - 5 pieces

MONTAGE INSTRUCTIONS



1. Fix castors (1) inside the five branched base (2).
2. Fix the column with a plate (3) into the base hole (2).
3. Fix the seat-backrest fixing element (5) into the seat sheet's guideways (4) and fix it with a bigger dial.
4. Insert the metal fixing element screwed to the backrest (6) into the end of a connector (5) and fix the smaller knob.
5. Backrest (7) mounted with a seat (5) place on the column pin (3).
6. Adjust the seat's and backrest's height and fix the adjusting screws.