

INSTRUCTION REFERS TO MODELS:

ERGOWORK chair PRO Special ChCPT Black, ERGOWORK chair PRO, Special ChL Black, ERGOWORK chair PRO Special ChL Blue, ERGOWORK chair PRO Special ChL Green, ERGOWORK chair PRO Special ChL Grey, ERGOWORK chair PRO Special ChL Red.

LIST OF INCLUDED PARTS:

Before the assembly, please make sure that all parts specified below are included in a package:

1. Backrest with metal plate, small knob - 1 set
2. Seat with a metal plate - 1 set (for the chair type „Plus”, armrests may be already fixed to the seat)
3. Mechanism with a long knob - 1 set
4. Column - 1 piece
5. Footrest with a knob - 1 piece
6. A five branched base - 1 piece
7. Glides- 5 pieces

ASSEMBLY INSTRUCTION



1. Fix glides (1) inside the five branched base (2).
Fix the column (3) into the base hole (2).
Fix the footrest (4) into the column (3).
ATTENTION!
Mounting a footrest, the chrome-plated rim must be placed on 3-armed, black bracket (on the top).
2. Insert the seat-backrest fixing element (6) into the seat sheet's guideways (5) and fix it with a long knob.
3. Unscrew the smaller knob from the backrest (7), place the seat-backrest fixing element (6) and screw the knob once again.
4. Backrest (7) mounted with a seat (5) place on the column pin (4).
5. Adjust the seat's and backrest's height and fix the adjusting screws.